



Digitized Automation for a Changing World

# AX-8 Series Operation Manual

# AX-8 Series Operation Manual

## Revision History

| Version         | Revision   | Date       |
|-----------------|--|------------|
| 1 <sup>st</sup> | The first version was published.   | 2024/03/01 |
| 2 <sup>nd</sup> | <ol style="list-style-type: none"><li>Chapter 2: Modified the execution time of instructions for AX-8 and AX-8H1 in section 2.2.1; modified the information on the LINK indicator for Ethernet port in section 2.2.3; added SSI wiring in section 2.2.5.3.</li><li>Chapter 9: Added Modbus COM port number setting and range for AX-8 models with the Linux / Windows operating system.</li></ol>  | 2024/12/30 |
| 3 <sup>rd</sup> | <ol style="list-style-type: none"><li>Chapter 1: Added information about the new module, AX-864EP1ME1TP.</li><li>Chapter 2: Added information about the new module, AX-864EP1ME1TP.</li><li>Chapter 3: Rearrange the layout of section 3.1.1; added information about the new module, AX-864EP1ME1TP in section 3.1.2; update the number of the latest version of DIADesigner-AX in section 3.2.</li></ol>   | 2025/04/30 |
| 4 <sup>th</sup> | <ol style="list-style-type: none"><li>Chapter 1: Added information about the new module, AX-8DH1ECP1CE1TP.</li><li>Chapter 2: Added information about the new module, AX-8DH1ECP1CE1TP; revised the description of shock resistance in section 2.1; added a warning about USB 3.0-related interference issues and the maximum number of nodes for read and write operations in section 2.2.1; revised the power consumption of AX-864EP1ME1TP in section 2.2.2; updated the USB port marking for AX-864EP1ME1TP in sections 2.2.3, 2.2.4 and 2.2.5.5.</li><li>Chapter 3: Added installation instructions for AX-8DH1ECP1CE1TP and updated the USB port marking for AX-864EP1ME1TP in sections 3.1.1 and 3.1.2.</li><li>Chapter 4: Added section 4.1 to introduce LCM display operation.</li><li>Appendix C: Revised the information about replacement of original project with USB backup project in section C.4; combined the original sections C.5 and C.9 into a new section "C.7 System Operation" ; updated the reference sections for situation when the PLC IP cannot be confirmed in section C.6.1; removed the original sections "C.7.2 Restore PLC" and "C.8 Replace Original Project with Backup Project" .</li></ol> | 2025/09/09 |



# AX-8 Series Operation Manual

## Table of Contents

### Chapter 1 Product Introduction

|   |            |
|---|------------|
| <b>1.1 Overview .....</b>                                 | <b>1-2</b> |
| 1.1.1 Related Manuals .....                               | 1-2        |
| 1.1.2 Model Descriptions .....                            | 1-3        |
| <b>1.2 DIADesigner-AX Software Overview .....</b>         | <b>1-6</b> |
| 1.2.1 Features .....                                      | 1-6        |
| <b>1.3 Electrical Safety Precautions .....</b>            | <b>1-7</b> |
| 1.3.1 Electrical Safety Precautions (English) .....       | 1-7        |
| 1.3.2 Précautions de sécurité électrique (Français) ..... | 1-8        |

### Chapter 2 Specifications and System Configurations

|   |            |
|---|------------|
| <b>2.1 General Specifications .....</b>           | <b>2-2</b> |
| <b>2.2 CPU Module Specifications .....</b>        | <b>2-4</b> |
| 2.2.1 Functional Specifications .....             | 2-4        |
| 2.2.2 Electrical Specifications .....             | 2-10       |
| 2.2.3 CPU Module Profiles .....                   | 2-13       |
| 2.2.4 CPU Module Input / Output Terminals .....   | 2-19       |
| 2.2.5 Wiring Configuration .....                  | 2-21       |
| 2.2.5.1 AX-8□□EP0□□□T Wiring .....                | 2-21       |
| 2.2.5.2 AX-8□□EP0□□□P Wiring .....                | 2-22       |
| 2.2.5.3 AX-8□□EP0□□□T, AX-8□□EP0□□□P Wiring ..... | 2-23       |
| 2.2.5.4 AX-8H1E30CD2T Wiring .....                | 2-25       |
| 2.2.5.4 AX-864EP1ME1TP Wiring .....               | 2-26       |
| 2.2.5.4 AX-8DH1ECP1CE1TP Wiring .....             | 2-28       |

### Chapter 3 Installing Hardware and Getting Started

|   |            |
|---|------------|
| <b>3.1 Installing Hardware .....</b>                    | <b>3-2</b> |
| 3.1.1 Installing and Uninstalling a Memory Card .....   | 3-2        |
| 3.1.2 Installing and Uninstalling a CPU Module .....    | 3-4        |
| 3.1.2.1 AX-8 Series (Except for AX-8DH1ECP1CE1TP) ..... | 3-4        |
| 3.1.2.2 AX-8DH1ECP1CE1TP .....                          | 3-6        |

|                                      |  |             |
|--------------------------------------|--|-------------|
| 3.1.3                                | Installing in the Control Cabinet .....                        | 3-7         |
| 3.1.3.1                              | Installation on a DIN Rail .....                               | 3-7         |
| 3.1.3.2                              | Installation in the Control Cabinet.....                       | 3-8         |
| 3.1.3.3                              | Ambient Temperature Requirements for the Control Cabinet ..... | 3-9         |
| 3.1.3.4                              | Measures to Enhance Anti-interference Ability .....            | 3-9         |
| 3.1.3.5                              | Dimension Requirements for the Control Cabinet .....           | 3-9         |
| <b>3.2</b>                           | <b>Installing and Uninstalling DIADesigner-AX .....</b>        | <b>3-10</b> |
| 3.2.1                                | Installing DIADesigner-AX.....                                 | 3-11        |
| 3.2.2                                | Uninstalling DIADesigner-AX .....                              | 3-16        |
| <b>3.3</b>                           | <b>Getting Started and Setting Up Communication.....</b>       | <b>3-17</b> |
| 3.3.1                                | Getting Started .....  | 3-17        |
| 3.3.2                                | Setting Up Communication.....                                  | 3-18        |
| <br><b>Chapter 4 Basic Operation</b> |  |             |
| <b>4.1</b>                           | <b>LCM Display Operation.....</b>                              | <b>4-3</b>  |
| 4.1.1                                | Overview .....   | 4-4         |
| 4.1.2                                | Home Screen .....  | 4-5         |
| 4.1.3                                | Main Menu Configuration .....                                  | 4-6         |
| 4.1.3.1                              | Information.....   | 4-6         |
| 4.1.3.2                              | Settings.....  | 4-8         |
| 4.1.3.3                              | Error Message .....  | 4-13        |
| 4.1.3.4                              | Performance .....  | 4-14        |
| 4.1.4                                | Error Codes and Descriptions .....                             | 4-15        |
| 4.1.4.1                              | BIOS Error Codes.....  | 4-15        |
| 4.1.4.2                              | Application Error Codes .....                                  | 4-17        |
| <b>4.2</b>                           | <b>Introduction to DIADesigner-AX.....</b>                     | <b>4-18</b> |
| 4.2.1                                | Creating a New Project .....                                   | 4-18        |
| <b>4.3</b>                           | <b>Settings on the Device Page .....</b>                       | <b>4-20</b> |
| 4.3.1                                | CPU Parameter Settings .....                                   | 4-21        |
| 4.3.1.1                              | Communication Settings.....                                    | 4-21        |
| 4.3.1.2                              | Applications .....   | 4-24        |
| 4.3.1.3                              | Backup and Restore .....                                       | 4-25        |
| 4.3.1.4                              | Files.....   | 4-26        |
| 4.3.1.5                              | Log .....  | 4-26        |
| 4.3.1.6                              | PLC Settings.....  | 4-29        |
| 4.3.1.7                              | PLC Shell .....  | 4-31        |

|   |   |             |
|---|---|-------------|
| 4.3.1.8                                 | User and Groups .....                               | 4-32        |
| 4.3.1.9                                 | Access Rights .....                                 | 4-36        |
| 4.3.1.10                                | Symbol Rights .....                                 | 4-42        |
| 4.3.1.11                                | System Settings .....                               | 4-44        |
| 4.3.1.12                                | System Parameters .....                             | 4-46        |
| 4.3.1.13                                | Task Deployment .....                               | 4-47        |
| 4.3.1.14                                | Status .....  | 4-48        |
| 4.3.1.15                                | Information .....                                   | 4-48        |
| <b>4.4</b>                              | <b>Data Type and Variables .....</b>                | <b>4-49</b> |
| 4.4.1                                   | Data Type .....                                     | 4-49        |
| 4.4.2                                   | Variables .....                                     | 4-50        |
| 4.4.2.1                                 | Declaration of Variables .....                      | 4-50        |
| 4.4.2.2                                 | Address Assignment .....                            | 4-51        |
| 4.4.2.3                                 | Variables .....                                     | 4-53        |
| 4.4.2.4                                 | User-defined Data Type .....                        | 4-58        |
| 4.4.2.5                                 | Timing for the Variable being Cleared to Zero ..... | 4-61        |
| 4.4.2.6                                 | Timing for the Default Value to be Valid .....      | 4-61        |
| <b>4.5</b>                              | <b>Task .....</b>                                   | <b>4-62</b> |
| 4.5.1                                   | Task Configuration .....                            | 4-62        |
| 4.5.1.1                                 | Task Type .....                                     | 4-62        |
| 4.5.1.2                                 | Bus Cycle Task .....                                | 4-63        |
| 4.5.1.3                                 | Watchdog .....                                      | 4-64        |
| 4.5.1.4                                 | Motion Instructions for Each Type of Task .....     | 4-65        |
| <b>4.6</b>                              | <b>Recipe Manager .....</b>                         | <b>4-68</b> |
| 4.6.1                                   | Recipe Manager .....                                | 4-70        |
| 4.6.2                                   | Recipe Definition .....                             | 4-72        |
| 4.6.3                                   | RecipeManCommands .....                             | 4-74        |
| <br>                                    |   |             |
| <b>Chapter 5 Hardware Configuration</b> |   |             |
| <b>5.1</b>                              | <b>Hardware Configuration .....</b>                 | <b>5-2</b>  |
| 5.1.1                                   | Environment of Hardware Configuration .....         | 5-2         |
| <br>                                    |   |             |
| <b>Chapter 6 Network Configuration</b>  |   |             |
| <b>6.1</b>                              | <b>Network Configuration .....</b>                  | <b>6-2</b>  |
| 6.1.1                                   | Introduction .....                                  | 6-2         |
| 6.1.2                                   | Basic Knowledge .....                               | 6-3         |

|         |                                   |     |
|---------|-----------------------------------|-----|
| 6.1.3   | Creating a Network Topology ..... | 6-5 |
| 6.1.3.1 | Creating Station Nodes.....       | 6-5 |
| 6.1.3.2 | Creating Connections .....        | 6-7 |

## **Chapter 7 Basic Settings & Operation of Motion Control**

|            |  |             |
|------------|--|-------------|
| <b>7.1</b> | <b>Overview of Motion Control Instructions .....</b>   | <b>7-4</b>  |
| 7.1.1      | Motion Control Instructions.....                       | 7-4         |
| 7.1.2      | Application Notes on Motion Control Instructions ..... | 7-4         |
| 7.1.3      | Categories of Motion Control Instructions.....         | 7-4         |
| <b>7.2</b> | <b>Creating Motion Control Project .....</b>           | <b>7-5</b>  |
| 7.2.1      | Flowchart.....   | 7-5         |
| 7.2.2      | Process for Creating a Project.....                    | 7-5         |
| <b>7.3</b> | <b>Commissioning .....</b>                             | <b>7-10</b> |
| 7.3.1      | Procedure for Commissioning .....                      | 7-10        |
| 7.3.2      | Example of Axis Parameter Settings.....                | 7-10        |
| 7.3.3      | Performing Axes Commissioning .....                    | 7-11        |
| <b>7.4</b> | <b>Motion Control Device .....</b>                     | <b>7-15</b> |
| 7.4.1      | Axis Setting .....                                     | 7-15        |
| 7.4.2      | Axis Introduction .....                                | 7-15        |
| 7.4.2.1    | Introduction to Axis Parameters.....                   | 7-16        |
| 7.4.2.2    | Axis Application in the Program .....                  | 7-25        |
| 7.4.3      | Procedure for Single-axis Configuration .....          | 7-26        |
| 7.4.4      | Axis Group Settings .....                              | 7-33        |
| 7.4.4.1    | Introduction to Axis Group Parameters .....            | 7-33        |
| 7.4.4.2    | Using Axis Groups in the Program.....                  | 7-35        |
| 7.4.5      | Process for Axis Group Configuration.....              | 7-36        |
| <b>7.5</b> | <b>Motion Axis Variables .....</b>                     | <b>7-41</b> |
| 7.5.1      | Variables for Single Axis .....                        | 7-41        |
| 7.5.2      | Variables for Axis Group .....                         | 7-44        |
| <b>7.6</b> | <b>Motion Control Programming.....</b>                 | <b>7-47</b> |
| 7.6.1      | Motion Control Program.....                            | 7-47        |
| 7.6.1.1    | DIADesigner-AX Programming Structure and Types .....   | 7-47        |
| 7.6.1.2    | POU in DIADesigner-AX .....                            | 7-48        |
| 7.6.1.3    | Adding POU in DIADesigner-AX.....                      | 7-49        |
| 7.6.1.4    | PDO Mapping .....                                      | 7-51        |

|            |   |             |
|------------|---|-------------|
| 7.6.2      | Axis State Transition .....                                     | 7-52        |
| 7.6.2.1    | Axis State .....  | 7-52        |
| 7.6.2.2    | Axis Group State.....   | 7-54        |
| 7.6.3      | Execution and Status of Motion Control Instructions .....       | 7-56        |
| 7.6.3.1    | Basic Rules for Instruction Execution .....                     | 7-56        |
| 7.6.3.2    | Timing Diagram for Inputs / Outputs .....                       | 7-58        |
| 7.6.3.3    | Repeated Execution of a Single Motion Control Instruction ..... | 7-59        |
| 7.6.3.4    | Multi-execution of Motion Control Instructions .....            | 7-59        |
| 7.6.3.5    | Synchronous Execution of Motion Control Instructions .....      | 7-60        |
| 7.6.4      | Position.....   | 7-65        |
| 7.6.4.1    | Types of Position.....  | 7-65        |
| 7.6.5      | Cam Tables and Framework.....                                   | 7-66        |
| 7.6.5.1    | E-CAM Framework .....   | 7-66        |
| 7.6.5.2    | E-CAM Establishment .....                                       | 7-67        |
| <b>7.7</b> | <b>Motion Control Functions.....</b>                            | <b>7-71</b> |
| 7.7.1      | System Structure.....   | 7-71        |
| 7.7.2      | Single-axis Control.....  | 7-71        |
| 7.7.2.1    | Cyclic Synchronous Position Mode .....                          | 7-71        |
| 7.7.2.2    | Profile Position Mode .....                                     | 7-72        |
| 7.7.2.3    | Positioning .....   | 7-72        |
| 7.7.2.4    | Stop Method.....  | 7-74        |
| 7.7.2.5    | MC_GearIn.....  | 7-76        |
| 7.7.2.6    | MC_GearInPos.....   | 7-78        |
| 7.7.2.7    | MC_CamIn .....  | 7-79        |
| 7.7.3      | Velocity Control .....  | 7-88        |
| 7.7.3.1    | CSP Mode .....  | 7-88        |
| 7.7.3.2    | CSV Mode .....  | 7-89        |
| 7.7.3.3    | Profile Velocity Mode .....                                     | 7-89        |
| 7.7.4      | Torque Control.....   | 7-90        |
| 7.7.5      | Common Functions for Single-axis Control.....                   | 7-91        |
| 7.7.5.1    | Position Command .....  | 7-91        |
| 7.7.5.2    | Velocity Command .....  | 7-93        |
| 7.7.5.3    | Acceleration and Deceleration Command .....                     | 7-94        |
| 7.7.5.4    | Jerk Command .....  | 7-95        |
| 7.7.5.5    | Axis Direction .....  | 7-96        |
| 7.7.6      | Axis Group Control.....   | 7-98        |
| 7.7.6.1    | Linear Interpolation.....                                       | 7-98        |

|                  |   |              |
|------------------|---|--------------|
| 7.7.6.2          | Helical Interpolation .....                             | 7-99         |
| 7.7.6.3          | Stop Command for Axis Group .....                       | 7-101        |
| 7.7.7            | High-speed I/O.....                                     | 7-102        |
| 7.7.7.1          | I/O Configuration.....                                  | 7-102        |
| 7.7.7.2          | DIO Settings .....                                      | 7-103        |
| 7.7.7.3          | SSI Encoder Settings.....                               | 7-104        |
| 7.7.7.4          | Pulse Encoder Settings .....                            | 7-105        |
| 7.7.7.5          | Capture / Compare Settings.....                         | 7-109        |
| 7.7.8            | Other Features .....                                    | 7-110        |
| 7.7.8.1          | Changing Current Position.....                          | 7-110        |
| 7.7.8.2          | Software Limit.....                                     | 7-110        |
| 7.7.8.3          | Position Lag Settings.....                              | 7-111        |
| 7.7.8.4          | Cam Switch .....  | 7-112        |
| 7.7.8.5          | Position Capture .....                                  | 7-113        |
| <b>7.8</b>       | <b>Programming Example .....</b>                        | <b>7-114</b> |
| 7.8.1            | Device Framework .....                                  | 7-114        |
| 7.8.1.1          | Utilization .....                                       | 7-114        |
| 7.8.1.2          | Configuration .....                                     | 7-114        |
| 7.8.2            | Examples.....   | 7-115        |
| 7.8.2.1          | Servo On .....  | 7-116        |
| 7.8.2.2          | Resetting and Monitoring Single-axis Errors .....       | 7-117        |
| 7.8.2.3          | Monitoring Instruction Errors.....                      | 7-121        |
| 7.8.2.4          | Quick Stop for Single Axis.....                         | 7-123        |
| 7.8.2.5          | Homing .....  | 7-126        |
| 7.8.2.6          | Absolute Positioning .....                              | 7-128        |
| 7.8.2.7          | Switching Cam Tables during Cam Operation .....         | 7-130        |
| 7.8.2.8          | Executing Master Phase Offset during Cam Operation..... | 7-138        |
| 7.8.2.9          | Changing Current Position in Movement.....              | 7-146        |
| 7.8.2.10         | Performing Superimposition during Gear Engagement ..... | 7-151        |
| <br>             |   |              |
| <b>Chapter 8</b> | <b>OPC UA Server</b>                                    |              |
| <b>8.1</b>       | <b>OPC UA Server.....</b>                               | <b>8-2</b>   |
| 8.1.1            | Creating a Project for OPC UA Access .....              | 8-2          |
| <b>8.2</b>       | <b>Connection Settings.....</b>                         | <b>8-4</b>   |
| 8.2.1            | Setting Up a Connection with UaExpert .....             | 8-4          |
| <b>8.3</b>       | <b>Setting Up an Encrypted Connection.....</b>          | <b>8-7</b>   |

|       |  |      |
|-------|--|------|
| 8.3.1 | Setting Up User Account and Password .....                         | 8-7  |
| 8.3.2 | CODESYS Security Agent .....                                       | 8-8  |
| 8.3.3 | Setting Up an Encrypted Connection with Prosys OPC UA Client ..... | 8-10 |
| 8.3.4 | Setting Up an Encrypted Connection with UaExpert .....             | 8-14 |

## **Chapter 9 Communication**

|            |  |             |
|------------|--|-------------|
| <b>9.1</b> | <b>Introduction to EtherCAT Communication .....</b>      | <b>9-3</b>  |
| 9.1.1      | Features of EtherCAT Fieldbus .....                      | 9-3         |
| 9.1.2      | Setting Up EtherCAT Master .....                         | 9-4         |
| 9.1.3      | Setting Up EtherCAT Slave .....                          | 9-6         |
| 9.1.4      | Backup Parameters for EtherCAT Slaves .....              | 9-9         |
| 9.1.4.1    | Data Backup Procedure .....                              | 9-9         |
| 9.1.4.2    | Introduction to Backup and Restore .....                 | 9-10        |
| 9.1.4.2.1  | Operation for Backup Function .....                      | 9-12        |
| 9.1.4.2.2  | Operation for Restore Function .....                     | 9-14        |
| <b>9.2</b> | <b>Introduction to Modbus Serial Communication .....</b> | <b>9-16</b> |
| 9.2.1      | Modbus Serial Port .....                                 | 9-16        |
| 9.2.1.1    | Adding Delta Modbus COM .....                            | 9-16        |
| 9.2.1.2    | Setting Up Delta Modbus COM .....                        | 9-19        |
| 9.2.2      | Modbus Serial Master .....                               | 9-21        |
| 9.2.2.1    | Adding Delta Modbus Master/Slave COM .....               | 9-21        |
| 9.2.2.2    | Setting Up Modbus Serial Master .....                    | 9-24        |
| 9.2.2.3    | Setting Up Modbus Serial Slave .....                     | 9-27        |
| 9.2.3      | Modbus Serial Slave .....                                | 9-33        |
| 9.2.3.1    | Adding a Modbus Serial Device .....                      | 9-33        |
| 9.2.3.2    | Setting Up the Modbus Serial Device .....                | 9-35        |
| <b>9.3</b> | <b>Introduction to Ethernet Communication .....</b>      | <b>9-37</b> |
| 9.3.1      | Ethernet .....   | 9-37        |
| 9.3.1.1    | Adding an Ethernet Adapter Device .....                  | 9-37        |
| 9.3.1.2    | Setting Up the Ethernet .....                            | 9-38        |
| 9.3.2      | Modbus TCP Master .....                                  | 9-41        |
| 9.3.2.1    | Adding a Modbus TCP Master / Slave .....                 | 9-42        |
| 9.3.2.2    | Setting Up the Modbus TCP Master .....                   | 9-46        |
| 9.3.2.3    | Setting Up the Modbus TCP Slave .....                    | 9-47        |
| 9.3.3      | Modbus TCP Slave .....                                   | 9-52        |
| 9.3.3.1    | Adding a Modbus TCP Slave Device .....                   | 9-53        |
| 9.3.3.2    | Setting Up the Modbus TCP Slave Device .....             | 9-55        |

|            |   |             |
|------------|---|-------------|
| <b>9.4</b> | <b>EtherNet/IP .....</b>                          | <b>9-57</b> |
| 9.4.1      | Introduction to EtherNet/IP.....                  | 9-57        |
| 9.4.1.1    | EtherNet/IP Overview.....                         | 9-57        |
| 9.4.1.2    | Definition.....                                   | 9-57        |
| 9.4.1.3    | Features of Ethernet .....                        | 9-58        |
| 9.4.1.3.1  | Delta EIP Structure.....                          | 9-58        |
| 9.4.1.3.2  | Features of EIP.....                              | 9-58        |
| 9.4.2      | EtherNet/IP Scanner Function .....                | 9-59        |
| 9.4.2.1    | Setting Up AX-8 Series PLC.....                   | 9-59        |
| 9.4.2.1.1  | Hardware Configuration.....                       | 9-59        |
| 9.4.2.1.2  | Read-Write Setting for Implicit Messages.....     | 9-60        |
| 9.4.2.1.3  | CIP Object Read-Write for Explicit Messages ..... | 9-62        |
| 9.4.3      | Adapter Function .....                            | 9-63        |
| 9.4.3.1    | Create an EDS File.....                           | 9-63        |
| 9.4.3.2    | Import an EDS File.....                           | 9-68        |
| 9.4.4      | CIP Object .....                                  | 9-71        |
| 9.4.4.1    | Object list.....                                  | 9-71        |
| 9.4.4.2    | Data Type.....                                    | 9-72        |
| 9.4.4.3    | Identity Object (Class ID: 01 Hex) .....          | 9-75        |
| 9.4.4.4    | Assembly Object (Class ID: 04 Hex).....           | 9-77        |
| 9.4.4.5    | TCP/IP Interface Object (Class ID: F5 Hex) .....  | 9-78        |
| 9.4.4.6    | Ethernet Link Object (Class ID : F6 Hex).....     | 9-81        |
| 9.4.5      | Delta EIP Product List.....                       | 9-84        |
| 9.4.5.1    | Delta EIP Product List (Adapters Supported) ..... | 9-84        |
| 9.4.5.2    | Delta EIP Product List (Scanners Supported).....  | 9-84        |
| <b>9.5</b> | <b>Network Security.....</b>                      | <b>9-85</b> |

## Appendix A Troubleshooting

|            |  |            |
|------------|--|------------|
| <b>A.1</b> | <b>Troubleshooting .....</b>                               | <b>A-2</b> |
| A.1.1      | Basic Troubleshooting Steps.....                           | A-2        |
| A.1.2      | Clear Error States .....                                   | A-2        |
| A.1.3      | Troubleshooting SOP .....                                  | A-3        |
| A.1.4      | Viewing Log .....  | A-3        |
| <b>A.2</b> | <b>Troubleshooting of CPU Modules .....</b>                | <b>A-5</b> |
| A.2.1      | ERROR LED Indicators Blinking Every 0.5 Seconds .....      | A-5        |
| A.2.2      | ERROR LED Indicators Blinking Rapidly Every 2 Seconds..... | A-6        |

|   |   |             |
|---|---|-------------|
| A.2.2   | ERROR LED Indicators Blinking Rapidly Every 1 Second .....    | A-6         |
| <b>A.3</b>  | <b>Troubleshooting of Function Blocks .....</b>               | <b>A-7</b>  |
| A.3.1   | DL_CmpAX8xxEDrv .....   | A-7         |
| A.3.2   | Motion Control Related Instructions .....                     | A-8         |
| <br>  |   |             |
| <b>Appendix B BIOS Settings</b>                           |   |             |
| <b>B.1</b>  | <b>Basic Settings and Operation of BIOS .....</b>             | <b>B-2</b>  |
| B.1.1   | Main .....  | B-3         |
| B.1.2   | Advanced .....  | B-4         |
| B.1.3   | Chipset .....   | B-5         |
| B.1.4   | Security .....  | B-8         |
| B.1.5   | Boot .....  | B-9         |
| B.1.6   | Save & Exit .....   | B-10        |
| <br>  |   |             |
| <b>Appendix C Settings and Operation of Windows/Linux</b> |   |             |
| <b>C.1</b>  | <b>Basic Settings of UWF .....</b>                            | <b>C-2</b>  |
| C.1.1   | UWF Execution via PAC_Tool .....                              | C-2         |
| C.1.2   | Read Current Status .....                                     | C-2         |
| C.1.3   | Enable UWF .....  | C-3         |
| C.1.4   | Disable UWF .....   | C-4         |
| C.1.5   | Fix UWF .....   | C-4         |
| <b>C.2</b>  | <b>Display Language Settings .....</b>                        | <b>C-5</b>  |
| <b>C.3</b>  | <b>UWF Exclusion Settings .....</b>                           | <b>C-6</b>  |
| <b>C.4</b>  | <b>Replace Original Project with USB Backup Project .....</b> | <b>C-7</b>  |
| C.4.1   | Retrieve a Project from PLC .....                             | C-7         |
| C.4.2   | Create a Project from DIADesigner-AX .....                    | C-8         |
| C.4.3   | USB Project Backup Tool .....                                 | C-8         |
| C.4.4   | Project Mode .....  | C-9         |
| C.4.5   | Clear Mode .....  | C-10        |
| C.4.6   | Extraction Password Settings .....                            | C-11        |
| C.4.7   | Project Replacement .....                                     | C-12        |
| <b>C.5</b>  | <b>IP Address Settings .....</b>                              | <b>C-13</b> |
| C.5.1   | Modify through Project Download .....                         | C-13        |
| C.5.2   | Modify through Windows Settings .....                         | C-13        |

**C.6 Reset IP Address ..... C-14**  
C.6.1 Connection Denied to PLC ..... C-14

**C.7 System Operation ..... C-16**

**Appendix D Firmware Package Updater Operation**

**D.1 Firmware Package Updater Operation .....D-2**  
D.1.1 Firmware Package Updater..... D-2  
D.1.2 Firmware Path ..... D-3  
D.1.3 Online Device ..... D-4  
D.1.4 Update ..... D-4

---

## Chapter 1 Product Introduction

### Table of Contents

|   |            |
|---|------------|
| <b>1.1 Overview .....</b>                                 | <b>1-2</b> |
| 1.1.1 Related Manuals .....                               | 1-2        |
| 1.1.2 Model Descriptions .....                            | 1-3        |
| <b>1.2 DIADesigner-AX Software Overview .....</b>         | <b>1-6</b> |
| 1.2.1 Features .....                                      | 1-6        |
| <b>1.3 Electrical Safety Precautions .....</b>            | <b>1-7</b> |
| 1.3.1 Electrical Safety Precautions (English) .....       | 1-7        |
| 1.3.2 Précautions de sécurité électrique (Français) ..... | 1-8        |

## **1.1 Overview**

This manual introduces the AX-8 Series CPU functions, devices, module tables, troubleshooting, and so forth.

### **1.1.1 Related Manuals**

The related manuals for AX-8 Series programmable logic controllers are listed below.

- **AX-8 Series Operation Manual**

This manual introduces CPU functions, devices, module tables, electrical specifications, appearances and dimension, basic concept of motion control, basic configurations, troubleshooting, and so forth.

- **DIADesigner-AX User Manual**

This manual introduces the use of the software, and programming languages, including Ladder Diagram (LD), Sequential Function Chart (SFC), Structured Text (ST), and Function Block Diagram (FBD), as well as Program Organization Unit (POU), tasks and editing techniques for motion control programs.

- **AX Series Motion Controller Manual**

This introduces single-axis and multi-axe instructions for programming the AX Series Motion Controllers.

- **AX Series Standard Instructions Manual**

This introduces standard instructions for programming the AX Series Controllers.

## 1.1.2 Model Descriptions

| Classification                      | Model Name   | Description   |
|-------------------------------------|--|---|
| AX-8 Series<br>Logic<br>Controller  | AX-800EP0PB1T<br>AX-800EP0PC1T                                   | NPN output, inbuilt with 1x Relative Encoder, 1x SSI, 8x DI (1 MHz), 8x DO (100 kHz), 2x Ethernet port, 1x EtherCAT, 1x RS-422 / 485, 4x USB, SD interface<br>Program capacity: 512 MB; data capacity: 512 MB; removable terminal blocks  |
|                                     | AX-800EP0PB1P<br>AX-800EP0PC1P                                   | PNP output, inbuilt with 1x Relative Encoder, 1x SSI, 8x DI (1 MHz), 8x DO (100 kHz), 2x Ethernet port, 1x EtherCAT, 1x RS-422 / 485, 4x USB, SD interface<br>Program capacity: 512 MB; data capacity: 512 MB; removable terminal blocks  |
| AX-8 Series<br>Motion<br>Controller | AX-816EP0CB1T<br>AX-816EP0MB1T<br>AX-816EP0CC1T<br>AX-816EP0MC1T | 16-axis motion controller CPU module, NPN output, inbuilt with 1x Relative Encoder, 1x SSI, 8x DI (1 MHz), 8x DO (100 kHz), 2x Ethernet port, 1x EtherCAT, 1x RS-422 / 485, 4x USB, SD interface.<br>Program capacity: 512 MB; data capacity: 512 MB; removable terminal blocks |
|                                     | AX-832EP0CB1T<br>AX-832EP0MB1T<br>AX-832EP0CC1T<br>AX-832EP0MC1T | 32-axis motion controller CPU module, NPN output, inbuilt with 1x Relative Encoder, 1x SSI, 8x DI (1 MHz), 8x DO (100 kHz), 2x Ethernet port, 1x EtherCAT, 1x RS-422 / 485, 4x USB, SD interface.<br>Program capacity: 512 MB; data capacity: 512 MB; removable terminal blocks |
|                                     | AX-864EP0CB1T<br>AX-864EP0MB1T<br>AX-864EP0CC1T<br>AX-864EP0MC1T | 64-axis motion controller CPU module, NPN output, inbuilt with 1x Relative Encoder, 1x SSI, 8x DI (1 MHz), 8x DO (100 kHz), 2x Ethernet port, 1x EtherCAT, 1x RS-422 / 485, 4x USB, SD interface.<br>Program capacity: 512 MB; data capacity: 512 MB; removable terminal blocks |
|                                     | AX-816EP0CB1P<br>AX-816EP0MB1P<br>AX-816EP0CC1P<br>AX-816EP0MC1P | 16-axis motion controller CPU module, PNP output, inbuilt with 1x Relative Encoder, 1x SSI, 8x DI (1 MHz), 8x DO (100 kHz), 2x Ethernet port, 1x EtherCAT, 1x RS-422 / 485, 4x USB, SD interface.<br>Program capacity: 512 MB; data capacity: 512 MB;                           |

1

| Classification | Model Name   | Description   |
|----------------|--|---|
|                |  | removable terminal blocks   |
|                | AX-832EP0CB1P<br>AX-832EP0MB1P<br>AX-832EP0CC1P<br>AX-832EP0MC1P | 32-axis motion controller CPU module, PNP output, inbuilt with 1x Relative Encoder, 1x SSI, 8x DI (1 MHz), 8x DO (100 kHz), 2x Ethernet port, 1x EtherCAT, 1x RS-422 / 485, 4x USB, SD interface.<br><br>Program capacity: 512 MB; data capacity: 512 MB; removable terminal blocks |
|                | AX-864EP0CB1P<br>AX-864EP0MB1P<br>AX-864EP0CC1P<br>AX-864EP0MC1P | 64-axis motion controller CPU module, PNP output, inbuilt with 1x Relative Encoder, 1x SSI, 8x DI (1 MHz), 8x DO (100 kHz), 2x Ethernet port, 1x EtherCAT, 1x RS-422 / 485, 4x USB, SD interface.<br><br>Program capacity: 512 MB; data capacity: 512 MB; removable terminal blocks |
|                | AX-816EP0CE1T<br>AX-816EP0ME1T                                   | 16-axis motion controller CPU module, NPN output, inbuilt with 1x Relative Encoder, 1x SSI, 8x DI (1 MHz), 8x DO (100 kHz), 2x Ethernet port, 1x EtherCAT, 1x RS-422 / 485, 4x USB, SD interface.<br><br>Program capacity: 512 MB; data capacity: 512 MB; removable terminal blocks |
|                | AX-832EP0CE1T<br>AX-832EP0ME1T                                   | 32-axis motion controller CPU module, NPN output, inbuilt with 1x Relative Encoder, 1x SSI, 8x DI (1 MHz), 8x DO (100 kHz), 2x Ethernet port, 1x EtherCAT, 1x RS-422 / 485, 4x USB, SD interface.<br><br>Program capacity: 512 MB; data capacity: 512 MB; removable terminal blocks |
|                | AX-864EP0CE1T<br>AX-864EP0ME1T                                   | 64-axis motion controller CPU module, NPN output, inbuilt with 1x Relative Encoder, 1x SSI, 8x DI (1 MHz), 8x DO (100 kHz), 2x Ethernet port, 1x EtherCAT, 1x RS-422 / 485, 4x USB, SD interface.<br><br>Program capacity: 512 MB; data capacity: 512 MB; removable terminal blocks |
|                | AX-816EP0CE1P<br>AX-816EP0ME1P                                   | 16-axis motion controller CPU module, PNP output, inbuilt with 1x Relative Encoder, 1x SSI, 8x DI (1 MHz), 8x DO (100 kHz), 2x Ethernet port, 1x EtherCAT, 1x RS-   |

| Classification | Model Name                             | Description  |
|----------------|--|--|
|                |  | <p>422 / 485, 4x USB, SD interface.</p> <p>Program capacity: 512 MB; data capacity: 512 MB; removable terminal blocks</p>  |
|                | <p>AX-832EP0CE1P<br/>AX-832EP0ME1P</p> | <p>32-axis motion controller CPU module, PNP output, inbuilt with 1x Relative Encoder, 1x SSI, 8x DI (1 MHz), 8x DO (100 kHz), 2x Ethernet port, 1x EtherCAT, 1x RS-422 / 485, 4x USB, SD interface.</p> <p>Program capacity: 512 MB; data capacity: 512 MB; removable terminal blocks</p>                             |
|                | <p>AX-864EP0CE1P<br/>AX-864EP0ME1P</p> | <p>64-axis motion controller CPU module, PNP output, inbuilt with 1x Relative Encoder, 1x SSI, 8x DI (1 MHz), 8x DO (100 kHz), 2x Ethernet port, 1x EtherCAT, 1x RS-422 / 485, 4x USB, SD interface.</p> <p>Program capacity: 512 MB; data capacity: 512 MB; removable terminal blocks</p>                             |
|                | <p>AX-8H1E30CD2T</p>                   | <p>NPN output, 8x DI (1 kHz), 4x DO (1 kHz), 2x Ethernet port, 2x EtherCAT, 1x RS-485, 4x USB, SD interface.</p> <p>Program capacity: 512 MB; data capacity: 1024 MB; removable terminal blocks</p>  |
|                | <p>AX-864EP1ME1TP</p>                  | <p>64-axis motion controller CPU module, NPN / PNP output, inbuilt with 6x DI (1 kHz), 2x DO (1 kHz), 3x Ethernet port, 1x EtherCAT, 2x RS-485, 1x USB, 1x Type-C, 1x HDMI.</p> <p>Program and data capacity: 1024 MB; removable terminal blocks</p>   |
|                | <p>AX-8DH1ECP1CE1TP</p>                | <p>128-axis motion controller CPU module · NPN / PNP output, inbuilt with 6x DI (1 MHz), 2x DO (200 kHz), 4x Ethernet port, 1x CANopen, 2x EtherCAT, 2x RS-485, 3x USB, 1x Type-C, 1x HDMI, 1x SSI, 1x Encoder, 1x LCM panel, 1x SD interface</p> <p>Program and data capacity: 1024 MB; removable terminal blocks</p> |

## 1.2 DIADesigner-AX Software Overview

Conformed to IEC 61131-3, DIADesigner-AX is a new programming tool for a new generation Delta PLC. With the abundant applied instructions and an adequate motion function library, DIADesigner-AX provides a friendly and multilingual programming interface for a more convenient and efficient development environment.

### 1.2.1 Features

DIADesigner-AX is applicable to AX series.

- Support all the programming languages that IEC 61131-3 defines, including FBD, LD, ST, and SFC, as well as POU, tasks and other programming language standard.
- Powerful and proven function library for various applications.
- Input assistance for the input and configuration.
- User-friendly programming with mouse and keyboard in IEC 61131-3 supported programming languages.
- Extensive debugging and online features for the fast optimization of the application code and to speed up testing and commissioning.
- Numerous security features for the protection of the source code and for safeguarding the operation of the controller.
- Programmable devices from different manufacturers.
- The user interface is extendible and adaptable without leaving the framework.
- Transparent internal structures of the development tool and the available components.
- Many seamlessly integrated tools for different kinds of automation tasks.

Two built-in configuration tools:

- HWCONFIG: the hardware configurations and parameter managements for the system.
- NWCONFIG: the network configurations and data exchange management for the system.

Providing various solutions for motion control including PLCopen, MC function block, G-code editor, E-CAM editor, positioning planning chart tool and many more.

- Support PLCopen POUs for single and multi-axis motions
- Support PLCopen POUs for add-on functions, including diagnostics, stop, and CAM controller
- Additional POUs for different tasks including monitoring dynamic data, following error, operating CAMs and CAM controllers
- Integrated graphical CAM editor with loads of configuration options
- Virtual and logical axes are supported.
- Integrated drivers for numerous Modbus and EtherCAT protocols
- Configuration of the drives as standard field devices.

## 1.3 Electrical Safety Precautions

### 1.3.1 Electrical Safety Precautions (English)

- In order to prevent possible severe damage caused by electric shocks, please first unplug the host power cable from the power outlet before moving the host.
- Confirm that all power cables have been unplugged before connecting or disconnecting any signal cables from the host.
- Confirm that the voltage setting of the power supply is adjusted to the standard voltage value used in this country/region. If you are unsure of the supplied voltage value of your region, please consult your local power company staff.
- If the power supply is damaged, do not attempt to fix it by yourself. Please contact Delta's professional technical service staff or the dealer.
- Restart Instructions: Pressing and holding down the reset button for 2 seconds will force restart.
- It is recommended to install this product inside a cabinet or inside an external case in order to block external collisions.
- This product is applicable to industrial automation equipment and applications. Please read this Operational Manual carefully and perform installation according to the instructions in order to prevent danger from occurring.
- If this product is not operated in accordance with the instructions described in the Manual, it will cause damage to the equipment or abnormal functions.
- The installation that the safety of any system incorporating the equipment is the responsibility of the assembler of the system.
- If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.
- Wipe clean with dry cloth to keep the product from humidity.
- Terminal block is mating with Plug and suitable for 16 AWG to 22 AWG. Torque value 0.5N·m Use Copper Conductors Only. The temperature rating of the input connection cable should higher than 105°C.
- To prevent electric shock, make sure to cut off the power to the module and the common input / output points before removing the module or the connected wires.
- This product uses DC power only. Do not use AC power for the product.
- Use the power adapters that comply with the power supply requirements of UL 61010-1, UL 61010-2-201, UL 62368-1, Class 2, SELV, LE, or LPS for this product.
- The power for the PLC and the common input / output points should be two independent power supplies and within the rated voltage. If you are uncertain of the voltage in your area, contact local electrical technicians

### 1.3.2 Précautions de sécurité électrique (Français)

- Afin d'éviter d'éventuels dommages graves causés par des chocs électriques, veuillez d'abord débrancher le câble d'alimentation de l'hôte de la prise de courant avant de déplacer l'hôte.
- Vérifiez que tous les câbles d'alimentation ont été débranchés avant de connecter ou de déconnecter tout câble de signal de l'hôte.
- Vérifiez que le réglage de la tension de l'alimentation est ajusté à la valeur de tension standard utilisée dans ce pays / cette région. Si vous n'êtes pas sûr de la valeur de tension fournie dans votre région, veuillez consulter le personnel de votre compagnie d'électricité locale.
- Si le bloc d'alimentation est endommagé, n'essayez pas de le réparer vous-même. Veuillez contacter le service technique professionnel de Delta ou le revendeur.
- Instructions de redémarrage: Appuyez et maintenez enfoncé le bouton de réinitialisation pendant 2 secondes pour forcer le redémarrage.
- Il est recommandé d'installer ce produit à l'intérieur d'une armoire ou à l'intérieur d'un boîtier externe afin de bloquer les collisions externes.
- Ce produit est applicable aux équipements et applications d'automatisation industrielle. Veuillez lire attentivement ce manuel d'utilisation et effectuer l'installation conformément aux instructions afin d'éviter tout danger.
- Si ce produit n'est pas utilisé conformément aux instructions décrites dans le manuel, il endommagera l'équipement ou des fonctions anormales.
- L'installation selon laquelle la sécurité de tout système intégrant l'équipement est à la charge de l'assembleur du système.
- Si l'équipement est utilisé d'une manière non spécifiée par le fabricant, la protection fournie par l'équipement peut être altérée.
- Essuyez avec un chiffon sec pour protéger le produit de l'humidité.
- Le bornier se couple avec la fiche et convient pour les fils de calibre 16 à 22 AWG. La valeur de couple est de 0.5 N·m. Utilisez uniquement des conducteurs en cuivre. La température nominale du câble de connexion d'entrée doit être supérieure à 105°C.
- Pour éviter les chocs électriques, assurez-vous de couper l'alimentation du module et des points d'entrée/sortie communs avant de retirer le module ou les fils connectés.
- Ce produit utilise uniquement une alimentation en courant continu. Ne pas utiliser une alimentation en courant alternatif pour ce produit.
- Utilisez les adaptateurs d'alimentation conformes aux exigences d'alimentation électrique de UL 61010-1, UL 61010-2-201, UL 62368-1, Class 2, SELV, LE, ou LPS pour ce produit.
- L'alimentation du PLC et des points d'entrée/sortie communs doit être assurée par deux sources d'alimentation indépendantes et dans la plage de tension nominale. Si vous n'êtes pas certain de la tension dans votre région, contactez les techniciens en électricité locaux.

---

# Chapter 2 Specifications and System Configurations

## Table of Contents

|            |   |            |
|------------|---|------------|
| <b>2.1</b> | <b>General Specifications .....</b>       | <b>2-2</b> |
| <b>2.2</b> | <b>CPU Module Specifications.....</b>     | <b>2-4</b> |
| 2.2.1      | Functional Specifications.....            | 2-4        |
| 2.2.2      | Electrical Specifications.....            | 2-10       |
| 2.2.3      | CPU Module Profiles .....                 | 2-13       |
| 2.2.4      | CPU Module Input / Output Terminals.....  | 2-19       |
| 2.2.5      | Wiring Configuration .....                | 2-21       |
| 2.2.5.1    | AX-8□□EP0□□□T Wiring .....                | 2-21       |
| 2.2.5.2    | AX-8□□EP0□□□P Wiring .....                | 2-22       |
| 2.2.5.3    | AX-8□□EP0□□□T, AX-8□□EP0□□□P Wiring ..... | 2-23       |
| 2.2.5.4    | AX-8H1E30CD2T Wiring.....                 | 2-25       |
| 2.2.5.5    | AX-864EP1ME1TP Wiring.....                | 2-26       |
| 2.2.5.6    | AX-8DH1ECP1CE1TP Wiring.....              | 2-28       |

## 2.1 General Specifications

| Item   | Specifications   |
|--|--|
| Operating temperature                                | 0 ~ 50°C*1   |
| Storage temperature                                  | -20 ~ 70°C (AX-8□□EP0, AX-8H1E30CD2T)<br>-40 ~ 70°C (AX-864EP1ME1TP, AX-8DH1ECP1CE1TP)   |
| Operating humidity                                   | 5 ~ 95%<br>No condensation   |
| Storage humidity                                     | 5 ~ 95%<br>No condensation   |
| Work environment                                     | No corrosive gas exists.   |
| Installation location                                | In a control cabinet   |
| Pollution degree                                     | 2  |
| Ingress protection (IP ratings)                      | IP20   |
| EMC Standard (electromagnetic compatibility)         | Refer to the tables of EMI, EMS, and conducted immunity test below.  |
| Vibration resistance                                 | Tested with:<br>5Hz ≤ f ≤ 8.4Hz, constant amplitude 3.5mm;<br>8.4Hz ≤ f ≤ 150Hz, constant acceleration 1g<br>Duration of oscillation: 10 sweep cycles<br>per axis in each direction of the 3 mutually perpendicular axes<br>International Standard IEC 61131-2 & IEC 60068-2-6 (TEST Fc) |
| Shock resistance                                     | Tested with:<br>Half-sine wave:<br>Strength of shock 15g peak value, 11ms duration;<br>Shock direction: The shocks in each direction per axis, on 3 mutually perpendicular axes (total of 18 shocks)<br>International Standard IEC 61131-2 & IEC 60068-2-27 (TEST Ea)                    |
| Safety   | Conforms to IEC 61131-2, UL 61010-1  |
| Ambient air temperature-barometric pressure-altitude | Operation: 1,080 ~ 795hPa (-1,000 ~ 2,000m)<br>Storage: 1,080 ~ 660hPa (-1,000 ~ 3,500m)   |
| Silicone flammability rating                         | UL94V-2  |

\*1: Leave the AX-8 Series PLC in an environment within the operating temperature for at least one hour before use to ensure the AX-8 Series PLC temperature is within the operating temperature.

- EMI

| Port  | Frequency range | Level (normative)      | Reference standard |
|---|-----------------|------------------------|--------------------|
| Enclosure port<br>(radiated; measured at a distance of 10 meters) | 30 ~ 230 MHz    | 40dB (μV/m) quasi-peak | IEC 61000-6-4      |
|   | 230 ~ 1,000 MHz | 47dB (μV/m) quasi-peak |                    |
| AC power port<br>(conducted)                                      | 0.15 ~ 0.5 MHz  | 79dB (μV) quasi-peak   | IEC 61000-6-4      |
|   |                 | 66dB (μV) average      |                    |
|   | 0.5 ~ 30 MHz    | 73dB (μV) quasi-peak   |                    |
|   |                 | 60dB (μV) average      |                    |

- EMS

| Environmental phenomenon                                       | Reference standard | Test                           |                | Test level |
|--|--------------------|--------------------------------|----------------|------------|
| Electrostatic discharge  | IEC 61000-4-2      | Contact                        |                | ±4kV       |
|  |                    | Air                            |                | ±8kV       |
| Radiofrequency electromagnetic field -<br>Amplitude modulation | IEC 61000-4-3      | 80% AM,<br>1 kHz<br>sinusoidal | 2.0 ~ 2.7 GHz  | 1V/m       |
|  |                    |                                | 1.4 ~ 2.0 GHz  | 3V/m       |
|  |                    |                                | 80 ~ 1,000 MHz | 10V/m      |
| Power frequency magnetic field                                 | IEC 61000-4-8      | 60 Hz                          |                | 30A/m      |
|  |                    | 50 Hz                          |                | 30A/m      |

- Conducted immunity test

| Environmental phenomenon             |                                      | Fast transient burst | High energy surge    | Radio frequency interference |
|--------------------------------------|--------------------------------------|----------------------|----------------------|------------------------------|
| Reference standard                   |                                      | IEC 61000-4-4        | IEC 61000-4-5        | IEC 61000-4-6                |
| Interface / Port                     | Specific interface / Port            | Test level           | Test level           | Test level                   |
| Data communication                   | Shielded cable                       | 1kV                  | 1kV CM               | 10V                          |
| Digital and analog I/O               | All shielded lines<br>(to the earth) | 1kV                  | 1kV CM               | 10V                          |
| Equipment power                      | DC power                             | 2kV                  | 0.5kV CM<br>0.5kV DM | 10V                          |
| I/O power and auxiliary power output | DC I/O and DC auxiliary power        | 2kV                  | 0.5kV CM<br>0.5kV DM | 10V                          |

## 2.2 CPU Module Specifications

### 2.2.1 Functional Specifications

- Motion Controller CPU Module

| Type               |                               |  | AX-8mnEP0MB1y*1<br>AX-8mnEP0CE1y*1<br>AX-8mnEP0ME1y*1  | AX-8H1E30<br>CD2T        | AX-864EP1<br>ME1TP               | AX-8DH1ECP<br>1CE1TP |  |
|--------------------|-------------------------------|--|--|--------------------------|----------------------------------|----------------------|--|
| Process time       | Execution time                | LD instruction   | 0.4ns  | 0.2ns                    | 0.4ns                            |                      |  |
|                    |                               | Arithmetic instructions (LREAL data type)                    | 1.2ns  | 0.4ns                    | 0.6ns                            |                      |  |
| Program            | Program capacity              |  | 1 GB (variable memory included)  | 512 MB                   | 1 GB (variable memory included)  |                      |  |
|                    | Variable memory               | Retentive  | Retain   | 96 KB (Retain + Persist) | 1.5 MB                           | 2.0 MB               |  |
|                    |                               |  | Persist  | 96 KB (Retain + Persist) | 2.0 MB                           | 8.0 MB               |  |
|                    | Non-retentive                 |  | 1 GB (program capacity included)   | 1024 MB                  | 1 GB (program capacity included) |                      |  |
| Device memory (%M) | Size                          | 5 MB   | 0.5 MB (retentive)   | 5 MB (retentive)         |                                  |                      |  |
| Motion Control     | Number of controlled axes     | Maximum number of controlled axes                            | mn=16: 16 axes<br>mn=32: 32 axes<br>mn=64: 64 axes   | 128 axes                 | 128 axes                         | 256 axes             |  |
|                    |                               | EtherCAT axes*2  | mn=16: 16 axes<br>mn=32: 32 axes<br>mn=64: 64 axes   | 128 axes                 | 64 axes                          | 128 axes             |  |
|                    |                               | Pulse Out axes   | 0  |                          |                                  | 1                    |  |
|                    |                               | Maximum number of axes for linear interpolation axis control | 6 axes   |                          |                                  |                      |  |
|                    |                               | Maximum number of axes for circular interpolation control    | 6 axes (3 slave axes)  |                          |                                  |                      |  |
|                    | Maximum number of axis groups |  | 8 groups   |                          |                                  |                      |  |
|                    | Motion control period         |  | The same control period as that is used for the communication cycle of data processing for EtherCAT. |                          |                                  |                      |  |
| CAM                | Number of CAM                 | Maximum  | 32,767 points  |                          |                                  |                      |  |

| Type                 |                             |                      |                                   | AX-8mnEP0MB1y*1<br>AX-8mnEP0CE1y*1<br>AX-8mnEP0ME1y*1   | AX-8H1E30<br>CD2T               | AX-864EP1<br>ME1TP           | AX-8DH1ECP<br>1CE1TP  |
|----------------------|-----------------------------|----------------------|-----------------------------------|---|---------------------------------|------------------------------|---|
|                      | data points                 | points per CAM table | Maximum points for all CAM tables | 655,340 points  |                                 |                              |   |
|                      |                             |                      | Maximum number of CAM tables      | 160   |                                 |                              |   |
|                      | Number of ports             |                      |                                   | 2   | 3                               | 4                            |   |
| Ethernet port        | Physical media types        |                      |                                   | IEEE 802.3 / 802.3u / 802.3ab 1 Gbps  |                                 |                              |   |
|                      | Topology                    |                      |                                   | Star and line   |                                 |                              |   |
|                      | Transmission speed          |                      |                                   | 10 / 100 / 1,000 Mbps   |                                 |                              |   |
|                      | Cable                       |                      |                                   | Category 5e or later, 100 meters (max.)   |                                 |                              |   |
|                      | Communication protocols     |                      |                                   | ARP, IP, TCP, UDP, Modbus TCP, EtherNet/IP, OPC UA  |                                 |                              |   |
|                      | Number of ports             |                      |                                   | 4   | 2                               | 4                            |   |
| USB port             | Type                        |                      |                                   | USB 2.0 (0.5A)  | USB 3.0 (1.0A / 2 ports shared) | USB 3.0 (0.9A) Type-C (0.9A) | 1x USB 3.0 (0.9A)<br>1x Type-C (0.9A)<br>2x USB 2.0 (1A shared)   |
|                      |                             |                      |                                   |   |                                 |                              | Note: Using USB 3.0 with equipment that includes 2.4G wireless communication may cause frequency interference issues. |
| Isolated RS-485 port | Number of ports             |                      |                                   | 1   | 2                               |                              |   |
|                      | Baud rate                   |                      |                                   | 9,600 / 19,200 / 38,400 / 57,600 / 115,200 bps  |                                 |                              |   |
|                      | Serial communication format |                      |                                   | <ul style="list-style-type: none"> <li>■ Stop bit: 1, 2;</li> <li>■ Parity bit: None, Odd, Even;</li> <li>■ Data bit: 7, 8</li> </ul> |                                 |                              |   |
|                      | Communication protocols     |                      |                                   | <ul style="list-style-type: none"> <li>■ Master (Modbus ASCII/RTU)</li> <li>■ Slave (Modbus RTU)</li> </ul>                           | Modbus ASCII/RTU                |                              |   |
| Isolated             | Number of ports             |                      |                                   | 1   | N/A                             |                              |   |

| Type             |                                 | AX-8mnEP0MB1y*1<br>AX-8mnEP0CE1y*1<br>AX-8mnEP0ME1y*1   | AX-8H1E30<br>CD2T    | AX-864EP1<br>ME1TP | AX-8DH1ECP<br>1CE1TP |
|------------------|---------------------------------|---|----------------------|--------------------|----------------------|
| RS-422<br>port   | Baud rate                       | 9,600 / 19,200 /<br>38,400 / 57,600 /<br>76,800 / 115,200 bps   | N/A                  |                    |                      |
|                  | Serial communication format     | <ul style="list-style-type: none"> <li>■ Stop bit: 1, 2;</li> <li>■ Parity bit: None, Odd, Even;</li> <li>■ Data bit: 7, 8</li> </ul> | N/A                  |                    |                      |
|                  | Communication protocols         | <ul style="list-style-type: none"> <li>■ Master (Modbus ASCII/RTU)</li> <li>■ Slave (Modbus RTU)</li> </ul>                           | N/A                  |                    |                      |
| EtherCAT<br>port | Number of ports                 | 1   | 2                    | 1                  | 2                    |
|                  | EtherCAT Master                 | Class B   |                      |                    |                      |
|                  | Physical media types            | IEEE 802.3 / 802.3u / 802.3ab 1 Gbps  |                      |                    |                      |
|                  | Transmission speed              | 100 Mbps  |                      |                    |                      |
|                  | Topology                        | Line, daisy chain, and branching  |                      |                    |                      |
|                  | Cable                           | Category 5e or later, 100 meters (max.)   |                      |                    |                      |
|                  | Maximum number of Slaves        | 256   | 512                  |                    |                      |
|                  | Communication cycle             | 250μs ~ (unit can be set to 250μs)  |                      |                    |                      |
| TCP              | Modbus TCP                      | Maximum number of connections   | 32 (Server + Client) |                    |                      |
|                  | Socket                          | Maximum number of TCP connections   |                      |                    |                      |
|                  | Modbus TCP                      | Maximum data length per connection  | 100 words            |                    |                      |
|                  | Socket                          | Maximum data length per instruction   | 8 KB                 | 1.5 KB             |                      |
| EtherNet/IP      | CIP I/O<br>Connection           | Maximum number of connections (Scanner)   | 32+32                | 32+32+32           | 32+32+32+32          |
|                  |                                 | Maximum number of connections (Adapter)   | 32+32                | 32+32+32           | 32+32+32+32          |
|                  | Requested Packet Interval (RPI) | <ul style="list-style-type: none"> <li>■ AX-8mnEP0MB1y: 10ms ~ 100ms</li> <li>■ AX-8mnEP0CE1y, AX-8mnEP0ME1y: 1ms ~ 100ms</li> </ul>  | 1ms ~ 100ms          |                    |                      |

| Type          |   | AX-8mnEP0MB1y*1<br>AX-8mnEP0CE1y*1<br>AX-8mnEP0ME1y*1   | AX-8H1E30<br>CD2T  | AX-864EP1<br>ME1TP | AX-8DH1ECP<br>1CE1TP |  |
|---------------|---|---|--|--------------------|----------------------|--|
|               | Maximum Transmission Speed                                    | <ul style="list-style-type: none"> <li>■ AX-8mnEP0MB1y: 12,800pps</li> <li>■ AX-8mnEP0CE1y, AX-8mnEP0ME1y: 32,000pps</li> </ul> | 64,000 pps   | 48,000pps          |                      |  |
|               |   | Maximum data length per connection  | Default: 100 bytes<br>Input: 509 bytes (T→O)<br>Output: 505 bytes (O→T)<br>(O: Originator; T: Target)  |                    |                      |  |
|               | CIP Explicit Message  | Class 3 / UCMM  | <ul style="list-style-type: none"> <li>■ Get_Attribute_Single (FB)</li> <li>■ Get_Attributes_All (FB)</li> <li>■ Set_Attribute_Single (FB)</li> <li>■ Set_Attributes_All (FB)</li> </ul>   |                    |                      |  |
|               |   | CIP objects supported   | Identity, Message Router, Assembly, Connection Manager, Port, TCP/IP Interface, Ethernet Link, Vendor Specific   |                    |                      |  |
| OPC UA server | Supported profiles and models                                 |   | PLCopen and OPC Foundation:<br>OPC UA Information Model for IEC 61131-3  |                    |                      |  |
|               | Endpoints and connecting ports                                |   | TCP: 4840 (Reconfigurable via configuration file)  |                    |                      |  |
|               | Maximum number of sessions (Client)                           |   | 5  |                    |                      |  |
|               | Maximum number of monitored items                             |   | 1,000  |                    |                      |  |
|               | Sampling rate of the monitored items (ms)                     |   | 100 / 300 / 500 / 1,000 / 2,500 / 5,000  |                    |                      |  |
|               | Maximum number of subscriptions                               |   | 100  |                    |                      |  |
|               | Maximum number of variables that can be published             |   | 10,000   |                    |                      |  |
|               | Maximum number of value attributes that can be published      |   | 10,000   |                    |                      |  |
|               | Maximum number of structure definitions that can be published |   | 100  |                    |                      |  |
|               | Maximum number of nodes for read and write*6                  |   | 1,000  |                    |                      |  |
|               | Conditions that variable cannot be published                  |   | <ul style="list-style-type: none"> <li>■ More than three-dimensional arrays</li> <li>■ Array of Array</li> <li>■ The OPC UA Stack will limit messages to about 300 KB. This is the maximum for values, too.</li> <li>■ Pointer variables, Interface variables</li> </ul> |                    |                      |  |

| Type              |   | AX-8mnEP0MB1y*1<br>AX-8mnEP0CE1y*1<br>AX-8mnEP0ME1y*1 | AX-8H1E30<br>CD2T  | AX-864EP1<br>ME1TP                            | AX-8DH1ECP<br>1CE1TP       |
|-------------------|---|---|--|---|----------------------------|
|                   |   |   | ■ Structures containing pointers and interfaces  |   |                            |
|                   | Security policy mode                          |   | None<br>Sign - Basic256Sha256<br>SignAndEncrypt - Basic256Sha2566  |   |                            |
|                   | Application authentication                    | Authentication  | X.509  |   |                            |
|                   |   | Number of storable certificates                       | <ul style="list-style-type: none"> <li>■ Trusted certificates: 32</li> <li>■ Issuer certificates: 32</li> <li>■ Rejected certificates: 32</li> </ul> |   |                            |
|                   | User authentication                           | Authentication  | "Anonymous" or with user name and password   |   |                            |
| I/O configuration | Number of I/O extension modules supported     |   | N/A  |   |                            |
|                   | I/O data capacity                             |   | IN: 131,072 bytes<br>OUT: 131,072 bytes  |   |                            |
|                   | Inbuilt I/O                                   | Encoder   | 1-CH EA± / EB± / EZ± 1 MHz   | N/A   | 1-CH EA± / EB± / EZ± 1 MHz |
|                   |   | SSI   | 1 set (shared with RS-422)   |   | 1 set (shared with RS-485) |
|                   |   | High-speed counter                                    | 1  |   | 1                          |
|                   |   | Pulse out   | 0  |   | 0                          |
| Memory card       | SD card type                                  | 1x SD card slot (SD card 3.0 interface)               | N/A  | 1x Micro SD card slot (SD card 3.0 interface) |                            |
| Real-time clock   | Year, Month, Date, Hour, Minute, Second, Week | Inbuilt RTC   |  |   |                            |

\*1: mn can be 16, 32, or 64, representing the number of axes for the controller.

\*2: EtherCAT axes include positioning and synchronous axes. The maximum number of axes is listed below.

| Model \ Item            | Maximum number of positioning axes | Maximum number of synchronous axes | Maximum number of positioning and synchronous axes |
|-------------------------|------------------------------------|------------------------------------|--|
| AX-816EP0 <sup>*3</sup> | 16                                 | 16                                 | 16   |
| AX-832EP0 <sup>*4</sup> | 32                                 | 32                                 | 32   |
| AX-864EP0 <sup>*5</sup> | 64                                 | 64                                 | 64   |
| AX-8H1E30CD2T           | 128                                | 128                                | 128  |
| AX-864EP1ME1TP          | 64                                 | 64                                 | 64   |
| AX-8DH1ECP1CE1TP        | 128                                | 128                                | 128  |

\*3: AX-816EP0 includes AX-816EP0□□□□ series PLC.

\*4: AX-832EP0 includes AX-832EP0□□□□ series PLC.

\*5: AX-864EP0 includes AX-864EP0□□□□ series PLC.

\*6: If the number of read or write operations exceeds the limit, the OPC UA server will return a service fault 0x80100000 BadTooManyOperations. The limit varies based on the model and firmware version. Please refer to the table below for details.

| Model \ Item               | Firmware version                     | Maximum number of nodes for read and write |
|----------------------------|--------------------------------------|--|
| AX-8xxEP0MB<br>AX-8xxEP0CB | N/A                                  | 100  |
| AX-8xxEP0CE<br>AX-8xxEP0ME | Prior to version 1.0.7.2 (exclusive) | 100  |
|                            | Version 1.0.7.2 or later             | 1000                                       |
| AX-8H1E30CD2T              | Prior to version 1.0.7.2 (exclusive) | 100  |
|                            | Version 1.0.3.2 or later             | 1000                                       |

## 2.2.2 Electrical Specifications

| Model                 |                | AX-8□□<br>EP0□□□<br>T | AX-8□□<br>EP0□□□<br>P | AX-8H1E30CD2T   | AX-<br>864EP1ME1TP | AX-<br>8DH1ECP1CE1TP |
|-----------------------|----------------|-----------------------|-----------------------|-----------------|--------------------|----------------------|
| Supply voltage        |                | 24VDC (-15% ~ +20%)   |                       |                 |                    |                      |
| Power consumption (W) |                | 28.8W (24V/1.2A)      | 72W (24V/3A)          | 90W (24V/3.75A) |                    |                      |
| Weight (g)            | Net weight*1   | 750g                  | 1000g                 | 1310            | 2130               |                      |
|                       | Gross weight*2 | 1100g                 | 1400g                 | 1800            | 2800               |                      |

\*1: Including terminal blocks.

\*2: Including terminal blocks and all packaging.

### ● Electrical specifications for the inputs on the digital input / output module

| Model                   |        | AX-8□□<br>EP0□□□<br>T       | AX-8□□<br>EP0□□□<br>P | AX-8H1E30CD2T | AX-<br>864EP1ME1TP                        | AX-<br>8DH1ECP1CE1TP                     |
|-------------------------|--------|-----------------------------|-----------------------|---------------|---|--|
| Number of inputs        |        | 8                           |                       |               | 6   |  |
| Connector type          |        | Removable terminal blocks   |                       |               |   |  |
| Input type              |        | Digital input               |                       |               |   |  |
| Input form              |        | NPN (Sink)                  | PNP (Source)          | NPN (Sink)    | NPN (Sink)<br>PNP (Source)                |  |
| Input voltage / current |        | 24VDC, 5mA/CH (-15% ~ +20%) |                       |               | 1 kHz<br>@24VDC/5mA,<br>IEC61131-2, type1 | 1 MHz @24VDC,<br>8mA/CH<br>(-15% ~ +20%) |
| Action level            | OFF→ON | > 15VDC                     |                       |               |   |  |
|                         | ON→OFF | < 5VDC                      |                       |               |   |  |
| Response time           | OFF→ON | 200ns                       | 450μs                 | 12.01μs       | 128.5ns                                   |  |
|                         | ON→OFF | 150ns                       | 350μs                 | 12.01μs       | 128.5ns                                   |  |
| Maximum input frequency |        | 200 kHz                     | 1 kHz                 | 200 kHz       | 1 MHz                                     |  |
| Isolation method        |        | Optocoupler isolation       |                       |               |   |  |

- Electrical specifications for the outputs on the digital input / output module

| Model                  |        | AX-8□□EP0□<br>□□T         | AX-8□□EP0□<br>□□P          | AX-8H1E30CD<br>2T           | AX-<br>864EP1ME1TP          | AX-<br>8DH1ECP1CE1TP  |
|------------------------|--------|---------------------------|----------------------------|-----------------------------|-----------------------------|---|
| Item                   |        |                           |                            |                             |                             |   |
| Number of outputs      |        | 8                         |                            | 4                           | 2                           |   |
| Connector type         |        | Removable terminal blocks |                            |                             |                             |   |
| Output type            |        | Digital output            |                            |                             |                             |   |
| Output form            |        | NPN ( Sink )              | PNP( Source )              | NPN ( Sink )                | NPN(Sink), PNP(Source)      |   |
| Voltage                |        | 24VDC                     |                            |                             |                             |   |
| Maximum output current |        | 100mA/CH                  | 50mA/CH                    | 100mA/CH                    | 250mA/CH                    | 200mA/CH  |
| Response time          | OFF→ON | Ton ≤ 1μs @<br>24V/100mA  | Ton ≤ 1.3μs @<br>24V/50mA  | Ton ≤ 60μs<br>@ 24V/100mA   | Ton ≤ 65μs<br>@ 24V/250mA   | Ton ≤ 2.05μs<br>@ 24V/10mA<br>Ton ≤ 2.34μs<br>@ 24V/200mA   |
|                        | ON→OFF | Toff ≤ 1μs @<br>24V/100mA | Toff ≤ 2.6μs<br>@ 24V/50mA | Toff ≤ 130μs<br>@ 24V/100mA | Toff ≤ 156μs<br>@ 24V/250mA | Toff ≤ 6.76μs<br>@ 24V/10mA<br>Toff ≤ 1.46μs<br>@ 24V/200mA |
| Isolation method       |        | Optocoupler isolation     |                            |                             |                             |   |

- Electrical specifications for the inputs of the encoder

| Model            |        | AX-8□□EP0□□□T         | AX-8□□EP0□□□P | AX-8DH1ECP1CE1TP |
|------------------|--------|-----------------------|---------------|------------------|
| Item             |        |                       |               |                  |
| Input signal     |        | Differential          |               |                  |
| Endpoints        |        | 1-CH EA± / EB± / EZ±  |               |                  |
| Response time    | OFF→ON | 150ns                 |               | 11.01μs          |
|                  | ON→OFF | 150ns                 |               | 2.01μs           |
| Isolation method |        | Optocoupler isolation |               |                  |


● Electrical specifications for other parts

| Item                         |                    | Model  | AX-8□□<br>EP0□□□T | AX-8□□<br>EP0□□□P                          | AX-8H1E30CD<br>2T | AX-<br>864EP1ME1TP                      | AX-<br>8DH1ECP1CE1TP |   |
|------------------------------|--------------------|--|-------------------|--|-------------------|---|----------------------|---|
| Main system                  | CPU                | Intel Celeron J1900 Quad Core 2.00 GHz                 |                   | Intel I3 TigerLaker UP3 Dual Core 3.00 GHz |                   | Intel Celeron J6412 2.6 GHz             |                      |   |
|                              | BIOS               | AMI BIOS   |                   |  |                   |   |                      |   |
|                              | Memory             | DDR3L<br>4 GB  | DDR3L<br>2 GB     | LPDDR4X 4<br>GB                            | DDR4 4 GB         |   |                      |   |
|                              | Retentive memory   | 96 KB MRAM   |                   | 4 MB                                       |                   | 15 MB                                   |                      |   |
| Communication interface      | Network interface  | 2x IEEE 802.3 / 802.3u / 802.3ab 1 Gbps                |                   | 2x IEEE 802.3 / 802.3u / 802.3ab 1 Gbps    |                   | 3x IEEE 802.3 / 802.3u / 802.3ab 1 Gbps |                      |   |
|                              | Fieldbus interface | EtherCAT   |                   | 2x EtherCAT                                |                   | 1x EtherCAT                             |                      |   |
|                              | USB                | 4x USB 2.0   |                   | 4x USB 3.0                                 |                   | 1x USB 3.0<br>1x USB TYPE-C 3.0         |                      |   |
|                              | Serial port        | 1x Isolated RS-485 / 422                               |                   | 1x Isolated RS-485                         |                   | 2x Isolated RS-485                      |                      |   |
| Display interface            |                    | 1x HDMI 1.4a   |                   | 1x HDMI 2.0                                |                   | 1x HDMI 1.4                             |                      |   |
| Extension interface          |                    | 1x SD Card Slot (SD Card 3.0 Interface)                |                   |  |                   | N/A                                     |                      | 1x Micro SD Card Slot (SD Card 3.0 Interface) |
| Storage device <sup>*1</sup> | SSD                | 1x M.2 2242 type B&M-key SATA SSD (SATA 2.0 Interface) | N/A               |  | 1x M.2 SATA 32 GB |   |                      |   |
|                              | eMMC               | N/A  |                   | 1x eMMC 8 GB                               |                   | N/A                                     |                      |   |

\*1: Write file to an SD card or USB rather than to SSD or eMMC when necessary.


### 2.2.3 CPU Module Profiles

- AX-8□□EP0




● AX-8H1E30CD2T

2





● AX-864EP1ME1TP



Unit: mm

● AX-8DH1ECP1CE1TP



Unit: mm

| Number | Name                                   | Description   |   |                |   |
|--------|--|---|---|----------------|---|
|        |  | AX-8□□EP0   | AX-8H1E30CD2T   | AX-864EP1ME1TP | AX-8DH1ECP1CE1TP                          |
| 1      | POWER LED                              | Indicates the power status of the CPU module (orange)<br><ul style="list-style-type: none"> <li>■ ON: power on</li> <li>■ OFF: power off</li> </ul>   |   |                |   |
|        | RUN LED                                | Indicates the operation status of the CPU module (green)<br><ul style="list-style-type: none"> <li>■ ON: the module is running</li> <li>■ OFF: the module is stopped</li> </ul>   |   |                |   |
|        | ERROR LED                              | Indicates the error status of the CPU module (red)<br><ul style="list-style-type: none"> <li>■ ON: a serious error occurs in the module</li> <li>■ OFF: the module is normal</li> <li>■ Blinking: a minor error occurs in the module</li> </ul>   |   |                |   |
|        | FB LED                                 | Indicates FB communication status   |   |                |   |
|        |  | <ul style="list-style-type: none"> <li>■ FB1 OFF: NO communication over EtherCAT</li> <li>■ FB1 ON: normal communication over EtherCAT</li> <li>■ FB1 Blinking: abnormal communication over EtherCAT</li> <li>■ FB2 OFF: NO communication over Modbus</li> <li>■ FB2 ON: communication over Modbus</li> </ul> | <ul style="list-style-type: none"> <li>■ FB1 OFF: NO communication over EtherCAT</li> <li>■ FB1 ON: normal communication over EtherCAT</li> <li>■ FB1 Blinking: abnormal communication over EtherCAT</li> </ul> |                |   |
| SD LED | Indicates SD card communication status |   |   |                |   |
|        | N/A                                    | <ul style="list-style-type: none"> <li>■ SD LED OFF: SD card detached</li> <li>■ SD LED ON: SD card attached</li> </ul>   | N/A   |                |   |
| 2      | SD Card Slot                           | Provides an interface for an SD card  |   | N/A            | Provides an interface for a Micro SD card |
| 3      | Reset                                  | Reset button  | N/A   |                |   |
| 4      | HDMI                                   | For display output  |   |                |   |


| Number | Name             | Description   |  |                               |   |
|--------|------------------|---|--|-------------------------------|---|
|        |                  | AX-8□□EP0   | AX-8H1E30CD2T                                  | AX-864EP1ME1TP                | AX-8DH1ECP1CE1TP                                |
| 5      | Ethernet Port    | Ethernet Switch communication port<br>LINK indicator:<br>■ ON: the network connection is established<br>(orange: 1000 Mbps; green: 100 Mbps)<br>■ OFF: the network connection is NOT established<br>ACT indicator (orange):<br>■ Blinking: data transmission (sending / receiving)<br>■ OFF: NO data transmission |  |                               |   |
| 6      | USB Port         | USB 2.0 port  | USB 3.0 port                                   | USB 3.0 port /<br>Type-C port | USB 3.0 port /<br>USB 2.0 port /<br>Type-C port |
| 7      | COM Port         | Provides an interface for RS-422 and RS-485 communication   | Provides an interface for RS-485 communication |                               |   |
|        | Input terminals  | For input wiring  |  |                               |   |
|        | Output terminals | For output wiring   |  |                               |   |
| 8      | Power supply     | For power supply  |  |                               |   |
| 9      | EtherCAT Port    | EtherCAT communication port<br>LINK indicator (green):<br>■ ON: the network connection is established.<br>■ OFF: the network connection is NOT established.<br>ACT indicator (orange):<br>■ Blinking: data transmission (sending / receiving)<br>■ OFF: NO data transmission                                      |  |                               |   |
| 10     | CANopen Port     | N/A   |  |                               | Provides a CANopen Switch port                  |


### 2.2.4 CPU Module Input / Output Terminals

| AX-8□□EP0 |      |     |
|-----------|------|-----|
|           | GPIO |     |
|           | TX+  | TX- |
|           | SG   | SG  |
|           | RX+  | RX- |
|           | A+   | A-  |
|           | B+   | B-  |
|           | Z+   | Z-  |
|           | X0   | Y0  |
|           | X1   | Y1  |
|           | X2   | Y2  |
|           | X3   | Y3  |
|           | X4   | Y4  |
|           | X5   | Y5  |
|           | X6   | Y6  |
| X7        | Y7   |     |
| VCC       | GND  |     |

| AX-8H1E30CD2T |      |      |
|---------------|------|------|
|               | GPIO |      |
|               | 485+ | 485- |
|               | SG   | SG   |
|               | X0   | X1   |
|               | X2   | X3   |
|               | X4   | X5   |
|               | X6   | X7   |
|               | Y0   | Y1   |
|               | Y2   | Y3   |
|               | VCC  | GND  |

2

| AX-864EP1ME1TP  |      |      |
|---|------|------|
|  | GPIO |      |
|   | D+ 0 | D- 0 |
|   | SG   | SG   |
|   | D+ 1 | D- 1 |
|   | I0   | I1   |
|   | I2   | I3   |
|   | I4   | I5   |
|   | S/S  | S/S  |
|   | Q0   | Q1   |
|   | 24V  | 0V   |


| AX-8DH1ECP1CE1TP  |      |      |
|---|------|------|
|  | GPIO |      |
|   | D+ 0 | D- 0 |
|   | SG   | SG   |
|   | D+ 1 | D- 1 |
|   | A+   | A-   |
|   | B+   | B-   |
|   | Z+   | Z-   |
|   | I0   | I1   |
|   | I2   | I3   |
|   | I4   | I5   |
|   | S/S  | S/S  |
|   | Q0   | Q1   |
|   | 24V  | 0V   |

## 2.2.5 Wiring Configuration

### 2.2.5.1 AX-8□□EP0□□T Wiring

|                         |              |
|-------------------------|--------------|
| Input type              | NPN (Sink)   |
| Input voltage / current | 24VDC, 5mA   |
| Output type             | NPN (Sink)   |
| Voltage / current       | 24VDC, 100mA |


● General Input / Output Wiring



### 2.2.5.2 AX-8□□EPO□□P Wiring




|                                |              |
|--------------------------------|--------------|
| <b>Input type</b>              | PNP (Source) |
| <b>Input voltage / current</b> | 24VDC, 5mA   |
| <b>Output type</b>             | PNP (Source) |
| <b>Voltage / current</b>       | 24VDC, 50mA  |

● General Input / Output Wiring






### 2.2.5.3 AX-8□□EP0□□□T, AX-8□□EP0□□□P Wiring

- Encoder Wiring (5V supported only)



● RS-422 / RS-485 / SSI Wiring



| Pin | Function      | Pin       |
|-----|---------------|-----------|
| TX+ | RS422 TX+     | RS422 RX+ |
| TX- | RS422 TX-     | RS422 RX- |
| SG  | RS422/485 GND | SG        |
| RX+ | RS422 RX+     | RS422 TX+ |
| RX- | RS422 RX-     | RS422 TX- |


| Pin | Function      | Pin     |
|-----|---------------|---------|
| TX+ | RS485 +       | RS485 + |
| TX- | RS485 -       | RS485 - |
| SG  | RS422/485 GND | SG      |

| Pin | Function | Pin        |
|-----|----------|------------|
| TX+ | CLOCK+   | SSI CLOCK+ |
| TX- | CLOCK -  | SSI CLOCK- |
| SG  | SSI GND  | SG         |
| RX+ | DATA+    | SSI DATA+  |
| RX- | DATA-    | SSI DATA-  |

**2.2.5.4 AX-8H1E30CD2T Wiring**

|                                |              |
|--------------------------------|--------------|
| <b>Input type</b>              | NPN (Sink)   |
| <b>Input voltage / current</b> | 24VDC, 5mA   |
| <b>Output type</b>             | NPN (Sink)   |
| <b>Voltage / current</b>       | 24VDC, 100mA |


● **General Input / Output Wiring**




### 2.2.5.5 AX-864EP1ME1TP Wiring

|                         |                           |
|-------------------------|---------------------------|
| Input type              | NPN / PNP (Sink / Source) |
| Input voltage / current | 24VDC, 5mA                |
| Output type             | NPN / PNP (Sink / Source) |
| Voltage / current       | 24VDC, 250mA              |




● General Input Wiring



I0~I5 : Sink or Source





● General Output Wiring




### 2.2.5.6 AX-8DH1ECP1CE1TP Wiring

|                         |                           |
|-------------------------|---------------------------|
| Input type              | NPN / PNP (Sink / Source) |
| Input voltage / current | 24VDC, 5mA                |
| Output type             | NPN / PNP (Sink / Source) |
| Voltage / current       | 24VDC, 200mA              |

● General Input Wiring




● General Output Wiring




Sink Output Wiring

Q0, Q1 : Sink




Source Output Wiring


Q0, Q1 : Source



● Encoder Wiring (5V supported only)



Encoder Wiring



---

# Chapter 3 Installing Hardware and Getting Started

## Table of Contents

|            |   |             |
|------------|---|-------------|
| <b>3.1</b> | <b>Installing Hardware .....</b>                              | <b>3-2</b>  |
| 3.1.1      | Installing and Uninstalling a Memory Card .....               | 3-2         |
| 3.1.2      | Installing and Uninstalling a CPU Module.....                 | 3-4         |
| 3.1.2.1    | AX-8 Series (Except for AX-8DH1ECP1CE1TP).....                | 3-4         |
| 3.1.2.2    | AX-8DH1ECP1CE1TP .....  | 3-6         |
| 3.1.3      | Installing in the Control Cabinet.....                        | 3-7         |
| 3.1.3.1    | Installation on a DIN Rail .....                              | 3-7         |
| 3.1.3.2    | Installation in the Control Cabinet.....                      | 3-8         |
| 3.1.3.3    | Ambient Temperature Requirements for the Control Cabinet..... | 3-9         |
| 3.1.3.4    | Measures to Enhance Anti-interference Ability .....           | 3-9         |
| 3.1.3.5    | Dimension Requirements for the Control Cabinet .....          | 3-9         |
| <b>3.2</b> | <b>Installing and Uninstalling DIADesigner-AX.....</b>        | <b>3-10</b> |
| 3.2.1      | Installing DIADesigner-AX.....                                | 3-11        |
| 3.2.2      | Uninstalling DIADesigner-AX .....                             | 3-16        |
| <b>3.3</b> | <b>Getting Started and Setting Up Communication .....</b>     | <b>3-17</b> |
| 3.3.1      | Getting Started.....  | 3-17        |
| 3.3.2      | Setting Up Communication.....                                 | 3-18        |


## 3.1 Installing Hardware

### 3.1.1 Installing and Uninstalling a Memory Card

- Installing and uninstalling an SD card (AX-8□□EP0, AX-8H1E30CD2T)


- SD card slot on the CPU module

The SD card slot is on the front side of the AX-8 Series PLC as indicated by the arrow below.



- Installing an SD card

Insert an SD card vertically into the card slot and push it to the end of the slot until it clicks. Be sure the SD card is fixed firmly in the slot; if the SD card is loose, it is not installed correctly. The SD card features a mistake-proof design, and it can be inserted in only one direction. Do not force to push the SD card into the slot in the wrong direction or you may damage the controller / card. Please refer to the figure below for instruction.




- Uninstalling an SD card

Push the SD card further into the slot to eject the card.

- Installing and uninstalling a micro SD card ( AX-8DH1ECP1CE1TP )

- Micro SD card slot on the CPU module

The micro SD card slot is on the front side of the AX-8 Series PLC as indicated by the arrow below.




- Installing a micro SD card

Insert a micro SD card vertically into the card slot and push it to the end of the slot until it clicks. Be sure the micro SD card is fixed firmly in the slot; if the micro SD card is loose, it is not installed correctly. The micro SD card features a mistake-proof design, and it can be inserted in only one direction. Do not force to push the micro SD card into the slot in the wrong direction or you may damage the controller / card. Please refer to the figure below for instruction.

- Uninstalling a micro SD card

Push the micro SD card further into the slot to eject the card.



## 3.1.2 Installing and Uninstalling a CPU Module


### 3.1.2.1 AX-8 Series (Except for AX-8DH1ECP1CE1TP)

- Rail mounting

Turn to the back side of the AX-8 Series PLC as shown in the figure below. Attach the fixing clip set to the AX-8 Series PLC using M3 round-head screws.

- AX-8□□EP0、AX-8H1E30CD2T

- AX-864EP1ME1TP





■ **Installation**

1. Pull out the fixing clip at the rear of the AX-8 Series PLC. Then edge the mounting rail with the horizontal slots which are also at the rear of the AX-8 Series PLC in direction ①.
2. Push the AX-8 Series PLC in direction ② till it clicks to lock it firmly on the mounting rail.

- AX-8□□EP0 · AX-8H1E30CD2T

- AX-864EP1ME1TP





3

■ **Uninstallation**

1. Pull down the fixing clip at the rear of the AX-8 Series PLC in direction ① with the tip of a screwdriver.
2. Then pull the AX-8 Series PLC in direction ② to remove it from the mounting rail.

- AX-8□□EP0 · AX-8H1E30CD2T

- AX-864EP1ME1TP





### 3.1.2.2 AX-8DH1ECP1CE1TP

Note: Avoid placing small foreign objects near the CANopen port located at the bottom of the module to prevent them from falling inside.



- **Wall mounting**

There are two ways to install the AX-8 Series PLC onto a wall:

1. Turn to the back side of the AX-8 Series PLC as shown in the figure below. Attach the fixing clip set to the AX-8 Series PLC using M3 round-head screw.




2. Turn the AX-8 Series PLC to its right side, as shown in the figure below. Attach the fixing clip set to the AX-8 Series PLC using M3 round-head screws.




### 3.1.3 Installing in the Control Cabinet

#### 3.1.3.1 Installation on a DIN Rail

Pull out the fixing clip at the rear of the AX-8 Series PLC. Then edge the DIN rail with the horizontal slots which are also at the rear of the AX-8 Series PLC. Push the AX-8 Series PLC to fit with the DIN rail till it clicks to have the AX-8 Series PLC firmly installed on the DIN rail.



### 3.1.3.2 Installation in the Control Cabinet



3

### 3.1.3.3 Ambient Temperature Requirements for the Control Cabinet

- Requirements for installing AX-8 Series PLC in the control cabinet


| ⚠ Warning  |
|--|
| <ul style="list-style-type: none"> <li>■ The ambient temperature of the control cabinet should be 0 ~ 50°C and the humidity should be 5 ~ 95%.</li> <li>■ Avoid installing AX-8 Series PLC near equipment with high temperature.</li> <li>■ Keep sufficient space for air ventilation.</li> <li>■ Install fans or air conditioner if the ambient temperature exceeds 55°C.</li> <li>■ AX-8 Series PLC is for indoor use only.</li> <li>■ Install the control cabinet around 1.0 ~ 2.0m in height for easier installation and operation.</li> <li>■ Keep away from the high-voltage equipment or power equipment during installation.</li> <li>■ Disconnect power supply of the control cabinet before installation.</li> </ul> |

### 3.1.3.4 Measures to Enhance Anti-interference Ability

| ⚠ Warning  |
|--|
| <ul style="list-style-type: none"> <li>■ Avoid installing the AX-8 Series PLC in the control cabinet with high-voltage equipment.</li> <li>■ Keep a distance of at least 200mm from the power wires during installation.</li> <li>■ The control cabinet should be grounded.</li> <li>■ Use the AX-8 Series PLC in accordance with the specified instructions by the manufacturer or the protection provided may be compromised.</li> </ul> |

### 3.1.3.5 Dimension Requirements for the Control Cabinet

- Internal installation

|   |   |
|---|---|
| <p>The AX-8 Series PLC should be installed in an enclosure. Keep a distance of at least 50 millimeters around the controller to ensure normal heat dissipation condition.</p> |  <p>(D &gt; 50mm)</p> |
|---|---|

## 3.2 Installing and Uninstalling DIADesigner-AX

Before starting the development work of AX-8 Series system, you must acquire the software **DIADesigner-AX**, which is the integrated platform for program development, hardware and network configuration.

- **System requirements**

The table below indicates the system requirements for DIADesigner-AX installation.

| Item             | System Requirements   |
|------------------|---|
| Version*1        | DIADesigner-AX V1.0.0.0 or later                                    |
| Operating System | Windows 7 / 8.1 / 10 (32/64 bits)                                   |
| CPU              | Intel Celeron 540 1.8GHz (min.)<br>Intel Core i5 M520 2.4GHz (min.) |
| Memory           | 2GB or above (4GB or above is recommended)                          |
| Hard Disk Drive  | 10GB or above   |
| Monitor          | Resolution: 1920 x 1080 pixels is recommended                       |
| Keyboard/Mouse   | General keyboard and mouse or Windows-compatible devices            |
| PC interface     | Ethernet, USB, Serial port (depending on product interface)         |
| Software         | Microsoft .Net Framework 4.6.2                                      |

\*1: The latest version available is V1.8 as of this writing. Please refer to the official website - [DIASstudio](#) for later releases.

### 3.2.1 Installing DIADesigner-AX

Before installation, ensure the computer used for installing DIADesigner-AX meets the minimum system requirements listed in section 3.2 and has been equipped with DIAInstaller.

DIAInstaller is used to easily download, install, and update all DIAStudio software including DIADesigner-AX. You can download **DIAStudio** for **DIAInstaller** from <https://diastudio.deltaww.com/home/downloads>.

You have to sign in or sign up before accessing the download page.



**Sign in with your existing account**

**Email Address**

**Password** [Forgot your password?](#)

**Sign in**

Don't have an account? [Sign up now](#)


After login, click **DIAStudio** download button to download **DIAInstaller** as the image shown below.

Software


| Software Name   | Description                                      | OS                 | Issue Date | File  |
|-----------------|--|--------------------|------------|---|
| COMMGR V2.2.1   | COMMGR V2.2.1                                    | Windows 10 64 bits | 2023/02/20 |  |
| DIASudio V1.2.2 | DIASudio Software download and Installation Tool | Windows 10 64 bits | 2023/06/16 |  |

Follow the steps below to install DIADesigner-AX.


1. Double-click **DIInstaller** icon to check the latest version of DIADesigner-AX.
2. Click **Download**.




3. After DIADesigner-AX is downloaded and grayed out, click **Install**.




4. An **InstallShield Wizard** shows up and starts installing. Click **Next** after completion.




5. The window of **License Agreement** shows up. Select **I accept the terms in the license agreement** and click **Next**.




6. The window of **Very important information** shows up. Select **I have read the information** and click **Next**.




7. Click **Change...** to change the download path. Or leave the default path unchanged. Click **Next**.




8. The window of **Setup Type** shows up as the image shown below. Select the one you need and then click **Next**.



9. The window of **Ready to Install the Program** appears as below. Click **Install** to continue.




10. It may take some time to install.



3


11. After installation, the window of **InstallShield Wizard Completed** appears. Click **Finish** to complete the installation.



### 3.2.2 Uninstalling DIADesigner-AX

Follow the steps below to uninstall DIADesigner-AX.

1. Double-click **DIInstaller** icon to open and then click **Uninstall**.



2. The system will remove DIADesigner-AX from your computer in the background automatically.

## 3.3 Getting Started and Setting Up Communication

### 3.3.1 Getting Started

After DIADesigner-AX is successfully installed, click **Start** . You can find it under the folder of **Delta Industrial Automation** or find its shortcut on the desktop. Double-click either one to start the software. Besides, you can open more than one DIADesigner-AX software to achieve multitasking.




OR



3

After the display of the welcome page, you can see the homepage as below. Refer to **Chapter 4** for more details on operation.



### 3.3.2 Setting Up Communication

After DIADesigner-AX is successfully installed, the system creates an execution file **CODESYS Gateway V3** under the folder of Delta Industrial Automation and **GatewaySysTray.exe** in the folder of Program Files. Double-click either one to start the Gateway.


Hereafter, the Gateway is started automatically whenever you turn on your computer. Its icon  shall appear on the taskbar. If not, go to the execution file **CODESYS Gateway V3** under the folder of Delta Industrial Automation or **GatewaySysTray.exe** in the Program Files folder to start the Gateway manually.

3




OR

| 名稱                            | 修改日期               | 類型      | 大小       |
|-------------------------------|--------------------|---------|----------|
| PCAN_Basic                    | 2023/8/17 下午 04:38 | 檔案資料夾   |          |
| SourceLicenses                | 2023/8/17 下午 04:38 | 檔案資料夾   |          |
| tempCFG                       | 2023/8/17 下午 04:38 | 檔案資料夾   |          |
| CmpBlkDrvCanClient.dll        | 2022/9/28 下午 04:25 | 應用程式擴充  | 424 KB   |
| CmpBlkDrvCanServer.dll        | 2022/9/28 下午 04:25 | 應用程式擴充  | 420 KB   |
| CmpBlkDrvUsb.dll              | 2022/9/28 下午 04:25 | 應用程式擴充  | 425 KB   |
| CmpEL6751CanDrv.dll           | 2022/9/28 下午 04:25 | 應用程式擴充  | 414 KB   |
| CmplxxatCANDrv.dll            | 2022/9/28 下午 04:25 | 應用程式擴充  | 422 KB   |
| CmpKvaserCANDrv.dll           | 2022/9/28 下午 04:25 | 應用程式擴充  | 421 KB   |
| CmpPCANBasicDrv.dll           | 2022/9/28 下午 04:25 | 應用程式擴充  | 420 KB   |
| Gateway.cfg                   | 2023/8/17 下午 04:39 | CFG 檔案  | 1 KB     |
| GatewayService.exe            | 2022/9/28 上午 07:25 | 應用程式    | 4,067 KB |
| GatewaySysTray.exe            | 2022/9/28 上午 07:25 | 應用程式    | 1,235 KB |
| qt.conf                       | 2021/2/10 下午 05:42 | CONF 檔案 | 1 KB     |
| ServiceControl.exe            | 2022/9/28 下午 04:25 | 應用程式    | 751 KB   |
| SysGraphicWindowQt.dll        | 2022/9/28 下午 04:25 | 應用程式擴充  | 876 KB   |
| SysNativeCommonControlsQt.dll | 2022/9/28 下午 04:25 | 應用程式擴充  | 429 KB   |
| SysPipeWindows.dll            | 2022/9/28 下午 04:25 | 應用程式擴充  | 417 KB   |
| SysSvgRendererQt.dll          | 2022/9/28 下午 04:25 | 應用程式擴充  | 417 KB   |
| SysSvgRendererWin.dll         | 2022/9/28 下午 04:25 | 應用程式擴充  | 809 KB   |
| SysWindowFileDialogQt.dll     | 2022/9/28 下午 04:25 | 應用程式擴充  | 412 KB   |



You can click the Gateway icon  on the taskbar to check its status. The icon is in red when the Gateway is started.




Click **Stop Gateway** if you need to stop gateway working. The icon turns grey when the gateway is stopped.





If you need to discontinue the execution of GatewaySysTray completely, select **Exit Gateway Control** and the icon  will disappear from the taskbar.



Get into the software **DIADesigner-AX** and open or create a project to see the project-setting page. Double-click **Device** (Product Name) in the left-hand column to open the device-setting page. The Gateway status is under the **Communication Settings** tab. If the Gateway is started, its light is green. If the Gateway is stopped, its light is red.




To configure the Local Gateway, click **Gateway** and select **Configure the Local Gateway...** to open the setting window.




3


You can create a different port such as COM Port for connection. Click **Add**, select **Add Interface...** and then use the drop-down list above to select **COM Port** to add.



After COM Port is added, you can set up its name, baud rate and the corresponding port. Click **OK** once the setting is done. You should Stop/Start GateSysTray again to ensure the following actions, such as Scan Network, work properly. Please refer to the previous steps to run GateSysTray again.




You can also add configuration settings under COM Port. Right-click the **COM Port** icon  **COM Port**, click **Add** and select **Add Configuration Setting...** to add the setting items. After that, you can further define the setting values. Click **OK** once the setting is done.



3

After the configurations of Local Gateway are nailed down, go to the **Scan Network** tab to bring out network scanned results on the **Select Device** setting page. Select **AX-816EP0ME1T** and then click **OK**.



If the connection is successfully established, the status light is green with the device information shown below.

The screenshot shows a software interface with a left-hand navigation menu and a main workspace. The navigation menu includes: Applications, Backup and Restore, Files, Log, PLC Settings, PLC Shell, Licensed Software Metrics, System Settings, Right Settings, System Parameters, System IEC Objects, Task Deployment, Status, and Information. The main workspace features a network diagram with a laptop, a central 'Gateway' device, and a target device on the right. The target device is highlighted with a red border. Below the diagram, there are two dropdown menus: 'Gateway-1' and 'AX-816EP0ME1T (active)'. The 'AX-816EP0ME1T (active)' dropdown is expanded, showing the following details:

- Device Name: AX-816EP0ME1T
- Device Address: 000A
- IP-Address: 192.168.0.10, 192.168.1.10
- MAC-Address: 00:18:23:86:8b:da, 00:18:23:86:8b:db
- Target ID: 16F7 0412
- Target Type: 4102
- Target Vendor: Delta Electronics
- Target Version: 3.5.18.30

**MEMO**

---

## Chapter 4 Basic Operation

### Table of Contents

|            |  |             |
|------------|--|-------------|
| <b>4.1</b> | <b>LCM Display Operation.....</b>          | <b>4-3</b>  |
| 4.1.1      | Overview .....                             | 4-4         |
| 4.1.2      | Home Screen .....                          | 4-5         |
| 4.1.3      | Main Menu Configuration .....              | 4-6         |
| 4.1.3.1    | Information .....                          | 4-6         |
| 4.1.3.2    | Settings.....                              | 4-7         |
| 4.1.3.3    | Error Message .....                        | 4-13        |
| 4.1.3.4    | Performance.....                           | 4-14        |
| 4.1.4      | Error Codes and Descriptions .....         | 4-15        |
| 4.1.4.1    | BIOS Error Codes.....                      | 4-15        |
| 4.1.4.2    | Application Error Codes.....               | 4-17        |
| <b>4.2</b> | <b>Introduction to DIADesigner-AX.....</b> | <b>4-18</b> |
| 4.2.1      | Creating a New Project .....               | 4-18        |
| <b>4.3</b> | <b>Settings on the Device Page .....</b>   | <b>4-20</b> |
| 4.3.1      | CPU Parameter Settings.....                | 4-21        |
| 4.3.1.1    | Communication Settings .....               | 4-21        |
| 4.3.1.2    | Applications .....                         | 4-24        |
| 4.3.1.3    | Backup and Restore .....                   | 4-25        |
| 4.3.1.4    | Files .....                                | 4-26        |
| 4.3.1.5    | Log .....                                  | 4-26        |
| 4.3.1.6    | PLC Settings.....                          | 4-29        |
| 4.3.1.7    | PLC Shell .....                            | 4-31        |
| 4.3.1.8    | User and Groups .....                      | 4-32        |
| 4.3.1.9    | Access Rights .....                        | 4-36        |
| 4.3.1.10   | Symbol Rights .....                        | 4-42        |
| 4.3.1.11   | System Settings .....                      | 4-44        |
| 4.3.1.12   | System Parameters .....                    | 4-46        |
| 4.3.1.13   | Task Deployment .....                      | 4-47        |
| 4.3.1.14   | Status .....                               | 4-48        |
| 4.3.1.15   | Information.....                           | 4-48        |
| <b>4.4</b> | <b>Data Type and Variables .....</b>       | <b>4-49</b> |
| 4.4.1      | Data Type .....                            | 4-49        |

|            |   |             |
|------------|---|-------------|
| 4.4.2      | Variables .....                                     | 4-50        |
| 4.4.2.1    | Declaration of Variables .....                      | 4-50        |
| 4.4.2.2    | Address Assignment.....                             | 4-51        |
| 4.4.2.3    | Variables .....                                     | 4-53        |
| 4.4.2.4    | User-defined Data Type .....                        | 4-58        |
| 4.4.2.5    | Timing for the Variable being Cleared to Zero ..... | 4-61        |
| 4.4.2.6    | Timing for the Default Value to be Valid .....      | 4-61        |
| <b>4.5</b> | <b>Task.....</b>                                    | <b>4-62</b> |
| 4.5.1      | Task Configuration .....                            | 4-62        |
| 4.5.1.1    | Task Type .....                                     | 4-62        |
| 4.5.1.2    | Bus Cycle Task .....                                | 4-63        |
| 4.5.1.3    | Watchdog .....                                      | 4-64        |
| 4.5.1.4    | Motion Instructions for Each Type of Task.....      | 4-65        |
| <b>4.6</b> | <b>Recipe Manager .....</b>                         | <b>4-68</b> |
| 4.6.1      | Recipe Manager .....                                | 4-70        |
| 4.6.2      | Recipe Definition.....                              | 4-72        |
| 4.6.3      | RecipeManCommands .....                             | 4-74        |


## 4.1 LCM Display Operation

Among the AX-8 Series, the AX-8DH1ECP1CE1TP model adopts an LCM (Liquid Crystal Display Module), providing an intuitive and streamlined user interface. It allows users to monitor equipment status in real time and perform error diagnosis, performance monitoring, PLC operation control, and network IP inquiry directly through the screen.

In this section, it introduces the display operations, provides a function overview, and explains error messages. With this interface, on-site personnel can perform various basic configuration and maintenance tasks without the need for an external programming editor.

Note: The term **Application / APP** used in this section (4.1) corresponds to what is referred to as a **project** in other sections.

### 4.1.1 Overview



The LCM startup sequence is as follows:

1. After the PLC is powered on, it enters the boot process, which displays the Delta logo and self-test codes.
2. If the PLC is started for normal operations, the system proceeds to the network information screen. If an error occurs, the corresponding error code and related message will be displayed (please refer to **section 4.1.4**).


### 4.1.2 Home Screen

The home screen shows the PLC's status parameters, including the application runtime status (e.g., **APP RUN**), total CPU usage, temperature, and the current power-on runtime.



By pressing the  $\Delta / \nabla$  buttons, users can view the runtime status of multiple applications.

Access the **Performance** screen from the home menu to view the usage of individual CPU core.



### 4.1.3 Main Menu Configuration

#### 4.1.3.1 Information

The **Information** menu provides basic information related to the PLC, such as firmware version, CPU model and details of each network.

1. Basic information

| Item  | Description          | Display  |
|-------|----------------------|--|
| FW    | Firmware version     | <div style="border: 2px solid black; padding: 5px;">                     FW : x.x.x.x<br/>                     LCD : x.x.x.x<br/>                     BIOS : x.x.x.x<br/>                     CPU : Celeron                 </div> |
| LCDSW | LCM software version |  |
| BIOS  | BIOS version         |  |
| CPU   | CPU model            |  |

2. Network information

| Item       | Description | Network Info Display  | Address  |
|------------|-------------|---|--|
| EtherCATX1 | EtherCAT    | <div style="border: 2px solid black; padding: 5px;">                     EthernetX1 Info<br/>                     192.168.0.10<br/>                     255.255.255.0<br/>                     0.0.0.0                 </div> | <div style="border: 2px solid black; padding: 5px;">                     1. 70ca4dfddf87<br/>                     2. 70ca4dfddf88<br/>                     3. 2abb30f0948a<br/>                     4. 16af709dc449                 </div> |
| EtherCATX2 |             |   |  |
| EthernetX1 | Ethernet    |   |  |
| EthernetX2 |             |   |  |
| EthernetX3 |             |   |  |
| EthernetX4 |             |   |  |

The **LANport MAC** option displays the MAC address of each network interface.

### 4.1.3.2 Settings

#### 1. APP Status

The **APP Status** menu is used to set the operating status of the PLC application. You can access and operate the **APP Status** from the **Settings** screen. To configure it, use the navigation buttons to select the desired status and press **Enter** to confirm. Once the setting is successfully applied, the ← symbol will move to the selected option. The item marked with the ← symbol indicates the current operating status, as shown in the figure below.



#### 2. Advanced Settings

The **Adv. Settings** menu provides access to high-level PLC operations. A password is required to enter this menu. The default password is **000000**.

Accessing the password entry screen:

- When entering the password entry screen, the first digit will blink and display **0**. Use the **Δ / ▽** buttons to cycle through digits 0 to 9.
- When the desired digit appears, pressing **Enter** to confirm.
- After a digit is confirmed, the cursor will automatically move to the next digit. Repeat the process to complete the entire password entry.
- The password input does not support backspace function. If an incorrect entry is made, a warning message stating **Incorrect Password** will be displayed. Press the **Back** button to return to the previous menu, then press **Enter** to re-enter the password screen.

Entering the password:


- During password input, each digit is displayed in plain text as it is being selected. After confirmed, the entered digit will change to masked format.
- Press **Enter** after the final digit is confirmed. If the password is incorrect, a warning message stating **Incorrect Password** will be displayed. Press the **Back** button to return and re-enter the password.
- If the password is correct, press **Enter** then it will proceed to the submenu.

a. Reset LAN port

The **Reset LANport** function restores the network settings of the port to the factory default IP or a dynamic IP.

Press **Enter** to confirm after configuration. The display is as follows.


Note: Do not power off the device during the reset process.



## b. Restore application

The **Restore APP** function restores the application to the most recent backup version. The system identifies the latest backup based on the saved timestamp. Follow the steps shown in the figure below to complete the restoration process. Upon restoration, the screen will display **Restore Done**, and the application will be replaced with the latest backup version.

Note: Do not power off the device during the restoration process.




If there is no backup application in the PLC, which means no project has ever been loaded, selecting **Restore APP** will result in a failed operation, and the screen will display **Restore Failed** as shown below.



## c. Factory reset

The **Factory Reset** function resets the PLC to its factory settings. This includes restoring the factory default IP and removing applications.

Note: Do not power off the device during the reset process.



d. Backup / restore with external device


The **Backup / Restore with Ext. Device** function allows the PLC application to be restored from or backed up with external devices. The steps are as follows.

- Using USB for backup / restore:


Go to **Backup / Restore with Ext. Device > USB Disk**, then select the corresponding USB device based on the connected hardware type (USB Disk 1 for USB 3.0, USB Disk 2 for Type-C, USB Disk 3 or 4 for USB 2.0).

To back up the application, select **PLC To USB**. When the message **Backup Done** appears, the application has been saved to the USB device.

To restore the application, select **USB To PLC**. The system will reboot, and the PLC application will be replaced.



USB Backup / Restore Flowchart




Hardware – USB Mapping

- Using SD card for backup / restore:

Go to **Backup / Restore with Ext. Device > SD Card**.

To back up the application, select **PLC To SD Card**. When the message **Backup Done** appears, the project has been saved to the SD card.

To restore the application, select **SD Card To PLC**. The system will reboot, and the PLC application will be replaced.




SD Card Backup / Restore Flowchart

- During the backup or restore process, the following error messages may appear:

The screen displays **No APP** when there is no application in the PLC.

The screen displays **No APP in USB Disk / SD Card** when there is no application in the external device.

The screen displays **No USB Disk / No SD Card** when there is no external device connected.




Backup / Restore Error Flowchart (USB Example)

e. Change LCM password

The **Change LCM Password** function allows users to replace the default LCM password with a personalized one.


Select **Change LCM Password** and enter the current password first. Once verified, the system proceeds to the **Enter New Password** screen, where users can input a new password. This is followed by the **Confirm New Password** screen – enter the new password again to confirm.

If the password has been successfully changed, a message stating **Password Changed** will appear. If the password entered is incorrect, the screen will display **Incorrect Password**.



3. Languages


The **Languages** menu allows users to choose the display language of the screen. Available options include Simplified Chinese and English. The default language is 简体中文 (Simplified Chinese).



### 4.1.3.3 Error Message

During PLC operation, users can check the current error status on the **Error Msg** screen. It displays the error code and corresponding message. Please refer to **section 4.1.4 Error Codes and Descriptions** to identify the issue, or contact our customer service team for assistance.


When the PLC is running normally, the message **Er.0 Null** will be shown on the **Error Msg** screen, indicating no active errors.



When the PLC encounters an issue, it typically falls into one of the following error types.


#### 1. BIOS error (the PLC fails to boot up)

After powering on, the system enters the BIOS self-test stage, during which the Delta logo and self-test codes are displayed. If any issue is detected during this process, it will jump to the Error Msg screen, showing the error code and corresponding message. For example, **Er.0D CPU initialization error** indicates a CPU initialization failure, which prevents the system from completing the boot process.



2. Application error (the PLC boots up successfully but a runtime error occurs)


Once the system has booted up successfully, users can view any detected issues on the **Error Msg** screen. For example, **Er.2007 PowerFail Task Create Fail** indicates a low-voltage error detected in the PLC during operation.



4

#### 4.1.3.4 Performance

The **Performance** screen displays system parameters related to PLC runtime performance, including CPU core utilization and memory usage.



## 4.1.4 Error Codes and Descriptions

### 4.1.4.1 BIOS Error Codes

| Code | Message   | Description   |
|------|---|---|
| 0x50 | Memory initialization error. Invalid memory type or incompatible memory speed   | Memory initialization failed due to invalid memory type or incompatible memory speed. |
| 0x51 | Memory initialization error. SPD reading has failed                             | Memory initialization failed because the SPD data could not be read.                  |
| 0x52 | Memory initialization error. Invalid memory size or memory modules do not match | Memory initialization failed due to invalid memory size or mismatched memory modules. |
| 0x53 | Memory initialization error. No usable memory detected                          | Memory initialization failed because no usable memory is detected.                    |
| 0x54 | Unspecified memory initialization error   | Memory initialization failed for an unknown reason.                                   |
| 0x55 | Memory not installed  | No memory is installed.   |
| 0x56 | Invalid CPU type or Speed   | CPU type or speed is not supported.   |
| 0x57 | CPU mismatch  | The installed CPU does not match system requirements.                                 |
| 0x58 | CPU self test failed or possible CPU cache error                                | CPU self-test failed or there is a possible CPU cache memory error.                   |
| 0x59 | CPU micro-code is not found or micro-code update is failed                      | CPU microcode was not found or the microcode update failed.                           |
| 0x5A | Internal CPU error  | An internal CPU error occurred.   |
| 0x5B | reset PPI is not available  | The reset PPI is not available.   |
| 0xD0 | CPU initialization error  | CPU initialization failed.  |
| 0xD1 | North Bridge initialization error   | Northbridge initialization failed.  |
| 0xD2 | South Bridge initialization error   | Southbridge initialization failed.  |
| 0xD3 | Some of the Architectural Protocols are not available                           | Some required architectural protocols are not available.                              |
| 0xD4 | PCI resource allocation error. Out of Resources                                 | PCI resource allocation failed due to lack of available resources.                    |
| 0xD5 | No Space for Legacy Option ROM  | Insufficient storage space for Legacy Option ROM.                                     |
| 0xD6 | No Console Output Devices are found   | No console output device was detected.  |
| 0xD7 | No Console Input Devices are found  | No console input device was detected.   |
| 0xD8 | Invalid password  | The password is invalid.  |
| 0xD9 | Error loading Boot Option (LoadImage returned error)                            | An error occurred while loading the boot option (LoadImage returned an error).        |

| Code | Message   | Description   |
|------|---|---|
| 0xDA | Boot Option is failed (StartImage returned error) | Boot option failed to start (StartImage returned an error). |
| 0xDB | Flash update is failed                            | Flash update failed.  |
| 0xDC | Reset protocol is not available                   | Reset protocol is not available.                            |
| 0xDE | HDD not installed                                 | No HDD is installed.  |
| 0xDF | CMOS BATTERY LOW POWER                            | CMOS battery power is low.                                  |
| 0xE8 | S3 Resume Failed                                  | Failed to resume from S3 state.                             |
| 0xE9 | S3 Resume PPI not Found                           | S3 resume PPI was not found.                                |
| 0xEA | S3 Resume Boot Script Error                       | An error occurred while executing S3 resume boot script.    |
| 0xEB | S3 OS Wake Error                                  | OS failed to wake up from S3 state.                         |
| 0xF8 | Recovery PPI is not available                     | Recovery PPI is not available.                              |
| 0xF9 | Recovery capsule is not found                     | Recovery capsule was not found.                             |
| 0xFA | Invalid recovery capsule                          | Recovery capsule is invalid.                                |

#### 4.1.4.2 Application Error Codes

| Code   | Message  | Description                                  |
|--------|--|--|
| 0x0    | null   | No error                                     |
| 0x2002 | Firmware update failed before, stop application        | Firmware update failed; application stopped  |
| 0x2004 | Voltage LOW -> NORMAL                                  | Unstable 24V DC power supply                 |
| 0x2005 | Mapping LED registers failed                           | LED register mapping failed                  |
| 0x2007 | PowerFail Task Create Fail                             | System initialization error                  |
| 0x2008 | Load System Information Fail                           | Failed to load system information            |
| 0x200A | Getting PCIe Bar registers adr failed                  | Failed to get PCIe register address          |
| 0x200B | open network settings file failed.                     | Failed to open network settings file         |
| 0x200C | PLCID CRC Check Fail                                   | PLC ID CRC check failed                      |
| 0x200D | retain memory crc error                                | Retentive memory CRC error                   |
| 0x21F0 | There is no user and password setting for FTP Server!! | No user or password set for FTP server       |
| 0x21F1 | There is no USBDisk Found!!                            | No USB device detected                       |
| 0x21F2 | This Storage Space is not support for FTP Server!!     | Storage space not supported for FTP server   |
| 0x21F3 | sFtp is not support for FTP Server!!                   | SFTP not supported for FTP server            |
| 0x3000 | LCM write Fail   | LCM write failed                             |
| 0x3001 | Factory info error, deny start                         | Factory information error; operation stopped |
| 0x3002 | M.2 Life Left 10 percent Stop PLC!!!                   | M.2 remaining lifespan is 10%; PLC stopped   |


## 4.2 Introduction to DIADesigner-AX

DIADesigner-AX is an open platform for PLC development system and the core for industrial automation. The adaptable DIADesigner-AX provides an easy way to create professional engineering of IEC 61131-3 automation projects. Based on the IEC 61131-3 data structure and the high-level language programming, DIADesigner-AX is strong in functionality, easy to develop, reliable, extendable and open for development. Integrated with components such as visualization and safety solution, DIADesigner-AX offers a variety of user-friendly engineering functions for your professional applications in controller development system sectors including PLC and motion control.


In DIADesigner-AX, you can customize the user interface by arranging the window layout and the appearance of menus, toolbars and commands according to your requirements.

### 4.2.1 Creating a New Project


1. Double-click the DIADesigner-AX icon  to open the software. To create a new project, click **New Project**  on the Start Page or click **File** on the toolbar and select **New Project (Ctrl+N)**.




2. A window with two sections, Categories and Templates, will pop up. Click **Projects** in the Categories section and choose **Standard project** in the Templates section. After that, create a name and specify a location for the project and then click **OK**.



- The Standard Project dialog then appears. Select the device and the programming language from the drop-down lists. Click **OK** after selection, the system will generate a cyclic task with a default PLC\_PRG.




- After a new project is created, a project management area will be added on the left-hand side. All the options are listed in nodes. If nothing appears in the project management area, click **View > Devices (Alt+0)** on the toolbar to open it.



### 4.3 Settings on the Device Page

In this section, all setting items on the Device page will be introduced respectively.




4

## 4.3.1 CPU Parameter Settings

### 4.3.1.1 Communication Settings


On the **Communication Settings** page, you can define method for communication between DIADesigner-AX and the controller. Use the drop-down list of the Gateway tab to add new gateways, manage existing gateways or configure local gateways. You can simply specify an IP address (e.g. 192.168.1.5) or its device name (e.g. AX-816EP0ME1T) in the field under the image of controller. After that, DIADesigner-AX will automatically scan for the controller within the network of the Gateway.



#### ● Connection Status

The dots in the bottom right corner of the images of Gateway and the controller indicate the connection status.

- Red: unable to establish connection.
- Green: connection is established.
- Black: unknown connection status.



| Tab                 | Description   |
|---------------------|---|
| <b>Scan network</b> | Click <b>Scan Network</b> to open the <b>Select Device</b> window. All configured gateways with the associated controllers are listed here. You can select a target device from the list. |

|   |  |
|---|--|
| <p style="text-align: center;"><b>Gateway</b></p> | <p>The following setting items are included in this menu:</p> <ul style="list-style-type: none"> <li>■ <b>Add New Gateway:</b> add and define a new gateway channel.</li> <li>■ <b>Manage Gateways:</b> an overview of all gateways is provided. You can add / delete entries or change the order here.</li> <li>■ <b>Configure the Local Gateway:</b> click to open the <b>Gateway Configuration</b> page. You can configure the block drivers for the local gateway here.</li> </ul>   |
| <p style="text-align: center;"><b>Device</b></p>  | <p>The following setting items are included in this menu:</p> <ul style="list-style-type: none"> <li>■ <b>Options</b> <ul style="list-style-type: none"> <li>- <b>Add Current Device to Favorites:</b> add the selected device to the list of favorite devices.</li> <li>- <b>Manage Favorite Devices:</b> click to open a list of all preferred devices. You can add / delete entries or change their order here. The device on the top is set as default.</li> <li>- <input checked="" type="checkbox"/> <b>Filter Network Scans by Target ID:</b> only the device whose target ID is the same as the current device configured in the project is displayed.</li> <li>- <input checked="" type="checkbox"/> <b>Confirmed Online Mode:</b> DIADesigner-AX requires you to confirm when calling the following online commands for safety purposes:<br/>Force values, Write values, Multiple loading, Remove force list, Single cycle, Start, and Stop.</li> <li>- <b>Store Communication Settings in Project:</b> <ul style="list-style-type: none"> <li><input checked="" type="checkbox"/>: DIADesigner-AX stores the communication settings in the project, which can be reused on the same computer later. If you use this project on another computer, the valid path must be reset.</li> <li><input type="checkbox"/>: DIADesigner-AX stores the communication settings in the locally installed options and user can reuse this setting on the same computer.</li> </ul> </li> </ul> </li> <li>■ <b>Rename Active Device</b> <p>Click to open the <b>Change Device Name</b> window.</p> </li> <li>■ <b>Send Echo Service</b> <p>DIADesigner-AX sends five echo services like the networking utility, Ping, to the controller to test network connections. These services are sent without data packet in the beginning and then sent with packet. The scope of data packets depends on the communication buffer of the controller. Information about each and the average response time for the transmission is shown on a new dialog box.</p> </li> <li>■ <input checked="" type="checkbox"/> <b>Encrypted Communication</b> <p>Communication to the controller is encrypted. A certificate is required to log in to the controller. If the certificate is not available, an error message will show up, prompting whether the certificate should be displayed / installed or not.</p> <p>Encrypted Communication is disabled when the <b>Enforce Encrypted Communication</b> option in the <b>Security Level</b> list is selected (<b>View &gt; Security Screen</b>).</p> </li> </ul> |


■ **Change Runtime Security Policy**

Click to open the **Change Runtime Security Policy** window to set encrypted communication for the device. The configuration of the controller will also be changed if the communication policy is modified.

| <b>Communication</b>          |  |
|-------------------------------|--|
| Current policy                | The currently selected policy for communication encryption.  |
| New policy                    | <ul style="list-style-type: none"> <li>- No encryption: encrypted communication is NOT supported.</li> <li>- Optional encryption: both encrypted and unencrypted communications are supported.</li> <li>- Enforced encryption: only encrypted communication is supported.</li> </ul> |
| <b>Device User Management</b> |  |
| Current policy                | The currently selected policy for user management.   |
| New policy                    | <ul style="list-style-type: none"> <li>- Optional user management: users can decide whether to activate encrypted communication or not.</li> <li>- Enforced user management: encrypted communication must be activated.</li> </ul>   |

### 4.3.1.2 Applications

You can check and manage the applications on the controller on this page.




4

| Item                        | Description   |
|-----------------------------|---|
| <b>Refresh List</b>         | To have the controller scanned for applications to update the list accordingly.   |
| <b>Remove</b>               | To delete the application selected in the list.   |
| <b>Remove All</b>           | To delete all listed applications on the controller.  |
| <b>Details</b>              | To check the attributes defined for the application on the Information tab.   |
| <b>Content<sup>*1</sup></b> | To check additional information about the differences between the latest generated code and the application code that exists on the controller, which are displayed in a comparison view. |

\*1: It is required to click **Application** under **Applications on the PLC** to activate **Content** button (**Application > Properties > Application generation options**).

### 4.3.1.3 Backup and Restore

You can backup and restore the application-specific files on the controller by saving and reading zip archive.



| Tab            | Description  |
|----------------|--|
| <b>Backup</b>  | <p>The items on the drop-down list are as follows:</p> <ul style="list-style-type: none"> <li>■ <b>Read Backup Information from Device....</b>: searching and listing all application-specific files in the <b>PlcLogic</b> directory.</li> <li>■ <b>Create Backup File and Save to Disc....</b>: compressing the chosen files into a backup zip file. (The file extension is .tbf, i.e. Target Backup File).</li> <li>■ <b>Save Backup File to Device</b>: saving the backup file to the controller.</li> </ul> |
| <b>Restore</b> | <p>The items on the drop-down list are as follows:</p> <ul style="list-style-type: none"> <li>■ <b>Load Backup File from Disc....</b>: selecting one backup file from the list found on the disk to view its content.</li> <li>■ <b>Load Backup File from Device....</b>: selecting one backup file from the list found on the controller to view its content.</li> <li>■ <b>Restore Backup to Device....</b>: restoring the backup file to the controller.</li> </ul>   |

- **Target Information**

|                |                |
|----------------|----------------|
| <b>ID</b>      | Device ID      |
| <b>Type</b>    | Device type    |
| <b>Version</b> | Device version |


- **Backup Information**

|                             |   |
|-----------------------------|---|
| <b>File name</b>            | Storage path for the backup file                          |
| <b>Size of active files</b> | Total size of the backup files set as active in the table |
| <b>Mode</b>                 | The scope for backup                                      |

|                  |  |
|------------------|--|
| <b>File name</b> | Storage path for the backup file   |
| <b>Comment</b>   | Optional entry for comment of the backup file; saved in the meta.info file and can be read when the files are restored |

### 4.3.1.4 Files

This section is for file transfer between the computer and the controller via DIADesigner-AX.




|   |  |
|---|--|
| <b>Location</b>   | Current file path in the computer system<br>The files with its name, size, and date modified are listed in the subdirectories below. |
|  | To create a new file folder  |
|  | To delete the selected files or folders  |
|  | To update the list of files and folders in the set path (Location)   |
|  | To write files to the controller   |
|  | To restore files from the controller   |

### 4.3.1.5 Log

In Log, it lists the events that occurred in the target system, including:

- Events which have occurred from system startup to shutdown (components loaded including version)
- Record of application operation including application download, online change, etc.
- Custom entries
- Log entries from I/O driver

- Log entries from data sources



| Item  | Description   |
|---|---|
| <b>UTC time</b>   | <input type="checkbox"/> : Standard setting; the time stamp is converted into the local time on the computer as indicated by the time zone of the operating system.<br><input checked="" type="checkbox"/> : The time stamp of the runtime system is displayed.   |
| <b>Severity</b>   | <p>Five categories based on the severity of the event:</p> <ul style="list-style-type: none"> <li>■  : Information</li> <li>■  : Warning</li> <li>■  : Error</li> <li>■  : Exception</li> <li>■  : Debugging</li> </ul> <p>You can show or hide each category by clicking the corresponding buttons in the bar. The number of log entries of the category concerned is shown on each button.</p> |
| <b>Time stamp</b>   | Date and time (e.g. 03.05.2023 20:10:31)  |
| <b>Description</b>  | Description of the event  |
| <b>Components</b>   | The library names used at runtime, e.g. CmpApp  |
| <b>Drop-down list with component names</b>  | To display the events related to the selected components  |
|  | To refresh the log list   |
|  | To export the list contents to an XML file  |
|  | To import an XML file to the list (Log)   |



### 4.3.1.6 PLC Settings

The basic settings for PLC configuration can be completed here. For instance, settings for I/O handling and bus cycle task.

① Application for I/O handling

② PLC Settings

Update I/O while in stop

Behavior for outputs in stop

Always update variables

③ Bus Cycle Options

Bus cycle task

④ Additional Settings

Generate force variables for IO mapping     Enable diagnosis for devices

Show I/O warnings as errors     Enable symbolic access for IOs

#### ① Application for I/O handling

| Item                         | Description                            |
|------------------------------|--|
| Application for I/O handling | Application for managing I/O operation |

#### ② PLC Settings

| Item                         | Description  |
|------------------------------|--|
| Update I/O while in stop     | <input type="checkbox"/> : When PLC is in stop, DIADesigner-AX does NOT refresh the values of I/O channels.<br><input checked="" type="checkbox"/> : When PLC is in stop, DIADesigner-AX still refreshes the values of I/O channels. The outputs are set to the predefined default values if the watchdog detects a malfunction.   |
| Behavior for outputs in stop | <p>The way to deal with the output channels when the controller is in stop:</p> <ul style="list-style-type: none"> <li>■ <b>Keep current values:</b> the current values are retained.</li> <li>■ <b>Set all outputs to default:</b> the default values resulting from the I/O mapping are assigned.</li> <li>■ <b>Execute program:</b> you can control the output values via a program contained in the project, which DIADesigner-AX executes in the stopped state. Enter the program name in the field on the right side.</li> </ul> |
| Always update variables      | Global setting, which defines whether or not DIADesigner-AX updates the I/O variables in the bus cycle task. This setting is effective for I/O variables of the slaves and modules only when their update settings are defined as <b>Disabled</b> .  |

| Item | Description   |
|------|---|
|      | <ul style="list-style-type: none"> <li>■ <b>Disabled (update only if used in a task):</b> DIADesigner-AX updates the I/O variables only if they are used in a task.</li> <li>■ <b>Enabled 1 (use bus cycle task if not used in any task):</b> DIADesigner-AX updates the I/O variables in the bus cycle task if they are not applied in any other tasks.</li> <li>■ <b>Enabled 2 (always in bus cycle task):</b> DIADesigner-AX updates all I/O variables in each cycle of the bus cycle task, regardless of whether they are used or whether they are mapped to an input or output channel.</li> </ul> |

③ Bus Cycle Options

| Item                               | Description  |
|------------------------------------|--|
| <b>Bus cycle task<sup>*1</sup></b> | Task that manages bus cycle. By default, it enters the task cycle by the device-defined options. |

\*1: Before you select **<unspecified>** for the bus cycle task, be aware that the default values given in the device description would take effect. You should therefore check this description. You can define the task with the shortest cycle time as default, but you can equally choose the task with the longest cycle time as default.

④ Additional Settings

| Item   | Description   |
|--|---|
| <b>Generate force variables for IO mapping</b> | The device does NOT support this function.  |
| <b>Enable diagnosis for devices</b>            | <input checked="" type="checkbox"/> : DIADesigner-AX automatically integrates the library CAA Device Diagnosis into the project and creates a hidden function block for each device. If there is already a function block for the device, then either an extended function block is used (e.g. with EtherCAT) or a further function block instance is added. It also contains the general implementation of device diagnosis. |
| <b>Show I/O warnings as errors</b>             | Warnings concerning the I/O configuration are displayed as errors.  |
| <b>Enable symbolic access for IOs</b>          | Symbolic access is activated for I/O.   |


### 4.3.1.7 PLC Shell

Users can use this text-based control monitor for accessing specific information from the controller. Specify device-dependent commands for this and receive responses from the controller in a result window.




### 4.3.1.8 User and Groups

User accounts and groups can be edited here to manage the access to objects and files at runtime. Use the default account (Administrator) and password (Administrator) at first logon and change your password afterwards.



4



- **Toolbar of the tab**

| Item  | Description   |
|---|---|
|  <b>Synchronization</b>      | <p>To enable and disable the synchronization function between the editor and the user management on the device.</p> <ul style="list-style-type: none"> <li>■ If the button is not pressed, then the editor is blank or it displays a configuration that is loaded from the hard disk.</li> <li>■ If the button is pressed, then DIADesigner-AX synchronizes the display in the editor continuously with the current user management on the connected device.</li> <li>■ If the synchronization is activated while the editor contains a user configuration that is not synchronized with the device yet, then a prompt message shall appear with the following options: <ul style="list-style-type: none"> <li>- <b>Upload from the device and overwrite the editor content:</b> the configuration on the device is loaded into the editor, overwriting the current contents.</li> <li>- <b>Download the editor content to the device and overwrite the user management there:</b> the configuration in the editor is transferred to the device and applied.</li> </ul> </li> </ul> |
|  <b>Import from disk</b>   | To import a user management configuration from the file.  |
|  <b>Export to disk</b>     | To save the current configuration of user management as an XML file.  |
|  <b>Export all to disk</b> | To save all user management configurations to the file.   |
| <b>Device user</b>  | User name of the user currently logged in.  |

- **Users**

| Item   | Description  |
|--|--|
|  <b>Add...</b>    | To create a new user account* <sup>1</sup>   |
|  <b>Import...</b> | To select the desired entries and import users into the device user management* <sup>2</sup> |
|  <b>Edit...</b>   | To change the settings of the selected user account  |
|  <b>Delete</b>    | To delete the selected user account  |

- **Groups**


| Item   | Description  |
|--|--|
|  <b>Add...</b>    | To create a new user group* <sup>3</sup>   |
|  <b>Import...</b> | To select the desired entries to import groups into the device user management* <sup>4</sup> |
|  <b>Edit...</b>   | To change the settings of the selected group   |
|  <b>Delete</b>    | To delete the selected group   |

\*1: The **Add User** setting page: click **OK** after finishing the setting.


|   | Item   | Description  |
|---|--|--|
| 1 | <b>Name</b>                                    | Define the user name.  |
| 2 | <b>Default group</b>                           | Select the default group.  |
| 3 | <b>Password</b>                                | Set the password.  |
| 4 | <b>Confirm password</b>                        | Enter the password again to confirm the password.  |
| 5 | <b>Password strength</b>                       | Security levels; from <b>Very weak</b> to <b>Very good</b> .   |
| 6 | <b>Hide password</b>                           | 👁 : The password is shown with asterisks * when it is typed in.<br>👁 : Click 👁 to reveal the password. |
| 7 | <b>Password can be changed by user</b>         | <input checked="" type="checkbox"/> : Password can be changed by the user.                             |
| 8 | <b>Password must be changed at first login</b> | <input checked="" type="checkbox"/> : Password must be changed at first login.                         |

\*2: The **Import Users** setting page: click **OK** after selecting the user from the list.

\*3: The **Add Group** setting page: enter the new group name and select the group members that are to be added for this new group. Then click **OK**.



\*4: The **Import Groups** setting page: click **OK** to import after selecting the group from the list.



### 4.3.1.9 Access Rights

Here you can define the access rights to the AX-8 Series PLC. As in the previous section **Users and Groups**, the users must be members of at least one user group; and, only user groups can be granted certain access rights.

Requirements for displaying the Access Rights page:

- In the DIADesigner-AX options, the Device editor category must be selected to display the Access Rights page. Note that this DIADesigner-AX option can be overwritten by the device description.

The access rights are granted to user groups instead of users:

- The primary requirement is that user management component should be available on the controller.
- Users and user groups are configured in **Users and Groups**.

Device user: Administrator

Synchronized mode: All changes are immediately downloaded to the device.

| Objects  | Add/Remove | Modify | View | Execute |
|--|------------|--------|------|---------|
| <div style="border: 1px solid gray; padding: 5px;"> <p>Runtime objects</p> <ul style="list-style-type: none"> <li>Device</li> <li>Logger</li> <li>PlcLogic                             <ul style="list-style-type: none"> <li>Application                                     <ul style="list-style-type: none"> <li>_C-ModuleIntegration_</li> <li>_Backup&amp;Restore</li> </ul> </li> <li>PlcShell</li> </ul> </li> <li>RemoteConnections                             <ul style="list-style-type: none"> <li>OPCUAServer</li> </ul> </li> <li>Settings</li> <li>UserManagement</li> <li>X509                             <ul style="list-style-type: none"> <li>CreateCertificateSigningRequest</li> <li>CreateSelfSignedCertificate</li> <li>DeleteCertificate</li> <li>ExportCertificate</li> <li>GetStatus</li> <li>ImportCertificate</li> <li>ListCertificates</li> <li>ListUseCases</li> <li>MoveCertificate</li> </ul> </li> </ul> </div> |            |        |      |         |
| <div style="border: 1px solid gray; padding: 5px;"> <p>File system objects</p> <ul style="list-style-type: none"> <li>/</li> <li>Boot</li> <li>cert                             <ul style="list-style-type: none"> <li>export</li> <li>import</li> </ul> </li> <li>Prj                             <ul style="list-style-type: none"> <li>PlcLogic                                     <ul style="list-style-type: none"> <li>ac_persistence</li> <li>alarms</li> <li>Application</li> <li>trend</li> <li>visu</li> <li>_cnc</li> </ul> </li> </ul> </li> <li>System Volume Information</li> </ul> </div>  |            |        |      |         |

- **Toolbar of the tab**

| Item  | Description  |
|---|--|
|  <b>Synchronization</b>  | <p>To enable and disable the synchronization between the editor and the user management on the device.</p> <ul style="list-style-type: none"> <li>■ If the button is not pressed, then the editor is blank or it displays a configuration that is loaded from the hard disk.</li> <li>■ If the button is pressed, then DIADesigner-AX synchronizes the display in the editor continuously with the current user management on the connected device.</li> </ul> |
|  <b>Import from disk</b> | N/A  |
|  <b>Export to disk</b>   | To save the current user management configuration as an XML file.  |
| <b>Device user</b>  | User name of the user currently logged in.   |

- **Objects**


| Description  |
|--|
| <p>In the tree structure, the objects to which actions can be executed at runtime are listed and sorted in the respective groups. In the <b>Rights</b> view, you can configure the access options of the user group for the selected object.</p>   |
| <p>Object source (root node):</p> <ul style="list-style-type: none"> <li>■ <b>Runtime objects &gt; /:</b> in these objects, the rights can be granted to folders of the current execution directory.</li> <li>■ <b>File system objects &gt; Device:</b> in these objects, those with online access are managed and therefore the access rights should be controlled.</li> </ul> <p>Refer to Overview of the objects for the descriptions of the objects.</p> |
| <p>Object groups and objects (indented):</p> <p>E.g. under <b>Device</b>, there are child nodes such as <b>Logger, PlcLogic, Settings, UserManagement</b>.</p>   |

- **Rights**

| Description  |
|--|
| <p>In general, the access rights of the subobjects are inherited from the root object (also Device or /). It implies that any changes of the access rights of a user group to a parent object also apply to its child objects.</p> <p>The table applies to the object that is currently selected in the tree structure. It shows the rights currently configured for each user group on this object.</p> |

**Description**

Synchronized mode: All changes are immediately downloaded to the device.



| Rights        | Add/Remove | Modify | View | Execute |
|---------------|------------|--------|------|---------|
| Administrator | +          | +      | +    | +       |
| Developer     | +          | -      | +    | -       |
| Everyone      | -          | -      | +    | -       |
| Service       | +          | -      | +    | -       |
| test_group    | ×          | ×      | ×    | ×       |
| Watch         | -          | -      | +    | -       |

Applicable actions on the object:

- Add/Remove
- Modify
- View
- Execute

When an object is selected, the table on the right side shows the access rights of the available user groups for the selected object.

The table provides a quick overview of:

- Which access rights are evaluated by an object
- Which user group is assigned with which kind of rights for the object


Meanings of the symbols:

- **+** : access right granted explicitly
- **-** : access right denied explicitly
- **+** : access right granted through inheritance
- **-** : access right denied through inheritance
- **×** : access right not granted or denied explicitly or inherited from the parent object. Inaccessible.
- No symbol: multiple objects with different access rights are selected.

Change the access rights by clicking the symbols for once.


● **Overview of the objects**

- Runtime objects > Device




- Logger:

Logger in the Access Rights tab is read-only as it is used online. Therefore, the only right that can be granted is the View action.




- PlcLogic:



All IEC applications are inserted here automatically as subobjects during download. This allows specific control of online access for application. Access rights can be assigned centrally over all applications in the PlcLogic. The Administrator and Developer user groups have full access to the IEC applications while the Service and Watch user groups only have read access (e.g. read-only value monitoring).

- Application:



The following table lists the actions affected when specific access rights are granted for an IEC application.

x : access not granted


● : access granted

|                    | Operation                | Access rights |         |        |      |
|--------------------|--------------------------|---------------|---------|--------|------|
|                    |                          | Add/Remove    | Execute | Modify | View |
| <b>Application</b> | Login                    | ●             | ●       | ●      | x    |
|                    | Create                   | x             | ●       | ●      | ●    |
|                    | Create child object      | x             | ●       | ●      | ●    |
|                    | Delete                   | x             | ●       | ●      | ●    |
|                    | Download / online change | x             | ●       | ●      | ●    |

|                           |   |   |   |   |
|---------------------------|---|---|---|---|
| Create boot application   | X | • | • | • |
| Read variable             | • | • | • | X |
| Write variable            | • | • | X | X |
| Force variable            | • | • | X | X |
| Set and delete breakpoint | • | X | X | • |
| Set next statement        | • | X | X | • |
| Read call stack           | • | • | • | X |
| Single cycle              | • | X | • | • |
| Switch on flow control    | • | X | X | • |
| Start / Stop              | • | X | • | • |
| Reset                     | • | X | • | • |
| Restore retain variables  | • | X | • | • |
| Save retain variables     | • | • | • | X |

- PlcShell:

Only Modify is granted here. This means that only when the Modify right has been granted to a user group can the PLC shell commands be used.



- RemoteConnections:

Additional external connections to the AX-8 Series PLC can be configured under this node. In general, access to OPC UA server can be configured here.




- Settings:

This is an online access to the configuration settings of the AX-8 Series PLC. By default, access to Modify is granted only to the administrator.



- UserManagement:

This is an online access to the user management of AX-8 Series PLC. By default, access to read / write is granted only to the administrator.



- X509:



This manages the online access of the X.509 certificate. There are two types of accesses:


1. Read (View)
2. Write (Modify)

Each operation is assigned one of these two access rights and is inserted as the child object under X509.

Therefore, access of each operation can be further fine-tuned.

■ File system objects > /

All folders in the execution path of the AX-8 Series PLC are inserted under the file system object /. This allows you to grant specific rights to each folder of the file system.




### 4.3.1.10 Symbol Rights


Here you can define the access rights of different user groups to individual symbol sets available on the AX-8 Series PLC.

Requirements:

1. User management must be set up on the controller.
2. Download a project to AX-8 Series PLC and make sure Symbol Sets are defined in DIADesigner-AX Object.
3. User groups have the data access right for logging on to the AX-8 Series PLC.



In the **Symbol Sets** view, all symbol sets are listed under Application whose definition and applications are downloaded to the AX-8 Series PLC altogether.




In the **Rights** view, it lists the user groups defined in the user management of the controller. Select a symbol set to check the corresponding access rights.

➕ : access granted

➖ : inaccessible not granted

Switch between ➕ and ➖ by double-clicking the symbol.




Click  to save the current configuration to an XML file. The file type is Device symbol management files (\*.dsm). Click  to read the file of the same type from the computer.

### 4.3.1.11 System Settings

Here you can set up the system settings<sup>\*1</sup> for the AX-8 Series PLC. Before setting up, make sure that DIADesigner-AX is successfully connected to the controller. Refer to **section 4.2.1.1** for establishing the connection.

\*1: The tab is called **Runtime Clock Configuration** in DIADesigner-AX V1.0.0 while is modified as **System Settings** in V1.1.0 as new function (IP Address setup) is added.

Go to **Device > System Settings**.



| Item                        | Description  |
|-----------------------------|--|
| <b>Runtime Clock</b>        | <ul style="list-style-type: none"> <li>■ PLC Time: current date and time on the controller. Click <b>Read PLC Time</b> to update.</li> <li>■ Date: click <b>Write PLC Time</b> to write the date on DIADesigner-AX (PC) into the controller.</li> <li>■ Time: click <b>Sync with Local Time</b> to write the time on DIADesigner-AX (PC) into the controller.</li> </ul> |
| <b>Time Zone</b>            | <ul style="list-style-type: none"> <li>■ PLC Timezone: click <b>Read Timezone</b> to update the current time zone of the controller.</li> <li>■ Timezone: click <b>Write Timezone</b> to write the time zone on DIADesigner-AX (PC) into the controller.</li> </ul>  |
| <b>Network<sup>*1</sup></b> | <ul style="list-style-type: none"> <li>■ <input checked="" type="checkbox"/> Apply IP settings while download: the IP of the controller is updated as the configured IP address while download.</li> <li>■ GLAN 1 &amp; GLAN 2: select to switch to the page you are looking for.</li> </ul>   |

| Item                           | Description  |
|--------------------------------|--|
|                                | <ul style="list-style-type: none"> <li>■ Enable Gateway and DNS Setting: the settings for Default gateway, Preferred DNS server and Alternate DNS server are available.</li> <li>■ IP Address Mode: static IP or DHCP.</li> <li>■ IP Setting: IP address / Subnet mask / Default gateway can be set by users.</li> <li>■ DNS Setting: users can select <b>Obtain DNS server address automatically</b> or define your own DNS server addresses.</li> <li>■ Read from PLC: read and update the IP address from the active controller.</li> </ul> |
| <b>Project ID<sup>*2</sup></b> | If Project ID status is active, the setting must be completed before downloading projects. Click <b>Set Project ID</b> to activate the feature.  |
| <b>Retain Settings</b>         | <ul style="list-style-type: none"> <li>■ <b>Original mode</b>: keep original retain setting of AX-8 Series PLC.</li> <li>■ <b>%M mode</b>: set up the %M address by giving the values of Start Memory Address and End Memory Address.</li> <li>■ <b>Clear</b>: clear all the %M addresses assigned to the variables.</li> </ul>  |

\*1:

Network parameter settings are available only when the DDF on AX-8 Series PLC is V1.0.1.0 or above.

AX-8 Series PLC support two Ethernet ports and the settings are illustrated as follows:

Take GLAN 1 for instance, when **Enable Gateway and DNS Setting** is checked, Gateway and DNS are configured based on the value set on this page. Meanwhile, the configuration is not available on the other tab, which is GLAN 2.

Conversely, if **Enable Gateway and DNS Setting** is left unchecked, the fields below are greyed out and configuration is unavailable.

Network

GLAN1 GLAN2

Enable Gateway and DNS Setting

IP Address Mode: Static

IP address: 192 . 168 . 0 . 10

Subnet mask: 255 . 255 . 255 . 0

Default gateway: 0 . 0 . 0 . 0

Obtain DNS server address automatically

Use the following DNS server addresses:

Preferred DNS server: 0 . 0 . 0 . 0


Alternate DNS server: 0 . 0 . 0 . 0

Read from PLC

\*2: Refer to **Chapter 8.2 of DIADesigner-AX Software Manual** for Project ID operation.

### 4.3.1.12 System Parameters

You can set up the parameters for the controller in the **System Parameters** tab but must note that editing during online monitoring is not supported.



1. I/O module CONFIG by Manual/Max when Power On: to set the configuration of I/O modules.
  - Manual (default): the actual module placement should be consistent with the configuration set in HWCONFIG for the PLC to run normally.
  - Max: set the maximum number for the module placement. An alarm pops up if the actual I/O module placement is larger than the maximum number defined.
2. CPU module Stop when I/O Module No Response: to set whether the CPU and other modules which function normally will continue to run or not when there is any extension module out of control or disconnected with no response.
  - Stop (default): the CPU module stops and reports error. Power-on reset is required for the CPU module to again function normally.
  - Keep RUN: the CPU module and other normal modules keep running.
3. CPU module Stop when I/O Module Occurred Error: to set the solution when minor errors occur in extension modules.
  - Stop: the CPU module stops and reports an error. The CPU module is restarted after the error is cleared.
  - Keep RUN (default): the CPU module keeps running with the warning messages recorded.
4. Select Action when 24Vdc Input unstable: to set the solution to power failure for 24Vdc input.
  - Continue Running when power stable (default): the CPU stops automatically till the power supply is stable to run again.
  - Into Error Status: the CPU stops with ERROR LED blinking; the CPU stays in STOP even after the power supply becomes stable again.
5. Show Battery Low Voltage Error: to set whether to show an alarm or not when the lithium battery is of low voltage or not installed.
  - Disable: there is no alarm when the lithium battery is of low voltage or not installed.
  - Enable (default): an alarm is displayed when the lithium battery is of low voltage or not installed

### 4.3.1.13 Task Deployment

In the following table it displays the inputs / outputs and their assignments to the defined tasks as well as bus cycle task. The information can be used for troubleshooting when the execution is below expectations. The contents are refreshed only after the project is compiled and downloaded to the CPU.


| I/O Deployment for Tasks |         | Channel   | EtherCAT_Task (0)        | MainTask (1) |
|--------------------------|---------|---|--------------------------|--------------|
| <b>I/O channels</b>      |         |   |                          |              |
| BuiltIn_DIO              |         |   |                          |              |
| %IB0                     | In0     |       | <input type="checkbox"/> |              |
| %IX0.0                   | X0      |       | <input type="checkbox"/> |              |
| %IX0.1                   | X1      |       | <input type="checkbox"/> |              |
| %IX0.2                   | X2      |       | <input type="checkbox"/> |              |
| %IX0.3                   | X3      |       | <input type="checkbox"/> |              |
| %IX0.4                   | X4      |       | <input type="checkbox"/> |              |
| %IX0.5                   | X5      |       | <input type="checkbox"/> |              |
| %IX0.6                   | X6      |       | <input type="checkbox"/> |              |
| %IX0.7                   | X7      |       | <input type="checkbox"/> |              |
| %QB0                     | Out0    |       | <input type="checkbox"/> |              |
| %QX0.0                   | Y0      |     | <input type="checkbox"/> |              |
| %QX0.1                   | Y1      |   | <input type="checkbox"/> |              |
| %QX0.2                   | Y2      |   | <input type="checkbox"/> |              |
| %QX0.3                   | Y3      |   | <input type="checkbox"/> |              |
| %QX0.4                   | Y4      |   | <input type="checkbox"/> |              |
| %QX0.5                   | Y5      |   | <input type="checkbox"/> |              |
| %QX0.6                   | Y6      |   | <input type="checkbox"/> |              |
| %QX0.7                   | Y7      |   | <input type="checkbox"/> |              |
| BuiltIn_Pulse_Encoder    |         |   |                          |              |
| %ID1                     | Counter | <input type="checkbox"/>  | <input type="checkbox"/> |              |
| %QX1.0                   | Reset   | <input type="checkbox"/>  | <input type="checkbox"/> |              |

 = Bus cycle task

|   |  |
|---|--|
|  | The task is defined as Bus cycle task in the PLC settings. |
|  | Inputs or outputs that are written or read by the task.    |


### 4.3.1.14 Status

Information about the status of the controller can be found here. For example, **Running**, **Stopped**, and other specific diagnostic messages from the respective device. It also includes information about card used and internal bus system.



### 4.3.1.15 Information

Here you can find general information that originates from the device description file: name, vendor, categories, version, order number, description, and so on.



## 4.4 Data Type and Variables

### 4.4.1 Data Type

| Data Type        | Minimum Value   | Maximum Value   | Data Width |
|------------------|---|---|------------|
| BOOL             | FALSE   | TRUE  | 1-bit      |
| BYTE             | 0   | 255   | 8-bit      |
| WORD             | 0   | 65535   | 16-bit     |
| DWORD            | 0   | 4294967295  | 32-bit     |
| LWORD            | 0   | $2^{64}-1$  | 64-bit     |
| SINT             | -128  | 127   | 8-bit      |
| USINT            | 0   | 255   | 8-bit      |
| INT              | -32768  | 32767   | 16-bit     |
| UINT             | 0   | 65535   | 16-bit     |
| DINT             | -2147483648   | 2147483647  | 32-bit     |
| UDINT            | 0   | 4294967295  | 32-bit     |
| LINT             | $-2^{63}$   | $2^{63}-1$  | 64-bit     |
| ULINT            | 0   | $2^{64}-1$  | 64-bit     |
| REAL             | -3.402823E+38   | 3.402823E+38  | 32-bit     |
| LREAL            | -1.7976931348623157E+308                              | 1.7976931348623157E+308                                     | 64-bit     |
| TIME             | T#0ms   | T#49d17h2m47s295ms  | 32-bit     |
| LTIME            | LTIME#0ns   | LTIME#213503d23h34n33s<br>709ms551us615ns                   | 64-bit     |
| TIME_OF_DAY(TOD) | TOD#00 : 00 : 00.000                                  | TOD#23 : 59 : 59.999  | 32-bit     |
| DATE             | D#1970-1-1<br>(01/01/70)                              | DATE#2106-2-7<br>(February 07 · 2106)                       | 32-bit     |
| DATE_AND_TIME    | DT#1979-1-1-00 : 00 : 00<br>(01/01/1970 00 : 00 : 00) | DT#2106-2-7-6 : 28 : 15<br>(February 07 · 2106 6 : 28 : 15) | 32-bit     |
| STRING           | ASCII format (8-bit): up to 255 characters            |   |            |
| WSTRING          | Unicode format (16-bit): no limit on the length       |   |            |

## 4.4.2 Variables

### Rules for variable identifiers:

- No spaces or special characters.
- Not case-sensitive (e.g. Var0 and VAR0 are deemed as the same variable).
- No consecutive underscore characters (e.g. b\_Var0 is acceptable but b\_\_Var0 is not permitted).

### Rules for multiple use of identifier:

- Local variable cannot be declared more than once.
- Local variables have priority over global variables. If they share the same name, the local variable is given precedence within the POU than the global variable.
- Variables with the same name can be declared in different global variable list (e.g. globe\_list1.bvar and globe\_list2.bvar can co-exist in two different global variable lists).

4

### Comments:

- Single comment: the symbol // indicates a single comment. For example: // Variable Define.
- Multiple comments: the symbol (\* XX : XX \*) indicates multiple comments from XX to XX. For example, (\*Variable Define : Variable Define\*).

### 4.4.2.1 Declaration of Variables

In DIADesigner-AX projects, variables are declared using the following methods.

Syntax: <Variable Name> : <Data Type> := <Initialization> ;

Example:

```
VAR
  bVar      :   BOOL   ;
  byVar     :   BYTE  := 1 ;
  wVar      :   WORD  := 16#0001 ;
  todVar    :   TOD   := TOD#02:30:15.100;
END_VAR
```

Array

Syntax: <Variable Name> : ARRAY[0..N] OF <Data Type>

Example:

```
VAR
  byVar_Array :   ARRAY[0..10] OF BYTE ;
  wVar_Array  :   ARRAY[0..30] OF WORD ;
  rVar_Array  :   ARRAY[0..50] OF REAL ;
END_VAR
```

### 4.4.2.2 Address Assignment

In AX-8 Series PLC, memory areas are divided into three ranges: I (input memory range), Q (output memory range) and M (flag memory range). You can use specific character strings to express memory position and size. There are two modes for non-volatile memory on AX-8 Series PLC, which can be configured in CPU parameter settings. When set to Mdev mode, the value of %M is retained; if not, it is the value of Retain & Persistent being retained.

Syntax: %<Memory Area Prefix><Size Prefix><Memory Position>

| Memory Area | Description              | Range      |
|-------------|--------------------------|------------|
| I           | Input Memory Range       | 128 KB     |
| Q           | Output Memory Range      | 128 KB     |
| M           | Flag Memory Range        | 5 MB       |
| --          | Non-volatile Memory Size | 96 KB      |
| Size Prefix | Data Type                | Data Width |
| X           | --                       | 1-bit      |
| B           | Byte                     | 8-bit      |
| W           | Word                     | 16-bit     |
| D           | DWord                    | 32-bit     |
| L           | LWord                    | 64-bit     |

- **Memory Area**

The numbering used for addressing the memory position depends on the target system. Before specifying the address value in the memory area, you need to know the corresponding memory-mapped position to prevent overlap of memory ranges. See the table below for reference.

| Memory Area |             |             |             |             |             |            |           |
|-------------|-------------|-------------|-------------|-------------|-------------|------------|-----------|
| X0.63~X0.56 | X0.55~X0.48 | X0.47~X0.40 | X0.39~X0.32 | X0.31~X0.17 | X0.23~X0.16 | X0.15~X0.8 | X0.7~X0.0 |
| X7.7~X7.0   | X6.7~X6.0   | X5.7~X5.0   | X4.7~X4.0   | X3.7~X3.0   | X2.7~X2.0   | X1.7~X1.0  | X0.7~X0.0 |
| B7          | B6          | B5          | B4          | B3          | B2          | B1         | B0        |
| W3          |             | W2          |             | W1          |             | W0         |           |
| D1          |             |             |             | D0          |             |            |           |
| L0          |             |             |             |             |             |            |           |

## ● Example


| Address                                   | Description   |
|---|---|
| %QX7.5                                    | Single bit address of the output bit 7.5                                    |
| %IW215                                    | Word address of the input word 215  |
| %QB7                                      | Byte address of the output byte 7   |
| %MD48                                     | Address of a double word at memory position 48 in flag memory               |
| VAR<br>wVar0 AT %IW0 : WORD ;<br>END_VAR  | Variable declaration with address information of an input word              |
| VAR<br>bVar0 AT IX7.5 : BOOL ;<br>END_VAR | Boolean variable declaration with address information of an input bit X7.5. |

### 4.4.2.3 Variables



- **Global Variables**

If a variable is declared in a POU, it is a local variable that can only be used within the POU. However, when a variable is declared in the global variable list, it is a global variable and can be used in any POU.

**Add Global Variable List:**



4



● **Constant Variables**

You can declare a variable as a constant variable. Constant variables can be accessed as read-only without assigning an initialization value.

**Declaration of Constant Variables:**

```

VAR CONSTANT
    pi : REAL := 3.14159 ;
END_VAR
    
```

- **Retain Variables**

You can declare a variable as retentive or use persistent variable directly. Refer to the table below for comparisons among variables, retain variables and persistent variables.

|                            | Initialize |            |            |          |              |
|----------------------------|------------|------------|------------|----------|--------------|
|                            | Reboot PLC | Reset warm | Reset cold | Download | Reset origin |
| <b>Variable</b>            | O          | O          | O          | O        | O            |
| <b>Retain Variable</b>     | X          | X          | O          | O        | O            |
| <b>Persistent Variable</b> | X          | X          | X          | X        | O            |

**Declaration of Retain Variables:**


```

VAR RETAIN
  bVar : BOOL ;
  byVar : BYTE ;
  wVar : WORD ;
END_VAR


```


To create persistent variable, you can declare **RETAIN PERSISTENT**, **PERSISTENT RETAIN** and **PERSISTENT** in Persistent Variable Object for the same outcome.

**Add Persistent Variable List:**




4






If it is required to declare a local variable as persistent, you have to add the variable instance path to the persistent variable list.



### 4.4.2.4 User-defined Data Type

You can create your own data type, DUT (Data Type Unit) or UDT (User-defined Data Type), by clicking **Add Object** and selecting **DUT**. There are four data types that can be created: Structure, Enumeration, Alias and Union.

**Add DUT:**



- **Structure**

A structure is a compound data type used for grouping simple data types or other compound data types.

**Syntax:**

TYPE <Structure Name>:

STRUCT

<Variable Declaration 1>

...

<Variable Declaration n>

END\_STRUCT

END\_TYPE

**Example:**

```


TYPE DUT :
STRUCT
    bVar    :    BOOL    ;
    wVar    :    WORD    ;
    iVar_Array :    ARRAY[0..2]OF INT    ;
END_STRUCT
END_TYPE
    
```

**Application:**

```

1  PROGRAM PLC_PRG
2
3  VAR
4      byVar2 AT %QX7.5 : BOOL ;
5      DUT_Var :DUT := (bVar:=TRUE,wVar:=12,iVar_Array:=[1,2,3]);
6  END_VAR
7
8
9  1  DUT_Var.bVar:=FALSE;
10 2  DUT_Var.iVar_Array[1]:=123;

```



- **Enumeration**

An enumeration is used to map a set of names to numeric values. Enumerated data types make code more self-documenting and program listing more readable.

**Syntax:**

TYPE <Enumeration Name>:

```

(
    <First Component Declaration>:= Component Declaration,
    ... ,
    < Last Component Declaration >:= Component Declaration
) <Basic Data Type> := Default Variable Initialization;
END_TYPE

```

**Example:**

```

TYPE Enumeration_0 :
(
    GREEN := 0,
    YELLOW:=3,
    RED:=8
) INT:=YELLOW;
END_TYPE

```

- **Alias**

Alias is a scalar data type for a variable that can save a single value and self-define the data type.

**Example:**

```
TYPE <Alias Name> : STRING(20); END_TYPE
```

- **Union**

Union is a data structure that contains different data types. All components share the same amount of memory.

**Syntax:**

```
TYPE <Union Name>:
```

```
UNION
```

```
    <Variable Declaration 1>
```

```
    ...
```

```
    <Variable Declaration n>
```

```
END_UNION
```

```
END_TYPE
```

**Example:**

```
TYPE DUT_Union :  
UNION  
    unVar0:WORD;  
    unVar1:DWORD;  
END_UNION  
END_TYPE
```

#### 4.4.2.5 Timing for the Variable being Cleared to Zero

For different types of variables, the timings to clear the variables to zero are various. Refer to the table below for the timings on different occasions\*1.

● = value retained

○ = value cleared to zero

| Action        | VAR | VAR Retain | VAR Retain Persistent |
|---------------|-----|------------|-----------------------|
| Online Change | ●   | ●          | ●                     |
| Reboot PLC    | ○   | ●          | ●                     |
| Reset Warm    | ○   | ●          | ●                     |
| Reset Cold    | ○   | ○          | ●                     |
| Download      | ○   | ○          | ●                     |
| Reset Origin  | ○   | ○          | ○                     |

\*1: The default value takes effect when value retention feature is unavailable.

#### 4.4.2.6 Timing for the Default Value to be Valid

● = invalid

○ = valid

| Action        | VAR | VAR Retain | VAR Retain Persistent |
|---------------|-----|------------|-----------------------|
| Online Change | ●   | ●          | ●                     |
| Reboot PLC    | ○   | ●          | ●                     |
| Reset Warm    | ○   | ●          | ●                     |
| Reset Cold    | ○   | ○          | ●                     |
| Download      | ○   | ○          | ●                     |

## 4.5 Task

### 4.5.1 Task Configuration

Task is used for controlling and executing the program blocks (POUs) in the PLC. You can define a task with its name, priority and the exact condition that initiates the commencement of the task. This condition is defined either by time (cyclic-interval, freewheeling) or by the occurrence of an internal or external event to initiate the task.

A task calls one or multiple program blocks (POUs). The sequence of task execution depends on the condition and priority defined. It is also possible to configure a watchdog for each task.

Rules for the order in which the defined tasks are processed:

- If the task condition is satisfied, then the system starts processing the task.
- If several tasks satisfy the condition for processing at the same time, then tasks with the highest priority\*<sup>1</sup> are processed first.
- If several tasks with the same priority level satisfy the condition for processing at the same time, then the system processes the task which has been waiting for the longest time first.
- The program calls are processed in the order they appear in the configuration dialog of the task. If it happens that a POU name in the project is identical with one in the library used, the POU in the project takes precedence to be executed.

\*1: Set the priority level from 0 to 31. A set number closer to 0 has a higher priority.

#### 4.5.1.1 Task Type


There are five task types:

- **Cyclic Task**  
The system processes the task in cycles. The execution cycle of the task is defined in the Interval input field.
- **Event Task**  
The system starts processing the Event Task as soon as the global variable defined in the Event input field contains a rising edge. The variable should be a Boolean variable.
- **External Task**  
The system processes the task once as soon as the defined built-in input contains a rising edge.
- **Freewheeling Task**  
When the controller starts running, the system begins to process the Freewheeling Task automatically in a continuous loop till the controller stops.
- **Status Task**  
The system starts Status Task processing as soon as the variable defined in the Event input field yields the Boolean value TRUE.

### 4.5.1.2 Bus Cycle Task

The system processes the task when its condition is satisfied. The priority level is set from 0 to 31 and the number closer to 0 has higher priority. The system processes the task in the order of Task Group in Task Configuration.

#### Sequence of Bus Cycle Task



Task 1: Priority = 1, Bus cycle Task, Cyclic Task

Task 2: Priority = 3, Event Task


Task 3: Priority = 5, Freewheeling Task

- ① The condition for starting Task 1 is met; Task 1 starts.
  - ② Task 1 is completed and the data from I/O buffer is exchanged with the I/O channel (physical hardware). Task 3 starts.
  - ③ The condition for starting Task 2 is met and Task 2 has higher priority than Task 3 does. Thus Task 2 starts whereas Task 3 halts.
  - ④ The condition for starting Task 1 is met and Task 1 has higher priority than Task 2 does. Thus Task 3 starts whereas Task 4 halts.
  - ⑤ Task 1 is completed and the I/O data from buffer is exchanged with the I/O channel (physical hardware). Task 2 starts again.
  - ⑥ Task 2 is completed and the Task 3 starts again.
- ① Bus Cycle: The messages are normally sent on the bus in this task. Other tasks copy only the I/O data from an internal buffer that is exchanged only with the physical hardware in the bus cycle task.

### 4.5.1.3 Watchdog

If the time for task execution exceeds the time set for watchdog, then the task is halted with an error status.

To enable watchdog:



\*1: several consecutive timeouts:

sensitivity = 0, watchdog timeout = time x 1

sensitivity = n, watchdog timeout = time x n

#### 4.5.1.4 Motion Instructions for Each Type of Task

The table below introduces the motion instructions for different task types. **V** means the motion instruction is available for that task type.

- Synchronous axes\*<sup>1</sup>

| Classification                                    | Instruction              | Task Type |              |                       |
|---|--------------------------|-----------|--------------|-----------------------|
|   |                          | Cyclic    | Freewheeling | Bus Cycle<br>EtherCAT |
| <b>Motion<br/>Control<br/>Function<br/>Blocks</b> | MC_Home                  |           |              | V                     |
|   | MC_Stop                  |           |              | V                     |
|   | MC_Halt                  |           |              | V                     |
|   | MC_MoveAbsolute          |           |              | V                     |
|   | MC_MoveRelative          |           |              | V                     |
|   | MC_MoveAdditive          |           |              | V                     |
|   | MC_MoveSuperImposed      |           |              | V                     |
|   | MC_CamIn                 |           |              | V                     |
|   | MC_CamOut                |           |              | V                     |
|   | MC_MoveVelocity          |           |              | V                     |
|   | MC_PositionProfile       |           |              | V                     |
|   | MC_VelocityProfile       |           |              | V                     |
|   | MC_AccelerationProfile   |           |              | V                     |
|   | MC_Jog                   |           |              | V                     |
|   | MC_GearIn                |           |              | V                     |
|   | MC_GearOut               |           |              | V                     |
|   | MC_GearInPos             |           |              | V                     |
|   | MC_Phasing               |           |              | V                     |
|   | DMC_TorqueControl        |           |              | V                     |
|   | DMC_VelocityControl      |           |              | V                     |
|   | DMC_MoveLinearAbsolute   |           |              | V                     |
|   | DMC_MoveLinearRelative   |           |              | V                     |
|   | DMC_MoveCircularAbsolute |           |              | V                     |
|   | DMC_MoveCircularRelative |           |              | V                     |
|   | DMC_GroupStop            |           |              | V                     |
|   | DMC_GroupHalt            |           |              | V                     |
| DMC_Home_P  |                          |           | V            |                       |
| DMC_GroupInterrupt                                |                          |           | V            |                       |




- Positioning axes

| Classification                                    | Instruction               | Task Type |              |                       |
|---|---------------------------|-----------|--------------|-----------------------|
|   |                           | Cyclic    | Freewheeling | Bus Cycle<br>EtherCAT |
| <b>Motion<br/>Control<br/>Function<br/>Blocks</b> | MC_Halt_DML               |           |              | V                     |
|   | MC_Home_DML               |           |              | V                     |
|   | MC_MoveAbsolute_DML       |           |              | V                     |
|   | MC_MoveRelative_DML       |           |              | V                     |
|   | MC_MoveVelocity_DML       |           |              | V                     |
|   | MC_Stop_DML               |           |              | V                     |
| <b>Instructions<br/>for<br/>Management</b>        | MC_Power_DML              |           |              | V                     |
|   | MC_ReadBoolParameter_DML  |           |              | V                     |
|   | MC_ReadParameter_DML      |           |              | V                     |
|   | MC_ReadStatus_DML         |           |              | V                     |
|   | MC_Reset_DML              |           |              | V                     |
|   | MC_WriteBoolParameter_DML |           |              | V                     |
|   | MC_WriteBoolParameter_DML |           |              | V                     |
|   | MC_ChangeAxisConfig_DML   |           |              | V                     |
|   | MC_ReinitDrive_DML        |           |              | V                     |
|   | MC_SetOpmode_DML          |           |              | V                     |
| MC_StartupDrive_DML                               |                           |           | V            |                       |

## 4.6 Recipe Manager

With Recipe Manager, you can import recipe files and export specific parameters by using **RecipeManCommands** from the function block **Recipe\_Management.library**.

- **Add Recipe Manager:**




Add Recipe Manager




Create a Recipe Manager



Name




● Add Recipe Definition:



4




### 4.6.1 Recipe Manager




4

| Item  | Description  |
|---|--|
| <b>Storage type</b>                                 | The file format to save recipe files. You can choose between Textual and Binary.   |
| <b>File path</b>                                    | The path to save recipe files.<br>Example: If choosing to save files in AllRecipes, the path would be PlcLogic/AllRecipes.         |
| <b>File extension</b>                               | The extension of the file .<file extension><br>The naming format of extension files <recipe>.<recipe definition>.<file extension>. |
| <b>Separator</b>                                    | The separators between each value in recipe files.   |
| <b>Available Columns</b><br><b>Selected Columns</b> | Define content and order of the recipe files.  |
| <b>Save as Default</b>                              | Apply the setting to all the recipe managers in the project.   |
| <b>Up</b>   | Move the item selected in the Selected Columns upward.   |
| <b>Down</b>   | Move the item selected in the Selected Columns downward.   |



| Item  | Description  |
|---|--|
| <b>Recipe Management in the PLC</b>   | <input checked="" type="checkbox"/> : Recipe Manager is activated.   |
| <b>Save Recipe</b>  |  |
| <b>Save recipe changes to recipe files automatically</b>                            | <input checked="" type="checkbox"/> : Recipe files are updated automatically while downloading projects. In case that Recipe changes, it is auto-saved to the recipe file.   |
| <b>Load Recipe</b>  |  |
| <b>Load only by exact match of variable list</b>                                    | <input checked="" type="checkbox"/> : The variables in the file must be in the same order as in the variable list while loading the recipe. Otherwise, the recipe cannot be loaded.<br>(Additional entries at the end are ignored.)    |
| <b>Load matching variables by variable name</b>                                     | <input checked="" type="checkbox"/> : Only variables with matching variable names from the recipe file are loaded, even though the order of variables or the contents in Name column do not match to the setting in the variable list. |
| <b>Write Recipe</b>   |  |
| <b>Limit the variable to min/max when recipe value is out of the range</b>          | In case that the recipe value is out of the min/max range, the maximum or minimum value would be written to the corresponding variables in the controller.   |
| <b>Do not write to a variable when the recipe value is out of the min/max range</b> | Prevent a value from being written to the controller if the recipe contains a value that is out of the value range.  |

### 4.6.2 Recipe Definition




4

| Parameter                                    | Description  |
|--|--|
| <b>Variable</b>                              | In the table, you can specify any variable including those self-defined in a POU.  |
| <b>Type</b>                                  | This automatically displays the relevant data type of the specified variable.  |
| <b>Name</b>                                  | You can define names of variables for inspection and comparison by Load Recipe.  |
| <b>Comment</b>                               | Additional information.  |
| <b>Minimal Value</b><br><b>Maximal Value</b> | You can specify the maximum and minimum values to be written to this variable. When the recipe value is out of range, the controller would determine whether to write the value to the variable according to the recipe manager. |
| <b>Current Value</b>                         | The current value would be displayed in online mode.   |


● **Add a New Variable:**

Enter the variable name in the blank or double-click the blank to open **Input Assistant** and choose the target variable.




● Add a New Recipe:

Right-click the page to select **Add a New Recipe**.



● The recipe file created in the controller



### 4.6.3 RecipeManCommands

The function block **RecipeManCommands** from **Recipe\_Management.library** provides several avenues for users to load recipe files or export recipe files from the controller.

| RecipeManCommands      | Description   |
|------------------------|---|
| LoadAndWriteRecipe     | Load the default recipe file and write the recipe to variables in the controller.                             |
| LoadFromAndWriteRecipe | Load the specified recipe file and write the recipe to variables in the controller.                           |
| ReadAndSaveAs          | Save the variables of the controller to the target file.  |
| ReadAndSaveRecipe      | Read the current PLC variables into the default recipe file.  |
| ReadAndSaveRecipeAs    | Read the current PLC variables into the default recipe file and save the recipe to the specified recipe file. |

## 4

### ● Example 1

In this example, we add **startDone** event through **Add Event Handler**. And with **LoadAndWriteRecipe**, the recipe **Case1** from the recipe definition **Recipes\_01** is automatically loaded to the corresponding variables in the controller as soon as the controller's status turns from **STOP** to **RUN**.

POU: Start\_Done


```

1  FUNCTION Start_Done : DWORD
2  VAR_IN_OUT
3  EventPm : CmpApp . EVTPARAM_CmpApp ;
4  END_VAR
5  VAR
6  FB0 : RecipeManCommands ;
7  END_VAR
8
9
10 FB0 . LoadAndWriteRecipe ( RecipeDefinitionName := 'Recipes_01' , RecipeName :=
11 'Case1' ) ;
12

```

- **Example 2**

In this example, we use **ReadAndSaveRecipe** and **ReadAndSaveAs** respectively to read the current PLC values into the default recipe and the specified recipe file.



POU: PLC\_PRG

```

1  PROGRAM PLC_PRG
2  VAR
3      iVar : INT ;
4      dwVar, dw_Return : DWORD ;
5      udi_Return : UDINT ;
6      bVar0, bVar1 : BOOL ;
7      FB1 : RecipeManCommands ;
8  END_VAR
9
10
11
12
13
14
15
16

```

---

```

1  IF bVar0 THEN
2      %MW3 := 50 ;
3      iVar := 60 ;
4      dwVar := 70 ;
5      udi_Return := FB1.ReadAndSaveRecipe ( RecipeDefinitionName :=
6      'Recipes_01', RecipeName := 'Case1' ) ;
7      bVar0 := FALSE ;
8  END_IF
9
10 IF bVar1 THEN
11     %MW3 := %MW3 + 10 ;
12     iVar := iVar + 20 ;
13     dwVar := dwVar + 30 ;
14     udi_Return := FB1.ReadAndSaveAS ( RecipeDefinitionName := 'Recipes_01',
15     FileName := 'POU_Variable.txtrecipe' ) ;
16     bVar1 := FALSE ;
17 END_IF

```

- Below are the files and contents generated by the controller when bVar0 and bVar1 are set as ON.

| Name                        | Size     | Modified          |
|-----------------------------|----------|-------------------|
| ..                          |          |                   |
| visu                        |          |                   |
| trend                       |          |                   |
| alarms                      |          |                   |
| ac_persistence              |          |                   |
| _cnc                        |          |                   |
| Application                 |          |                   |
| Case1.Recipes_01.txtrecipe  | 89 bytes | 2000/1/1 上午 08:34 |
| Case2.Recipes_01.txtrecipe  | 92 bytes | 2000/1/1 上午 08:33 |
| Case20.Recipes_02.txtrecipe | 50 bytes | 2000/1/1 上午 08:33 |
| Case21.Recipes_02.txtrecipe | 50 bytes | 2000/1/1 上午 08:33 |
| POU_Variable.txtrecipe      | 90 bytes | 2000/1/1 上午 08:34 |

Case1.Recipes\_01.txtrecipe - Notepad

```

File Edit Format View Help
%MW3:=50:=WORD:::==
PLC_PRG.iVar:=60:=INT:::==
PLC_PRG.dwVar:=70:=DWORD:::==

```

POU\_Variable.txtrecipe - Notepad

```

File Edit Format View Help
%MW3:=60:=WORD:::==
PLC_PRG.iVar:=80:=INT:::==
PLC_PRG.dwVar:=100:=DWORD:::==

```

**MEMO**

---

# Chapter 5 Hardware Configuration

## Table of Contents


5.1 Hardware Configuration .....5-2  
5.1.1 Environment of Hardware Configuration ..... 5-2

## 5.1 Hardware Configuration

Hardware Configuration is the tool in DIADesigner-AX for hardware development. It provides functions including parameter settings for CPU and modules. This chapter provides introduction to the abovementioned functions.


### 5.1.1 Environment of Hardware Configuration

Double-click  **Hardware Configuration** on the Device pane to open the **Hardware Configuration [Device]** window as the image shown below.




- ① Hardware Configuration [Device]: this is the main working area for system configuration and settings.
- ② Product List Editor: here lists all the supported modules for the selected CPU.

Click  in the top left corner to see the current configuration including information such as the added module names, total width of the connected modules, current consumption and so on.





Use in the top right corner to rearrange the device image for better viewing experience and easier operation. Below is the display when the controller is in connection.



**MEMO**

---

## Chapter 6 Network Configuration

### Table of Contents

- 6.1 Network Configuration ..... 6-2**
- 6.1.1 Introduction ..... 6-2
- 6.1.2 Basic Knowledge ..... 6-3
- 6.1.3 Creating a Network Topology ..... 6-5
  - 6.1.3.1 Creating Station Nodes ..... 6-5
  - 6.1.3.2 Creating Connections ..... 6-7

## 6.1 Network Configuration



DIADesigner-AX provides a platform for user to configure the network in the project. Details about the settings are covered in this chapter.

### 6.1.1 Introduction

Network Configuration is used for:

1. Creating networks such as EtherCAT, Modbus, Ethernet and CANOpen in a project, and setting up paths for data transmission.
2. Setting up EtherCAT master.
3. Setting up Modbus COM port.
4. Setting up Ethernet IP.


Double click  **Network Configuration** in the Device tree to open the setting page.



- 1 **Device:** all the configured devices are shown in a tree view.
- 2 **Working area:** the main working area for overall network configuration.
- 3 **Device list:** all the available devices are shown in a tree view.
- 4 **Message display area:** operational messages are shown here.

## 6.1.2 Basic Knowledge

In this section, basic knowledge for network configuration is introduced.



### ● Device and Network

Device is the fundamental element in a network. It can be a PLC, a servo, a driver or any device that you defined. Network is a collection of devices which are interconnected. In a network, every communication port must be assigned with a single network type such as Modbus, Ethernet or EtherCAT. Here, the communication ports of a device serve as the physical interface to connect to a network; therefore, the device can connect to different networks at the same time if it is equipped with more than two ports.

### ● Device Name



Device name serves as the identity of the device that allows you to identify it in the Device tree. Nevertheless, it bears little significance on operation.

● Network and Communication Port

■ EtherCAT



The yellow line **EtherCAT\_1** represents the EtherCAT communication. Double-click the Master Station node to open the EtherCAT setting page of the Master. The number of Master Station is 0 and must not be changed.

Double-click the connection node of the Slave **1** to open the EtherCAT setting page of the Slave. The last digit is used as an indicator of this connection on the Network Configuration Editor page. For instance, the node number is 1 in the EtherCAT address 1001.




■ Modbus TCP / EtherNet/IP

The red line represents Ethernet port, including Modbus TCP and EtherNet/IP communication. Double-click the line to open its setting page and edit IP addresses. The last digit appeared in the last section of the IP address is used as an indicator of this connection.



■ Modbus


The blue line represents the Modbus communication (RS-485). Double-click the line to open the setting page for Modbus communication port.



## 6.1.3 Creating a Network Topology

### 6.1.3.1 Creating Station Nodes


For the first time the network configuration page is accessed, the system automatically creates a graphical representation based on the devices built in the project



You can add additional devices like PLCs, servo motors, and drivers in the network topology in the following ways:


- **Method 1**

Double-click the device to add from the **Product List Editor** pane on your right-hand side. The device added will be updated in the graphical representation as well as in the Device tree immediately.




● **Method 2**


Right-click the project name in the Device tree to bring out the context menu. Double-click **Add Device** on the context menu to open a setting page for adding devices. Double-click the target device or click **Add Device** after selecting the target device.



● **Method 3**

Click the icon  or right-click the device and select **Network Scan** on the context menu to scan and then add the devices and network that have been configured in the project.






### 6.1.3.2 Creating Connections

After the station nodes are created, the next step is to establish connections. The network types supported have been listed in **section 6.1.2**. Follow the methods below to establish connections.


- **Scenario 1**

Drag and drop the communication port to the corresponding network type shown in line to create a connection between the devices.



● Scenario 2

Hold the communication port and drag it to the unused dotted line to create a network connection that is the same as the selected network communication type. Concurrently, a new unused dotted line in grey is added below.



6

---

# Chapter 7 Basic Settings & Operation of Motion Control

## Table of Contents

|  |             |
|--|-------------|
| <b>7.1 Overview of Motion Control Instructions .....</b>     | <b>7-4</b>  |
| 7.1.1 Motion Control Instructions .....                      | 7-4         |
| 7.1.2 Application Notes on Motion Control Instructions ..... | 7-4         |
| 7.1.3 Categories of Motion Control Instructions.....         | 7-4         |
| <b>7.2 Creating Motion Control Project.....</b>              | <b>7-5</b>  |
| 7.2.1 Flowchart.....   | 7-5         |
| 7.2.2 Process for Creating a Project.....                    | 7-5         |
| <b>7.3 Commissioning .....</b>                               | <b>7-10</b> |
| 7.3.1 Procedure for Commissioning .....                      | 7-10        |
| 7.3.2 Example of Axis Parameter Settings .....               | 7-10        |
| 7.3.3 Performing Axes Commissioning .....                    | 7-11        |
| <b>7.4 Motion Control Device.....</b>                        | <b>7-15</b> |
| 7.4.1 Axis Setting .....                                     | 7-15        |
| 7.4.2 Axis Introduction .....                                | 7-15        |
| 7.4.2.1 Introduction to Axis Parameters.....                 | 7-16        |
| 7.4.2.2 Axis Application in the Program .....                | 7-25        |
| 7.4.3 Procedure for Single-axis Configuration .....          | 7-26        |
| 7.4.4 Axis Group Settings .....                              | 7-33        |
| 7.4.4.1 Introduction to Axis Group Parameters .....          | 7-33        |
| 7.4.4.2 Using Axis Groups in the Program .....               | 7-35        |
| 7.4.5 Process for Axis Group Configuration.....              | 7-36        |
| <b>7.5 Motion Axis Variables .....</b>                       | <b>7-41</b> |
| 7.5.1 Variables for Single Axis .....                        | 7-41        |
| 7.5.2 Variables for Axis Group .....                         | 7-44        |
| <b>7.6 Motion Control Programming.....</b>                   | <b>7-47</b> |
| 7.6.1 Motion Control Program.....                            | 7-47        |
| 7.6.1.1 DIADesigner-AX Programming Structure and Types ..... | 7-47        |
| 7.6.1.2 POU in DIADesigner-AX .....                          | 7-48        |
| 7.6.1.3 Adding POU in DIADesigner-AX.....                    | 7-49        |
| 7.6.1.4 PDO Mapping .....                                    | 7-51        |
| 7.6.2 Axis State Transition .....                            | 7-52        |
| 7.6.2.1 Axis State .....                                     | 7-52        |

---

|            |   |             |
|------------|---|-------------|
| 7.6.2.2    | Axis Group State .....  | 7-54        |
| 7.6.3      | Execution and Status of Motion Control Instructions.....        | 7-56        |
| 7.6.3.1    | Basic Rules for Instruction Execution.....                      | 7-56        |
| 7.6.3.2    | Timing Diagram for Inputs / Outputs.....                        | 7-58        |
| 7.6.3.3    | Repeated Execution of a Single Motion Control Instruction ..... | 7-59        |
| 7.6.3.4    | Multi-execution of Motion Control Instructions .....            | 7-59        |
| 7.6.3.5    | Synchronous Execution of Motion Control Instructions .....      | 7-60        |
| 7.6.4      | Position .....  | 7-65        |
| 7.6.4.1    | Types of Positions .....  | 7-65        |
| 7.6.5      | Cam Tables and Framework .....                                  | 7-66        |
| 7.6.5.1    | E-CAM Framework .....   | 7-66        |
| 7.6.5.2    | E-CAM Establishment .....                                       | 7-67        |
| <b>7.7</b> | <b>Motion Control Functions.....</b>                            | <b>7-71</b> |
| 7.7.1      | System Structure .....  | 7-71        |
| 7.7.2      | Single-axis Control .....                                       | 7-71        |
| 7.7.2.1    | Cyclic Synchronous Position Mode.....                           | 7-71        |
| 7.7.2.2    | Profile Position Mode .....                                     | 7-72        |
| 7.7.2.3    | Positioning .....   | 7-72        |
| 7.7.2.4    | Stop Method .....   | 7-74        |
| 7.7.2.5    | MC_GearIn .....   | 7-76        |
| 7.7.2.6    | MC_GearInPos.....   | 7-78        |
| 7.7.2.7    | MC_CamIn.....   | 7-79        |
| 7.7.3      | Velocity Control.....   | 7-88        |
| 7.7.3.1    | CSP Mode .....  | 7-88        |
| 7.7.3.2    | CSV Mode.....   | 7-89        |
| 7.7.3.3    | Profile Velocity Mode.....                                      | 7-89        |
| 7.7.4      | Torque Control .....  | 7-90        |
| 7.7.5      | Common Functions of Single-axis Control .....                   | 7-91        |
| 7.7.5.1    | Position Command .....  | 7-91        |
| 7.7.5.2    | Velocity Command .....  | 7-93        |
| 7.7.5.3    | Acceleration and Deceleration Command .....                     | 7-94        |
| 7.7.5.4    | Jerk Command .....  | 7-95        |
| 7.7.5.5    | Axis Direction.....   | 7-96        |
| 7.7.6      | Axis Group Control.....   | 7-98        |
| 7.7.6.1    | Linear Interpolation .....                                      | 7-98        |
| 7.7.6.2    | Helical Interpolation .....                                     | 7-99        |
| 7.7.6.3    | Stop Command for Axis Group .....                               | 7-101       |
| 7.7.7      | High-speed I/O .....  | 7-102       |
| 7.7.7.1    | I/O Configuration.....  | 7-102       |
| 7.7.7.2    | DIO Settings .....  | 7-103       |
| 7.7.7.3    | SSI Encoder Settings .....                                      | 7-104       |
| 7.7.7.4    | Pulse Encoder Settings .....                                    | 7-105       |

---

|            |   |              |
|------------|---|--------------|
| 7.7.7.5    | Capture / Compare Settings .....                        | 7-109        |
| 7.7.8      | Other Features .....                                    | 7-110        |
| 7.7.8.1    | Changing Current Position.....                          | 7-110        |
| 7.7.8.2    | Software Limit.....                                     | 7-110        |
| 7.7.8.3    | Position Lag Settings.....                              | 7-111        |
| 7.7.8.4    | Cam Switch.....   | 7-112        |
| 7.7.8.5    | Position Capture .....                                  | 7-113        |
| <b>7.8</b> | <b>Programming Example .....</b>                        | <b>7-114</b> |
| 7.8.1      | Device Framework .....                                  | 7-114        |
| 7.8.1.1    | Utilization .....                                       | 7-114        |
| 7.8.1.2    | Configuration .....                                     | 7-114        |
| 7.8.2      | Examples.....   | 7-115        |
| 7.8.2.1    | Servo On .....  | 7-116        |
| 7.8.2.2    | Resetting and Monitoring Single-axis Errors .....       | 7-117        |
| 7.8.2.3    | Monitoring Instruction Errors.....                      | 7-121        |
| 7.8.2.4    | Quick Stop for Single Axis.....                         | 7-123        |
| 7.8.2.5    | Homing .....  | 7-126        |
| 7.8.2.6    | Absolute Positioning .....                              | 7-128        |
| 7.8.2.7    | Switching Cam Tables during Cam Operation.....          | 7-130        |
| 7.8.2.8    | Executing Master Phase Offset during Cam Operation..... | 7-138        |
| 7.8.2.9    | Changing Current Position in Movement.....              | 7-146        |
| 7.8.2.10   | Performing Superimposition during Gear Engagement ..... | 7-151        |

## 7.1 Overview of Motion Control Instructions

### 7.1.1 Motion Control Instructions

This section introduces the elements of a motion control program, including devices, symbols, and motion control instructions.

Motion control instructions are defined as function blocks (FBs) and are used in programs to perform various motion control purposes. The MC motion control instructions introduced in this manual are developed based on the specifications of PLCopen<sup>\*1</sup> motion control function block.

This section provides an overview of the two motion control instructions, PLCopen and Delta-defined function blocks. PLCopen defines the interface of programs and function blocks, thus realizing the standardized motion control programming environment defined in IEC61131-3. Using PLCopen-based instructions together with Delta-defined instructions can reduce training and technical support costs.

Before using the instructions, make sure you fully understand the functionality of the device, symbols, and instructions. It is recommended to refer to the appendices of the AXn motion control instruction list and related error codes.

\*1: PLCopen is an international standard organization that promotes industrial control standards based on IEC61131-3, which is widely adopted for PLC programming. For more information about PLCopen, please check the official website <http://www.plcopen.org/>.

### 7.1.2 Application Notes on Motion Control Instructions

This section describes the important operating specifications and limitations when applying motion commands. The detailed information of each command will be described in **Section 7.6.3 Motion Control Programming**.

- **Programming languages supported by motion control instructions**

DIADesigner-AX supports all programming languages to create, edit or maintain programs. Supported languages include Ladder Diagram (LD), Sequential Function Chart (SFC), Continuous Function Chart (CFC), Structured Language (ST), and Function Block Diagram (FBD).

For detailed information about the programming language, refer to the **DIADesigner-AX Software Manual**.

### 7.1.3 Categories of Motion Control Instructions


This section introduces the categories of motion control instructions. The corresponding instructions can be found in the libraries SM3\_Basic, DL\_MotionControl, and DL\_MotionControlLight. For more details, refer to the **AX Series Motion Controller Manual**.

| Category                                | Type           | Function Group                            | Description   |
|---|----------------|---|---|
| Single-axis motion control instructions | Motion         | Positioning                               | "MC_": Motion control instruction based on PLCopen<br>"DMC_": Delta custom motion control command<br>"SMC_": Motion command<br>"MC_XXX_DML": Delta's custom motion control instructions, used for positioning axes. |
|   |                | Velocity control                          |   |
|   |                | Torque control                            |   |
|   |                | Synchronized control                      |   |
|   | Administrative | Administrative function                   |   |
| Multi-axis motion control instructions  | Motion         | Axis group movement                       | Multi-axis motion   |
|   | Administrative | Administrative functions on multiple axes | Multi-axis configuration, monitoring and reset.   |

## 7.2 Creating Motion Control Project

### 7.2.1 Flowchart

The flowchart below illustrates the process of motion control project creation and axis configuration.




### 7.2.2 Process for Creating a Project


- Establish a new project

On the desktop shortcut, double-click  to launch DIADesigner-AX.


1. Click **File > New Project** in the toolbar or click  **New Project...** on the **Start Page**.




2. Enter **Name** and **Location** in the **New Project** window, and select the desired template to create a project. In this section, Model AX-8 is taken as an example; therefore, we select **Standard project** and then click **OK**.




3. Double-click on **Network Configuration** to continue with EtherCAT settings.




4. After double-clicking, the **Network Configuration Editor** window pops. The slave device can be found and added from the **Product List Editor** on the right.




5. Select **Fieldbuses > EtherCAT > ASD > Delta ASDA-A2-E EtherCAT (CoE) Drive DML**, double-click and it will be automatically added to the **Network Configuration Editor**.




6. Click on the yellow box above the slave station and drag it to the EtherCAT main line to complete the connection configuration between the master station and the slave station.





7. Double-click the small yellow box of the master station to set the parameters of the EtherCAT master station. In the master station setting, the EtherCAT synchronization time can be set.






8. Double-click slave device to enter the slave EtherCAT settings. After double-clicking, the slave station related setting page appears, such as station number setting, **Process Data** and **Startup Parameters** setting, etc.




- You can then start programming. It should be noted that for the motion command part, use the motion function block to write the program in the POU under **EtherCAT\_Task** to prevent the motion function block from running normally.



## 7.3 Commissioning


### 7.3.1 Procedure for Commissioning

The steps to establish a commissioning process are as follows:



### 7.3.2 Example of Axis Parameter Settings

Before using software to perform commissioning, axis parameters must be set first. The setting method is illustrated below:



#### ● Axis configuration screen

**Axis Type and Limits**

Virtual mode

Finite

Modulo

Linear Axis Software Limits

Activated

Negative [u]:

Positive [u]:

Rotary Axis Modulo Settings

Modulo value [u]:

**Motion Parameter**

Velocity Ramp Type

Trapezoid

Sin<sup>2</sup>

Quadratic

Quadratic(smooth)

Error Reaction

Quick Stop

Dynamic Limits

Velocity [u/s]:  Acceleration [u/s<sup>2</sup>]:  Deceleration [u/s<sup>2</sup>]:  Jerk [u/s<sup>3</sup>]:

Position Lag Supervision

Position Lag Reaction:  Lag Limit [u]:

**Transmission Mechanism**

Mechanism Type:

Mechanism Settings

(1) Command pulse per motor rotation:  [ Pulse ]

(4) Pitch:  [ Unit ]

Gear Box

Gear Ratio =  $\frac{(2) \text{ Gear ratio numerator } \input{type="text" value="1"/>$

$\frac{(3) \text{ Gear ratio denominator } \input{type="text" value="1"/>$

● Parameter settings


| Parameter Name                     | Setup       |
|------------------------------------|-------------|
| Axis type ①                        | Linear axis |
| Command pulse per motor rotation ③ | 10,000      |
| Pitch ③                            | 1*1         |
| Gear ratio denominator             | 128*2       |
| Gear ratio numerator               | 1*2         |
| Software limit_Positive ②          | 10,000      |
| Software limit_Negative ②          | -10,000     |

\*1: The unit is 1mm. For instance, if you need to move by 1μm, the input parameter would be 0.001.


\*2: It is a must to set P1-44 and P1-45 of the servo drive.

### 7.3.3 Performing Axes Commissioning


1. Double-click to select **EtherCAT\_Master\_SoftMotion**.




2. Double-click to select **Online Config Mode**.



- After entering the online commissioning, double-click to select **SM\_Drive\_ETC\_Delta\_ASDA\_A2**.



- After entering the axis parameter setting page, open the **Commissioning** tab.



● Display on the Commissioning page

The screenshot shows the Commissioning page interface. It includes a table for axis variables, a status section, and several control buttons and input fields.

| variable                         | set value | actual value |
|----------------------------------|-----------|--------------|
| Position [u]                     | 21.38     | 21.38        |
| Velocity [u/s]                   | 0.00      | -1.95        |
| Acceleration [u/s <sup>2</sup> ] | 0.00      | -488.28      |
| Torque [Nm]                      | 0.00      | 0.00         |

Status: SMC\_AXIS\_STATE.power\_off  
 Communication: operational (100)

Errors  
 Axis Error: 0 [16#00000000]  
 FB Error: SMC\_ERROR.SMC\_NO\_ERROR  
 uiDriveInterfaceError: 0  
 strDriveInterfaceError:

Power 3, Error reset 4, Homing 5

Inch 6: Distance: 1, Velocity: 1, Acceleration: 10, Deceleration: 10, Jerk: 0

Read&Write 7: Parameter: , Value: , Prepared Value:

■ ① Information on axis commands

| Name                             | Function                         |
|----------------------------------|----------------------------------|
| Position [u]                     | Set position and actual position |
| Velocity [u/s]                   | Set value and actual value       |
| Acceleration [u/s <sup>2</sup> ] | Set value and actual value       |
| Torque [Nm]                      | Set value and actual value       |

■ ② Axis status and communication status

| Name          | Function             |
|---------------|----------------------|
| Status        | Axis status          |
| Communication | Communication status |

- ③ Axis power: Set power on / off
- ④ Error reset: Clear servo axis error messages
- ⑤ Homing: Set the axis back to the original position

■ ⑥ Inch

| Name         | Function              |
|--------------|-----------------------|
| Distance     | Moving distance       |
| Velocity     | Moving velocity       |
| Acceleration | Acceleration rate     |
| Deceleration | Deceleration rate     |
| Jerk         | Command value of jerk |

■ ⑦ Read & Write:

Read and write the upper axis parameters. To read or modify Object Dictionary, please follow the steps:

- Read and write the parameter 0x6098 in object dictionary.

16#1609800

1 = fixed number

6098 = the parameter to be read and written

00 = sub for the parameter

1. Convert 0x1609800 to decimal number as 23,107,584.
2. Turn 23,107,584 into -23,107,584.
3. Enter -23,107,584 in **Parameter** field to read the parameter "0x6098".

## 7.4 Motion Control Device

### 7.4.1 Axis Setting

Motion control equipment is mainly used to set axis parameters. In most applications, user can set axis parameters in DIADesigner-AX. DIADesigner-AX provides user with a convenient editing environment. In this editing environment, the axis parameter setting of motion control is defined as its single data structure. This data structure contains multiple related parameters.

### 7.4.2 Axis Introduction

In a motion control system, the object used to perform motion control is called an axis, which contains physical servo drives, encoders and virtual servo drives. The axis types are listed in the table below.

| Types                 | Function   |
|-----------------------|--|
| Positioning axis*1    | Perform basic positioning control such as absolute positioning, relative positioning etc through EtherCAT communication.                                 |
| Velocity axis*1       | Perform velocity control and torque control through EtherCAT communication (as seen in CIA 402 Velocity Mode).   |
| Synchronous axis*2    | Perform servo control through EtherCAT communication, including basic positioning control as well as synchronous motion control such as electronic cams. |
| Pulse type servo axis | Perform physical servo control through pulses.   |
| Virtual axis          | Perform motion control commands without using physical servo control.  |
| Encoder axis          | Use physical encoder (SSI or incremental encoder) as feedback signals.   |
| Virtual encoder axis  | Used only in a program without encoders.   |

\*1:

Positioning axis and velocity axis need to use DL\_MotionControlLight library.

When the number of EtherCAT axes used by AX-8 exceeds 64 and the Soft Motion version is below V4.7.0.0, the MAX\_MAILBOX\_CHANNELS and MAX\_SDO\_Channels parameters in the Library (IODrvEtherCat → ETC\_Parameter) must be changed to 128.

\*2: Synchronous axis need to be used with DL\_MotionControl and SM3\_Basic library.

### 7.4.2.1 Introduction to Axis Parameters

A servo axis is established with the corresponding axis parameters attendant. The following table lists its related instructions:

- Synchronous Axis

The screenshot shows the configuration interface for the SM\_Drive\_ETC\_Delta\_ASDA\_A2. It includes sections for:
 

- 1 Axis Type and Limits:** Options for Virtual mode, Finite/Modulo axis type, and software limits (Negative [u]: 0, Positive [u]: 1000). Rotary Axis Modulo Settings are set to 360.
- 2 Motion Parameter:** Velocity Ramp Type (Trapezoid, Sin<sup>2</sup>, Quadratic, Quadratic(smooth)) and Dynamic Limits (Velocity [u/s]: 5, Acceleration [u/s<sup>2</sup>]: 100, Deceleration [u/s<sup>2</sup>]: 100, Jerk [u/s<sup>3</sup>]: 10000).
- 3 Error Reaction:** Quick Stop is checked.
- 4 Position Lag Supervision:** Position Lag Reaction is Deactivated, Lag Limit [u]: 1.
- 5 Transmission Mechanism:** Mechanism Type is Ball Screw. Mechanism Settings include Command pulse per motor rotation (1280000 [Pulse]) and Pitch (10000 [Unit]). Gear Box settings show Gear Ratio = (2) Gear ratio numerator / (3) Gear ratio denominator, both set to 1.
- 6 Servo Gear Ratio Settings:** Reverse OFF is selected. Diagrams show motor rotation directions: CCW for Positive Command and CW for Negative Command.

- ① Axis Type and Limits

| Name            | Function                              |
|-----------------|---------------------------------------|
| Virtual         | Activate virtual axis.                |
| Finite / Modulo | Set to be linear axis or rotary axis. |

- ② Linear Axis Software Limits

| Name         | Function   |
|--------------|--|
| Activated    | Activate software limit (only linear axis is supported). |
| Negative [u] | Reverse software limit.                                  |
| Positive [u] | Forward software limit.                                  |

■ ③ Rotary Axis Modulo Setting

| Name             | Function  |
|------------------|---|
| Modulo value [u] | Set the area of rotation for a turn (only for rotary axis). |

■ ④ Error Reaction

| Name                             | Function  |
|----------------------------------|---|
| Quick Stop                       | Axis emergency stop   |
| Deceleration [u/s <sup>2</sup> ] | Axis deceleration to stop (only valid when Quick Stop is not activated) |

■ ⑤ Velocity Ramp Type

| Name  | Function                   |
|---|----------------------------|
| Trapezoid / Sin <sup>2</sup> / Quadratic / Quadratic (Smooth) | Set axis motion trajectory |

■ ⑥ Position Lag Supervision

| Name                  | Function                           |
|-----------------------|------------------------------------|
| Position Lag Reaction | Set the reaction for position lag. |
| Lag Limit [u]         | Set the value of lag limit.        |

■ ⑦ Positive / Negative Command

| Name                     | Function  |
|--------------------------|---|
| Reverse OFF / Reverse ON | Enable or disable reverse function for positive / negative command. |


■ ⑧ Transmission Mechanism

- Servo Gear Ratio Setting

| Name             | Function                                       |
|------------------|--|
| Unit Numerator   | Numerator factor of the electronic gear unit   |
| Unit Denominator | Denominator factor of the electronic gear unit |


The introductions of different mechanisms are given below:

- Ball Screw




| Name                                 | Function                               |
|--------------------------------------|--|
| (1) Command pulse per motor rotation | Command pulse value per motor rotation |
| (4) Pitch                            | Distance between screw threads         |
| (2) Gear ratio numerator             | Numerator of gear ratio                |
| (3) Gear ratio denominator           | Denominator of gear ratio              |

- Round Table




| Name                                     | Function                                    |
|--|---|
| (1) Command pulse per motor rotation     | Command pulse value per motor rotation      |
| (4) Movement distance per motor rotation | Distance of the movement per motor rotation |
| (2) Gear ratio numerator                 | Numerator of gear ratio                     |
| (3) Gear ratio denominator               | Denominator of gear ratio                   |

- Belt Pulley



| Name   | Function   |
|--|--|
| (1) Command pulse per motor rotation                           | Command pulse value per motor rotation                                 |
| (4) Diameter<br>(moving distance motor rotation: diameter * n) | Diameter<br>Distance of the movement per motor rotation:<br>diameter*n |
| (2) Gear ratio numerator                                       | Numerator of gear ratio  |
| (3) Gear ratio denominator                                     | Denominator of gear ratio  |


■ ⑨ Homing Setting



| Name   | Function  |
|--|---|
| Homing Mode                                  | Configure homing mode setting.                        |
| Homing speed during search for switch        | Set the homing speed during search for switch.        |
| Homing speed during search for z phase pulse | Set the homing speed during search for Z phase pulse. |
| Homing Acceleration                          | Set the homing acceleration rate.                     |

● Positioning axis

❖ Positioning axis - Delta servo motors



❖ Positioning axis - Delta drives

**1** Axis Type and Limits

- Finite
- Modulo
- Linear Axis Software Limits
  - Activated
  - Negative [u]: 0
  - Positive [u]: 1000
- Rotary Axis Modulo Settings
  - Modulo value [u]: 360

**2** Linear Axis Software Limits

**3** Rotary Axis Modulo Settings

**4** Motion Parameter

Velocity Ramp Type: S-curve

A: Acc.Begin [ s ] 0.2  
 B: Acc.Arrival [ s ] 0.2  
 C: Dec.Begin [ s ] 0.2  
 D: Dec.Arrival [ s ] 0.2

**6** Transmission Mechanism

Mechanism Type: Ball Screw

Mechanism Settings

(1) Command pulse per motor rotation: 4 [ Pulse ]  
 (4) Pitch: 1 [ Unit ]

Gear Box

Gear Ratio =  $\frac{(2) \text{ Gear ratio numerator } 1}{(3) \text{ Gear ratio denominator } 1}$

**5**

|  | Positive Command | Negative Command |
|--|------------------|------------------|
| <input checked="" type="radio"/> Reverse OFF |                  |                  |
| <input type="radio"/> Reverse On             |                  |                  |

■ ① Axis Type and Limits

| Name            | Function                              |
|-----------------|---------------------------------------|
| Finite / Modulo | Set to be linear axis or rotary axis. |

■ ② Linear Axis Software Limits

| Name         | Function   |
|--------------|--|
| Activated    | Activate software limit (only linear axis is supported). |
| Negative [u] | Reverse software limit.                                  |
| Positive [u] | Forward software limit.                                  |

■ ③ Rotary Axis Modulo Setting

| Name             | Function  |
|------------------|---|
| Modulo value [u] | Set the area of rotation for a turn (only for rotary axis). |

■ ④ Velocity Ramp Type

❖ Delta Servo Motors

| Name                         | Function                          |
|------------------------------|-----------------------------------|
| Trapezoid / Sin <sup>2</sup> | Set the motion trajectory of axes |

❖ Delta drives

| Name                | Function                                  |
|---------------------|---|
| Trapezoid / S-Curve | Set the motion trajectory of axes         |
| A : Acc.Begin       | S acceleration start time setting 1 (s)   |
| B : Acc.Arrival     | S acceleration arrival time setting 2 (s) |
| C : Dec.Begin       | S deceleration start time setting 1 (s)   |
| D : Dec.Arrival     | S deceleration arrival time setting 2 (s) |

■ ⑤ Positive / Negative Command

| Name           | Function  |
|----------------|---|
| Reverse OFF/ON | Enable or disable reverse function for positive / negative command. |


■ ⑥ Transmission Mechanism

- Servo Gear Ratio Setting

| Name             | Function                                       |
|------------------|--|
| Unit Numerator   | Numerator factor of the electronic gear unit   |
| Unit Denominator | Denominator factor of the electronic gear unit |


The following columns are introduced for different mechanisms:

- Ball Screw




| Name                                 | Function                               |
|--------------------------------------|--|
| (1) Command pulse per motor rotation | Command pulse value per motor rotation |
| (4) Pitch                            | Distance between screw threads         |
| (2) Gear ratio numerator             | Numerator of gear ratio                |
| (3) Gear ratio denominator           | Denominator of gear ratio              |

- Round Table




| Name                                     | Function                                    |
|--|---|
| (1) Command pulse per motor rotation     | Command pulse value per motor rotation      |
| (4) Movement distance per motor rotation | Distance of the movement per motor rotation |
| (2) Gear ratio numerator                 | Numerator of gear ratio                     |
| (3) Gear ratio denominator               | Denominator of gear ratio                   |

- Belt Pulley



| Name   | Function  |
|--|---|
| (1) Command pulse per motor rotation                           | Command pulse value per motor rotation                              |
| (4) Diameter<br>(moving distance motor rotation: diameter * n) | Diameter<br>Distance of the movement per motor rotation: diameter*n |
| (2) Gear ratio numerator                                       | Numerator of gear ratio   |
| (3) Gear ratio denominator                                     | Denominator of gear ratio   |


Motor Settings—settings for Delta drives



| Name                          | Function   |
|-------------------------------|--|
| Motor Selection               | Set the motor type                               |
| Pole Number                   | Set the number of motor poles                    |
| Maximum Operation Frequency   | Set the maximum operation frequency of the motor |
| Motor Rated Frequency         | Set the motor rated frequency                    |
| Rated Current                 | Set the motor rated current current              |
| Rated Power                   | Set the motor rated power                        |
| Rated Voltage                 | Set the motor rated voltage                      |
| Rated Speed                   | Set the motor rated speed                        |
| Encoder Connected             | Set whether to start the encoder                 |
| Encoder Type Selection        | Set the type of encoder                          |
| Encoder Input Type Setting    | Set the the input type of encoder                |
| Encoder Pulses Per Revolution | Set the number of encoder pulses per revolution  |


■ ⑧ Homing Setting

❖ Delta servo motors



❖ Delta drives

(Supported models: C2000Plus, CH2000, MH300, MS300; DDF V1.0.1.0 (inclusive) and above support this interface)




| Name   | Function  |
|--|---|
| Homing Mode                                  | Configure homing mode setting.                        |
| Homing speed during search for switch        | Set the homing speed during search for switch.        |
| Homing speed during search for z phase pulse | Set the homing speed during search for Z phase pulse. |
| Homing Acceleration                          | Set the homing acceleration rate.                     |


### 7.4.2.2 Axis Application in the Program

When a servo axis is added to the project, the system will automatically generate its servo axis name (the user can also modify its name) and input the name to the function block.

- Synchronous axis




- Positioning axis




### 7.4.3 Procedure for Single-axis Configuration


The axis setting procedure is shown in the figure below. For details of PLC project creation, refer to **section 7.2** of this manual.



1. Open the project, click on **Network Configuration**.




- After entering the **Network Configuration** page, click **Delta ASDA-A2-E EtherCAT (CoE) Drive Rev4\_SM<sup>1</sup>** and then wire **1** to the yellow line above.




\*1: Delta ASDA-A2-E EtherCAT (CoE) Drive Rev4\_SM is a synchronous axis. If you need to add a new positioning axis, select Delta ASDA-A2-E EtherCAT (CoE) Drive Rev4\_DML. The subsequent steps are the same.


- After the axis is created, double-click the slave device to be set.




- Switch to the page **Process Data** and set up its PDO mapping group. The default setting for Delta ASDA-A2 is the 2<sup>nd</sup> group, which can operate normally with most function blocks. If additional groups or PDO parameters are required, please refer to the content regarding function blocks in the **AX Series Motion Controller Manual**.



- Initialize EtherCAT communication  
Where it is necessary to write fixed values for the required Object Dictionary after each initialization, go to the **Startup Parameters** page to set up.




- After completing related settings of axis communication, double-click **SM\_Drive\_ETC\_Delta\_ASDA\_A2**.




7. Axis setting page


Axis types: **Modulo** stands for rotary axis; **Finite** stands for linear axis.



8. Set the **Linear Axis Software Limits**. When **Activated** is checked, the software limits will be activated. **Negative** refers to negative limit whereas **Positive** refers to positive limit.




9. After the rotary axis settings are done, the rotation range must be defined. You should set the **Modulo** value in **Rotary Axis Modulo Settings**.




10. Scaling / Mapping page


Set the pulse value for **Command pulse per motor rotation**.  
 Set the moving distance per motor revolution, **Pitch**.




11. To set the EtherCAT communication cycle, click **EtherCAT\_Master\_SoftMotion** and set the **Cycle time** to **4000**, **Sync offset** to **20**.




12. Scan the network for PLC.




13. After adding the scanned PLC, click **OK**.




14. A green light appears after the controller is successfully connected. Click **Login**.



15. Here, a window showing whether to download the program will pop up. Click **YES** to continue.



7



### 7.4.4 Axis Group Settings

Axis group movement should be applied via DIADesigner-AX software when multiple axes are executed simultaneously with linear and helical interpolation functions required.

|                        |   |                       |
|------------------------|---|-----------------------|
| Number of control axes | Maximum number of axes controlled by linear interpolation   | 6 axes                |
|                        | Number of control axes controlled for helical interpolation | 6 axes (3 slave axes) |

#### 7.4.4.1 Introduction to Axis Group Parameters

The parameters used for axis group motion are as follows:

DeltaAxisGroup X

1 Kinematic Configuration

|         |             |   |     |
|---------|-------------|---|-----|
| Axis X: | (Configure) | <input type="text" value="SM_Drive_ETC_Delta_ASDA_A2"/>   | ... |
| Axis Y: | (Configure) | <input type="text" value="Please Enter an Axis Mapping"/> | ... |
| Axis Z: | (Configure) | <input type="text" value="Please Enter an Axis Mapping"/> | ... |

|         |             |   |     |
|---------|-------------|---|-----|
| Axis A: | (Configure) | <input type="text" value="Please Enter an Axis Mapping"/> | ... |
| Axis B: | (Configure) | <input type="text" value="Please Enter an Axis Mapping"/> | ... |
| Axis C: | (Configure) | <input type="text" value="Please Enter an Axis Mapping"/> | ... |

Note

$$\text{Following Ratio} = \frac{\text{Target Position of Following Axis}}{\text{Target Position of Axis Group}}$$

2 Motion Parameter

RampType S Curve

|                           |                                      |                            |
|---------------------------|--------------------------------------|----------------------------|
| Max Velocity Limit        | <input type="text" value="1000000"/> | (user unit)/s              |
| Max Acceleration Limit    | <input type="text" value="2000000"/> | (user unit)/s <sup>2</sup> |
| Max Deceleration Limit    | <input type="text" value="2000000"/> | (user unit)/s <sup>2</sup> |
| Max Jerk Limit (Reserved) | <input type="text" value="0"/>       | (user unit)/s <sup>3</sup> |

3 Tasks

Bus Task:

● ① Kinematic

| Name                 | Function             |
|----------------------|----------------------|
| Axis X <sup>*1</sup> | X axis in axis group |
| Axis Y <sup>*1</sup> | Y axis in axis group |
| Axis Z <sup>*1</sup> | Z axis in axis group |
| Axis A <sup>*1</sup> | A axis in axis group |
| Axis B <sup>*1</sup> | B axis in axis group |
| Axis C <sup>*1</sup> | C axis in axis group |


● ② Motion Parameters

| Name                                    | Function  |
|---|---|
| Ramp Type <sup>*2</sup>                 | Velocity ramp type  |
| Max Velocity Limit <sup>*3</sup>        | Maximum velocity of axis group                              |
| Max Acceleration Limit <sup>*3</sup>    | Maximum acceleration of axis group                          |
| Max Deceleration Limit <sup>*3</sup>    | Maximum deceleration of axis group                          |
| Max Jerk Limit (Reserved) <sup>*3</sup> | Maximum jerk rate of axis group (this function is reserved) |

● ③ Tasks


| Name     | Function                       |
|----------|--------------------------------|
| Bus Task | Set update task for axis group |

\*1: Axis X ~ Axis C: Input the individual axis name.




\*2: There are two ramp types: Trapezoid and S Curve, which are displayed as follows.

■ Trapezoid



■ S Curve



\*3:


- Max Velocity Limit: When the movement speed of the axis group exceeds the set parameters, an error will be reported.
- Max Acceleration Limit: When the axis group movement acceleration exceeds the set parameter, an error will be reported.
- Max Deceleration Limit: When the axis group movement deceleration exceeds the set parameter, an error will be reported.

### 7.4.4.2 Using Axis Groups in the Program

Before using the axis group function block in the program, you must add an axis group node in the project tree and set the name of the single axis to be used by the axis group. After the setting is complete, please point the node name of the axis group to the AxisGroup pins of each functional block.


### 7.4.5 Process for Axis Group Configuration

To use the axis group movement, you must set the axis group name and the corresponding individual axis through DIADesigner-AX. The flowchart of axis group creation is as follows.




- **Steps to create an axis group**


1. Add a single axis. The following process takes two virtual axes creation as an example.




- After the creation is complete, right-click **Application** and select **Add Object > Delta Axis Group**.




- Set the name for axis group in the **Add Delta Axis Group** window and click **Add**. **DeltaAxisGroup** will then appear in the project tree on the left.




4. Click on **DeltaAxisGroup**, input the names of the two virtual axes into **Axis X** and **Axis Y**.




5. Then click **Bus Task** to enter the **Input Assistant** page. Select **EtherCAT\_Task** and click **OK**.




6. After setting the task, **EtherCAT\_Task** appears in the field of **Tasks**.



7. Add **DMC\_GroupEnable** function block under **PLC\_PRG**, and fill in the axis group name in the **AxisGroup** pin.



8. After the program is written, click **Compile** icon to check the validity.



7

9. After compilation, click on **Online Monitoring** button to download the program.

The screenshot displays the software interface with the following components:

- Menu Bar:** File, Edit, View, Project, FBD/LD/IL, Build, Online, Debug, Tools, Window, Help.
- Toolbar:** Includes icons for file operations, navigation, and execution. The 'Online Monitoring' button (represented by a blue circle with a white 'O') is highlighted with a blue arrow.
- Devices Panel:** Shows a tree view of the project structure. Under 'Application', 'PLC\_PRG (PRG)' is selected and highlighted in blue.
- Code Editor:** Displays the following code:
 

```

1 PROGRAM PLC_PRG
2 VAR
3     DMC_GroupEnable_0: DMC_GroupEnable;
4 END_VAR
            
```
- Ladder Logic:** Shows a single step (1) with a normally open contact labeled 'TRUE' connected to the 'EN' input of a function block 'DMC\_GroupEnable\_1'. The 'AxisGroup' input of the block is connected to 'DeltaAxisGroup'. The outputs of the block are 'bDone', 'bBusy', 'bError', and 'ErrorID'.

## 7.5 Motion Axis Variables

### 7.5.1 Variables for Single Axis

After axes are created in the project tree of the software DIADesigner-AX, the corresponding axis parameters, which are only for reading, will be generated automatically. Axes are divided into two types: synchronous axis (Axis\_REF\_SM3) and positioning axis (Axis\_REF\_DML), which are set out in the following tables:

- Synchronous axis (Axis\_REF\_SM3)

| No.    | Name                  | Data Type   | Default Value  | Description  |
|--------|-----------------------|---|----------------|--|
| 1000   | nAxisState            | SMC_AXIS_STATE(INT)                               | Standstill (3) | Show current axis state according to MC_ReadStatus   |
| 1012   | bCommunication        | BOOL  | FALSE          | TRUE when EtherCAT axis communication is normal; FALSE if disconnected   |
| 1014   | uiDriveInterfaceError | UINT  | 0              | If the Driver Interface detects an error, it will display the corresponding error code   |
| 1021   | wDriveId              | WORD  | Driver         | The number in driver nodes on the Fieldbus   |
| 1025   | fTaskCycle            | LREAL   | Driver         | EtherCAT task cycle time   |
| 1035   | fbeFBError            | ARRAY [0..g_SMC_NUMBER_FB_ERRORS] OF SMC_FB_ERROR | 0              | Axis-related error table   |
| 1040   | bVirtual              | BOOL  | FALSE          | TRUE if it is a virtual axis; FALSE if it is a real axis.  |
| 1051   | iRatioTechUnitsNum    | DINT  | 1              | Change gear ratio in axis setting (denominator)  |
| 1052   | dwRatioTechUnitsDenom | DWORD   | 1              | Change gear ratio in axis setting (numerator)  |
| 1060   | iMovementType         | INT   | 1              | 0 = Modulo<br>1 = Finite   |
| 1061   | fPositionPeriod       | LREAL   | 1000           | Maximum moving distance of rotary axis   |
| 1062   | eRampType             | SMC_RAMPTYPE                                      | Trapez         | Velocity ramp type:<br><ul style="list-style-type: none"> <li>■ Trapezoid</li> <li>■ sin<sup>2</sup></li> <li>■ Quadratic</li> <li>■ Quadratic (smooth)</li> </ul> |
| 1100/1 | fSetPosition          | LREAL   | 0              | Command position (user-defined unit)   |
| 1101   | fActPosition          | LREAL   | 0              | Feedback position (user-defined unit)  |

| No.         | Name                   | Data Type | Default Value | Description   |
|-------------|------------------------|-----------|---------------|---|
| 1110,1<br>1 | fSetVelocity           | LREAL     | 0             | Command velocity (user-defined unit/s)  |
| 1111,1<br>0 | fActVelocity           | LREAL     | 0             | Feedback velocity (user-defined unit/s)   |
| 1115        | bConstantVelocity      | BOOL      | FALSE         | TRUE when the velocity is constant  |
| 1120        | fSetAcceleration       | LREAL     | 0             | Acceleration command (user-defined unit/s <sup>2</sup> )                          |
| 1125        | bAccelerating          | BOOL      | FALSE         | TRUE when axis is accelerating  |
| 1135        | bDecelerating          | BOOL      | FALSE         | TRUE when axis is decelerating  |
| 1140        | fSetJerk               | LREAL     | 0             | Commanded jerk value  |
| 1160        | fSetTorque             | LREAL     | 0             | Commanded torque (Nm)   |
| 1161        | fActTorque             | LREAL     | 0             | Actual torque (Nm)  |
| 1200,2      | fSWLimitPositive       | LREAL     | 0             | Set the range of software positive limit  |
| 1201,3      | fSWLimitNegative       | LREAL     | 0             | Set the range of software negative limit  |
| 1204        | bSWEndSwitchActive     | BOOL      | FALSE         | TRUE when software limit switch activated; the state machine changes to Errorstop |
| 1205        | bSWLimitEnable         | BOOL      | FALSE         | Software limit switch: TRUE (Enable) / FALSE (Disable)                            |
| -           | strDriveInterfaceError | STRING    | "             | Axis error  |

#### ● Positioning axis (Axis\_REF\_DML)

| No.  | Name                  | Data type      | Default value       | Description  |
|------|-----------------------|----------------|---------------------|--|
| 1000 | nAxisState            | SML_AXIS_STATE | SML_AS_PowerOff (0) | Show current axis state according to MC_ReadStatus                                     |
| 1012 | bCommunication        | BOOL           | FALSE               | TRUE when EtherCAT axis communication is normal; FALSE if disconnected                 |
| 1014 | uiDriveInterfaceError | UINT           | 0                   | If the Driver Interface detects an error, it will display the corresponding error code |
| 1051 | iRatioTechUnitsNum    | DINT           | 1                   | Change gear ratio in axis setting (denominator)  |
| 1052 | dwRatioTechUnitsDenom | DWORD          | 1                   | Change gear ratio in axis setting (numerator)  |
| 1060 | iMovementType         | SML_Movemen    | SML_MT_MO           | Axis types:  |

| No.  | Name                           | Data type        | Default value | Description   |
|------|--------------------------------|------------------|---------------|---|
|      |                                | tType            | DULO          | SML_MT_MODULO = rotary axis<br>SML_MT_FINITE = linear axis  |
| 1062 | eRampType*1                    | SMC_RAMP<br>TYPE | Trapez        | Velocity ramp type:<br><ul style="list-style-type: none"> <li>■ Trapezoid</li> <li>■ sin^2</li> </ul> |
| 1101 | fActPosition                   | LREAL            | 0             | Feedback position (user-defined unit)   |
| -    | strDriveInterfac<br>e<br>Error | STRING           | "             | Axis error  |

\*1: Only Trapezoid and sin^2 are supported.

## 7.5.2 Variables for Axis Group

After axis groups are created in the project tree of the software DIADesigner-AX, the system will automatically create the corresponding axis variables, which are set out in the following table.

| Name                     | Data type                   | Set value (default)   | Function   |
|--------------------------|-----------------------------|---|--|
| GroupState               | DMC_GROUP_STATE             | GroupDisabled /<br>GroupStandby /<br>GroupMoving /<br>GroupHoming /<br>GroupStopping /<br>GroupErrorstop<br>(GroupDisabled) | Commands for axis groups status  |
| bError                   | BOOL                        | TRUE / FALSE<br>(FALSE)   | TRUE when an error occurs in the axis group  |
| dwErrorId                | DMC_ERROR                   | DMC_ERROR<br>(DMC_GM_NO_ERROR)  | Detailed error description   |
| lrVelocity               | LREAL                       | 0 ~ 1.798E+308<br>(0)   | Current velocity of axis group   |
| lrAcceleration           | LREAL                       | Positive, negative,<br>or zero<br>(0)   | Current acceleration of axis group   |
| lrJerk                   | LREAL                       | Positive, negative,<br>or zero<br>(0)   | Current jerk of axis group   |
| bAccelerating            | BOOL                        | TRUE / FALSE<br>(FALSE)   | TRUE when acceleration   |
| bDecelerating            | BOOL                        | TRUE / FALSE<br>(FALSE)   | TRUE when deceleration   |
| bConstantVelocity        | BOOL                        | TRUE / FALSE<br>(FALSE)   | TRUE when constant velocity (includes velocity = 0)  |
| bInPosition              | BOOL                        | TRUE / FALSE<br>(FALSE)   | TRUE when positioning is completed   |
| bContinueDataWritten     | BOOL                        | TRUE / FALSE<br>(FALSE)   | TRUE if relevant data is available for DMC_GroupContinue after axis group motion is suspended  |
| ContinuePos              | ARRAY<br>[0..5] OF<br>LREAL | [0,0,0,0,0,0]   | Record the current position of the axis group when the execution of DMC_GroupInterrupt is done |
| AxisX_Name* <sup>1</sup> | String                      |   | Display the axis name used by the current axis group in Axis_X                                 |
| AxisY_Name* <sup>1</sup> | String                      |   | Display the axis name used by the current axis   |

| Name                                | Data type                   | Set value (default)   | Function   |
|-------------------------------------|-----------------------------|---|--|
|                                     |                             |   | group in Axis_Y  |
| AxisZ_Name*1                        | String                      |   | Display the axis name used by the current axis group in Axis_Z   |
| AxisA_Name*1                        | String                      |   | Display the axis name used by the current axis group in Axis_A   |
| AxisB_Name*1                        | String                      |   | Display the axis name used by the current axis group in Axis_B   |
| AxisC_Name*1                        | String                      |   | Display the axis name used by the current axis group in Axis_C   |
| RampType                            | DMC_GR<br>OUP_RA<br>MP_TYPE | Trapezoid / S<br>Curve<br>(S Curve)   | Ramp type of the current axis group  |
| IrMaxVelocityLimit                  | LREAL                       | positive number or<br>zero (1000000)  | Maximum velocity of axis group   |
| IrMaxAcceleration<br>Limit          | LREAL                       | positive number or<br>zero (2000000)  | Maximum acceleration of axis group   |
| IrMaxDeceleration<br>Limit          | LREAL                       | positive number or<br>zero (2000000)  | Maximum deceleration of axis group   |
| IrMaxJerkLimit(Res<br>erved)        | LREAL                       | positive number or<br>zero (0)  | Maximum jerk of axis group (reserved)  |
| bVelocityWarning                    | BOOL                        | TRUE / FALSE<br>(FALSE)   | TRUE when the axis group velocity exceeds the<br>value set in IrVelocityWarningPercentage  |
| bAccelerationWarni<br>ng            | BOOL                        | TRUE / FALSE<br>(FALSE)   | TRUE when the axis group acceleration exceeds<br>the value set in IrAccelerationWarningPercentage  |
| bDecelerationWarni<br>ng            | BOOL                        | TRUE / FALSE<br>(FALSE)   | TRUE when the axis group deceleration exceeds<br>the value set in IrDecelerationWarningPercentage  |
| bJerkWarning<br>(Reserved)          | BOOL                        | TRUE / FALSE<br>(FALSE)   | TRUE when the axis group jerk exceeds the value<br>set in IrJerkWarningPercentage  |
| StopMethod                          | Enum of<br>BYTE             | Immediate Stop /<br>MaxGroupDecStop<br>/ MaxAxisDecStop<br>(Immediate Stop) | Set the stopping method for the axis group when<br>errors occur or when the movement is meant to<br>stop   |
| IrVelocityWarning<br>Percentage     | LREAL                       | 0 ~ 1<br>(0)  | When setting the maximum ratio of the axis group<br>speed limit, the speed warning is displayed, and<br>setting 0 disables the speed warning.                              |
| IrAccelerationWarni<br>ngPercentage | LREAL                       | 0 ~ 1<br>(0)  | When setting the maximum ratio of the axis group<br>acceleration limit, the acceleration warning is<br>displayed, and setting 0 is to disable the<br>acceleration warning. |
| IrDecelerationWarni                 | LREAL                       | 0 ~ 1   | When setting the maximum proportion of the axis  |

| Name                                | Data type | Set value (default) | Function  |
|-------------------------------------|-----------|---------------------|---|
| ngPercentage                        |           | (0)                 | group deceleration limit, a deceleration warning is displayed. Set 0 to disable the deceleration warning.   |
| lrJerkWarning Percentage (Reserved) | LREAL     | 0 ~ 1<br>(0)        | When setting the maximum ratio of the axis group jerk limit, the jerk warning is displayed, and setting 0 disables the jerk warning.  |
| Radius Correction                   | LREAL     | 0 ~ 100<br>(0,1)    | The is to set the permissible error of the radius when helical interpolation is selected.<br>Error % = the distance between [the center point] and [the vertical bisector of the starting and ending positions]/radius. |

\*1: When the axis type is a rotation axis, the set movement distance cannot exceed the modulo setting value. If it exceeds the limit, an **Axis limit violated** error will be reported.

## 7.6 Motion Control Programming

### 7.6.1 Motion Control Program

Please refer to the following descriptions before starting programming in DIADesigner-AX.

#### 7.6.1.1 DIADesigner-AX Programming Structure and Types

In the standard structure, all programs, including subroutines, are written in the same source code for a PLC. With the size of program getting larger, maintenance and debugging also becomes a considerable burden. Under the framework of IEC 61131-3, the program is divided into several units according to the functions or characteristics, which makes the development and maintenance of the program easier. Because the Program Organization Unit (POU) is modular, different POUs can be developed by different designers, which can bring significant benefits to the allocation and execution of project manpower. In DIADesigner-AX, POUs are of three types: program (PROG), function block (FB) and function (FC).

##### 1. Program (Program, PROG)

A program POU can determine its role based on its designated task (TASK) type. If it is assigned to periodic work, the program POU will play the role of the main program; if it is assigned to interrupt type work, the program POU will play the role of the interrupt subroutine. In addition, the program POU can also call function blocks (FB).

##### 2. Function Block (Function Block, FB)

Static (memory) variable symbols can be declared inside the function block POU. Therefore, the value of the static variable symbol can be maintained after the operation. Since the value stored in the function block is calculated together with the input value during execution, even if the input value is the same, the resulting output may be different. In addition, the function block can call other function blocks internally.

##### 3. Function (Function, FC)

Function is used to pass back the operation results. In POU, only minimal permissions are provided for Function. Compared with FB, it cannot access memory space and can only return one single value. Function is used for calculation and then returns the results. In use, Function can only call Function but not FB because Function does not have memory space.

After creating a POU, each program POU must specify a task (TASK). Work (TASK) is used to determine the sequence of program POU execution or startup. The characteristic of the IEC61131-3 program architecture is that the program is divided into several independently developed POUs. When POUs are compiled, all POUs are rearranged and combined into an executable code that can be scanned step by step. The rearrangement order of POUs is based on the work (TASK) to which POUs are assigned. Work (TASK) is of the following types:

- Cyclic
- Event
- External
- Freewheeling
- Status

Refer to **Section 4.4.1** of this manual for details.

### 7.6.1.2 POU in DIADesigner-AX


All POU created by users will be listed in the project management area. Program POU and function block POU will be managed separately. In addition, depending on the language in which the program POU and function block POU are compiled, the POU icon displayed will be different, and POU-related information will also be displayed behind each POU name. Double-click POU in the project management area to open the editing window of the POU. The POU editing window consists of two parts: the upper part of the window is the area symbol table of the POU, and the lower part of the window is the main body of the program. In addition, depending on the programming language, the editing environment in the lower part of the window will also be different.




You can add the variables you need to use in the regional symbol table. In addition, in the system, when the axis / axis group is established, the corresponding variables will be automatically generated. The content of the variables can be referred to **Section 7.5**.

### 7.6.1.3 Adding POU in DIADesigner-AX


1. Open an existing project in DIADesigner-AX. Right-click **Application**, select **Add Object** and then **POU**.




- Enter the program name in the **Name** field and select the language in the **Implementation language** field. Then click **Add**.



- At this point, the POU appears on the left. Double-click **EtherCAT\_Task** and select **Add Call**.



- Select the **POU** which has been created and click **OK**.



- Select **POU** under **EtherCAT\_Task** to start programming.



### 7.6.1.4 PDO Mapping

Set the communication of the PDO (Process Data Objects) mapping between the DIADesigner-AX software and the AX motion control CPU, before using motion control instructions.

PDO Mapping Settings:

|                  |  |
|------------------|--|
| RxPDO (1600 hex) | Control Word (6040 hex), TargetPosition (607A hex) |
| TxPDO (1A00 hex) | Status Word (6041 hex), ActualPosition (6064 hex)  |


The table above pre-sets the PDO mapping parameters that will be used for ASDA-A2-E. For the PDO parameters required by the corresponding motion function blocks, refer to the **AX Series Motion Controller Manual**.

## 7.6.2 Axis State Transition

This section introduces transition of single axis state and multi-axis state in axis groups when different motion function blocks are used. The transition rules fulfill PLCopen motion control standard.

### 7.6.2.1 Axis State

- Synchronous Axis



Note 1: Whenever an error occurs, regardless of the state

Note 2: When `MC_Power Enable = FALSE` and no axis error occurs

Note 3: Execute `MC_Reset` and `MC_Power = FALSE`

Note 4: Execute `MC_Reset`, `MC_Power = TRUE` and `MC_Power Enable = TRUE`


Note 5: `MC_Power Enable = TRUE` and `MC_Power = TRUE`

Note 6: When `MC_Stop Done = TRUE` and `MC_Stop Execute = FALSE`

| State           | Description   |
|-----------------|---|
| Disabled        | The axis is in Servo Off state.   |
| Standstill      | The axis is in Servo On state.  |
| Discrete Motion | The state is Discrete Motion while executing single-axis motion instructions. |

|                     |   |
|---------------------|---|
| Continuous Motion   | The state is Continuous Motion while executing single-axis continuous motion instructions.  |
| Synchronized Motion | The state is Synchronized Motion while executing synchronized motion instructions, including synchronized waiting instruction.          |
| Stopping            | After the execution of MC_Stop instruction stops; Active is TRUE. In this state, no single-axis motion instructions can be executed.    |
| Errorstop           | Whenever an error occurs in single axis, it enters the state of Errorstop, in which no single-axis motion instructions can be executed. |
| Homing              | The state is Homing while executing MC_Home or MC_HomeWithParameter instructions for single axis.                                       |

● Positioning Axis



| State             | Definition   |
|-------------------|--|
| Disabled          | The axis is in Servo Off state   |
| Standstill        | The axis is in Servo On state  |
| Discrete Motion   | The state is Discrete Motion while executing single-axis motion instructions.  |
| Continuous Motion | The state is Continuous Motion while executing single-axis continuous motion instructions.   |
| Stopping          | After the execution of MC_Stop_DML instruction stops, Active is TRUE. In this state, no single-axis motion instructions can be executed. |
| Errorstop         | Whenever an error occurs in single axis, it enters the state of Errorstop, in which no single-axis motion instructions can be executed.  |
| Homing            | The state is Homing while executing MC_Home or MC_HomeWithParameter instructions for single axis.  |



enter the stop state, and the group state will enter GroupStandby.

- If the group is in the GroupStandby state, the single-axis state does not need to be in the StandStill state.
- Group movement commands (including MC\_GroupStop), all single axes in the group are in the SynchronizedMotion state.
- When an error occurs during axis group movement, all axes in the axis group will stop immediately until the group enters GroupErrorStop. Each non-error uniaxial will enter the Standstill state.
- If the state of the axis group is GroupErrorStop, the state of the single axis will not be affected.

### 7.6.3 Execution and Status of Motion Control Instructions

AX series controllers are divided into the following two categories based on the motion function blocks:

| Type | Description                             |
|------|---|
| MC_  | PLCoopen motion control function blocks |
| DMC_ | Delta-defined function blocks*1         |

The general pins in each motion control function block instruction include input, output and in/out. This section elaborates on the definition of these pins and their behaviors.

\*1: Delta-defined function block instructions (DMC) include Delta-defined motion control function blocks and other administrative / non-administrative function blocks applicable to AX series motion control CPUs. For details, please refer to the **AX Series Motion Controller Manual**.

#### 7.6.3.1 Basic Rules for Instruction Execution

- **Definition of input and output pins**

The general input and output pins of motion control function blocks are listed below. Usually, a function block contains at least one or a part of the following pins. For example, based on the properties of motion control function blocks, a function block basically contains either of the input pins, Execute and Enable.

| Input          |   |           |                      |
|----------------|---|-----------|----------------------|
| Name           | Description   | Data Type | Set Value (default)  |
| En             | Receive logic status from instruction front end                           | BOOL      | True / False (False) |
| Enable         | Enable Motion Control Function Blocks                                     | BOOL      | True / False (False) |
| Execute        | Execute motion control function block                                     | BOOL      | True / False (False) |
| Output         |   |           |                      |
| Name           | Description   | Data Type | Set Value (default)  |
| Eno            | Transmits the logic state of the En input to the next chained command     | BOOL      | True / False (False) |
| Done           | Indicates that the execution of the function block has been completed     | BOOL      | True / False (False) |
| Valid          | Indicates that the value displayed by the output pin is a valid value     | BOOL      | True / False (False) |
| Busy           | Indicates that the motion function block has been queued for execution    | BOOL      | True / False (False) |
| Active         | Indicates that the axis is being controlled by the function block         | BOOL      | True / False (False) |
| CommandAborted | Indicates that the execution of the motion function block was interrupted | BOOL      | True / False (False) |
| Error          | Indicates the status of an error in a function block                      | BOOL      | True / False (False) |

A motion control function block usually has either Execute or Enable input pin, which is used to execute or enable the motion control function block. In addition, a motion control function block also contains Busy and Done output pins for display of its status. When the execution of a motion control function block can be interrupted by another function block, the output pin, CommandAborted, is included in this function block. Furthermore, when an error occurs during the execution of a motion control function block, the output pin Error will turn into True.

The motion control function block not only has Execute/Enable input, but may also contain input pins for input value/status, whose characteristics are described below.

- Use input value
  - For a function block with an Execute input, the value of each input pin is taken when the Execute input signal transfers from False to True. However, when Execute is retriggered, the input value will not be updated.
  - For function blocks with Enable input, the value of each input pin is taken when the Enable input signal transfers from False to True. Compared with Execute input, function blocks of Enable input usually have more input values that need to be continuously updated (see the description of each function block for details).
- The input value is out of range
  - After the motion control function block is activated, the input of value that exceeds permitted range will be restricted by the system, or a function block error will occur during execution, resulting in errors in the motion axes. Users should avoid entering incorrect input values in the programs.
- Mutually exclusive of output pins
  - For a function block with Execute input, Busy output, Done output, CommandAborted output or Error output, only one of the states will be set True at one time. When Execute input is set to be True, one of the rest must be set True.
  - For a function block with Enable input, Valid output and Error output are mutually exclusive, which means only one of them can be set True.
- Valid time for output data/status value
  - When a function block contains Execute input and the input signal changes from True to False, the current Done output, Error output, CommandAborted output of current True and output pin data will be reset or cleared. However, when the function block is busy, even if the Execute input signal changes from True to False, the execution of the function block will not stop. The expected output states such as Done output, Error output, CommandAborted output will still generate to True and retain for one cycle.
  - For a function block with Enable input, when the Enable input signal changes from True to False, the Valid output, Busy output and Error output will be reset.
- Characteristics of Done output
  - The Done output of the motion control function block will be set to True after the motion control function block has successfully executed.
- Characteristics of Busy output
  - A function block with an Execute input uses the Busy output to indicate that the execution has not yet completed and that a new output status (value) will be generated later. When the Execute input signal transfers from False to True, the Busy output is set to True. When the Done output, CommandAborted output or Error output is set to True, the Busy output is reset.
  - A function block with an Enable input uses a Busy output to indicate that the execution is not yet completed and that a new output state (value) will be generated later. When the Enable input signal transfers from False

to True, the Busy output is set to True and if Busy output is True, the changes in input state (value) can still be expected.


■ Characteristics of CommandAborted output

- When the execution of a motion control function block is interrupted, the CommandAborted output is set to True.

■ Relation between Enable input and Valid output

- Function blocks with Enable input use Valid output to indicate whether the current output data/status is valid. The Valid output will be set to True only if the Enable input is set to True and the output data/status is valid. If an error occurs in the function block, the output data/status will be invalid and the Valid output will be set to False. The Valid output will be set to True only after the error in the motion control function block is eliminated and the output data/status becomes valid.

**7.6.3.2 Timing Diagram for Inputs / Outputs**




Condition 1: The execution of the motion control function block is interrupted.

Condition 2: An error occurs in the motion control function block.

Condition 3: The motion control function block is executed normally.

7



Condition 1: The motion control function block is executed normally.

Condition 2: An error occurred while controlling the function block in motion.


### 7.6.3.3 Repeated Execution of a Single Motion Control Instruction

During execution of single-axis motion function blocks (Busy state), variables of input pins can be modified to perform rising edge trigger on function block pins again. At this time, the state of the output pin of the function block remains unchanged (Busy state), but the action performed by the system is equivalent to interrupting the previous rising edge trigger instruction with Aborting in buffer mode. For similar behavior patterns, refer to **Section 7.6.3.5**.

### 7.6.3.4 Multi-execution of Motion Control Instructions

This section explains the situation when multiple motion control instructions for one axis or axis group are executed within the same scan period.

- In the following, when contact A is ON, motion 1 and motion 2 corresponding to axis 1 start in the same task period.
- According to the ladder diagram logic, instructions are executed in a top-down order. As a result, motion 1 will be started first and followed by motion 2 after completion.
- This situation is regarded as multi-execution of motion control instructions. As the motion combination is determined by input variable, BufferMode, it is the BufferMode setting in Motion 2 that decides the combination mode between Motion 1 and 2.



### 7.6.3.5 Synchronous Execution of Motion Control Instructions

Single axis with SoftMotion V4.10.0.0\*1 (inclusive) and above, and SM3\_Basic V4.10.0.0 (inclusive) and above supports Buffered Mode feature; DL\_MotionControl V1.2.0.0 (inclusive) and above supports SoftMotion V4.10.0 .0.

\*1: In SoftMotion V4.10.0.0, modification of parameters in Axis\_REF is prohibited; if any, the error message **SMC\_MOVING\_WITHOUT\_ACTIVE\_MOVEMENT** will appear.

- **Buffer mode**

For the same axis, you can activate another motion control instruction when the axis is in motion. There are six types of buffer mode you can choose from to proceed with multi-execution of the instructions. The BufferMode is selected based on the BufferMode parameter setting of the later motion instruction.

The meanings of the terms related to BufferMode are as follows:

- Current instruction: The motion control instruction at runtime right before the multi-execution instruction.
- Buffered instruction: The motion control instruction waiting to be executed.
- Transit velocity: The velocity applied in transition from current instruction to buffered instruction.
- Target velocity: Velocity parameter of the instruction.
- Target position: Position or Distance parameters in instructions related to displacement.


| BufferMode                                   | Operation  |
|--|--|
| 0: mcAborting<br>(Aborting)                  | The current instruction is immediately aborted to execute the buffered instruction.  |
| 1: mcBuffered<br>(Buffered)                  | The buffered instruction is not executed until the current instruction is completed as expected.   |
| 2: mcBlendingLow<br>(Low velocity)           | The buffered instruction is executed after the target position of the current instruction is achieved. The transit velocity is set to be the target velocity of either the current or the buffered instruction, whichever is lower.  |
| 3: mcBlendingPrevious<br>(Previous velocity) | The buffered instruction is executed after the target position of the current instruction is achieved. The transit velocity is the target velocity of the current instruction.   |
| 4: mcBlendingNext<br>(Next velocity)         | The buffered instruction is executed after the target position of the current instruction is achieved. The transit velocity is the target velocity of the buffered instruction.  |
| 5: mcBlendingHigh<br>(High velocity)         | The buffered instruction is executed after the target position of the current instruction is achieved. The transit velocity is set to be the target velocity of either the current or the buffered instruction, whichever is higher. |

- **Example: a brief introduction with two relative displacement instructions**


Here, the maximum velocity of the first relative displacement instruction is V1 and the displacement is S1 while the maximum velocity of the second relative displacement instruction is V2 and the displacement is S2.

By changing the BufferMode of the second displacement instruction, it results in different transiting processes as shown in the figures below:


■ BufferMode=mcAborting




■ BufferMode=mcBuffered




■ BufferMode=mcBlendingLow



■ BufferMode=mcBlendingPrevious




**3. The current instruction and the buffered instruction are in opposite directions**




■ BufferMode=mcBlendingNext


**1. The velocity of the current instruction is lower than that of the buffered instruction**




**2. The velocity of the current instruction is higher than the buffered instruction**



**3. The current instruction and the buffered instruction are in opposite directions**




■ BufferMode=mcBlendingHigh



■ BufferMode curve is planned mainly based on input parameters of function block by satisfying the sequence: Jerk → Acceleration / Deceleration → Position → Velocity.

For example, when Position < Velocity, Velocity = Acceleration / Deceleration, and Jerk < Acceleration / Deceleration, the curve planning is as follows:



Due to insufficient path, the planned Acceleration, Deceleration, and Velocity will not reach Target as Jerk does.

## 7.6.4 Position


This section introduces the positioning process of motion control programming.

### 7.6.4.1 Types of Positions

The MC function blocks are composed of the following two types of positions:

1. Command position: The command position given by the motion function block.
2. Actual position: the feedback position from servo drives.

The figures below illustrate the relation between the command position and the actual position:



The following items are the same for the command position and the actual position.

| Type             | Definition  |
|------------------|---|
| Command position | The position output by the motion controller to servo drive |
| Actual position  | The position feedback from servo drive or encoder           |


Note: For axes configured as virtual, the command position is equal to the actual position.

## 7.6.5 Cam Tables and Framework

This section introduces electronic cam (E-CAM) operation as well as applications, and cam table generation as well as setting through DIADesigner-AX software. For detailed instructions, refer to the **AX Series Motion Controller Manual**.

### 7.6.5.1 E-CAM Framework

Adopt cam Editor of DIADesigner-AX for cam curve planning and download to PLC through communication protocols so that MC function blocks can be used to control cam.



### 7.6.5.2 E-CAM Establishment

The data that defines the relation between the master / slave (cam shaft) is called E-CAM data.

To use cam Editor of DIADesigner-AX, it is crucial to know the relation between master and slave positions via the following two methods.


Method 1: Obtain the connection between positions of master and slave axes based on E-CAM data setting.

Method 2: Measure the correspondence between positions of master and slave axes from actual work.


After the relationship between cam master and slave is confirmed, the slave axis position can be obtained based on the the master axis position.

- **Creating DIADesigner-AX cam tables**


1. Right-click **Application** on the left, select **Add Object**, and then select **Cam table**.




2. In the **Add Cam table** window, **Name** refers to the name of the cam table, which can be modified by yourself.



3. After clicking **Add**, you can see the **Cam** icon on the left.



4. Click **Cam table** on the **Cam** page.




5. On the **Cam Table** screen, you can add or delete cam data.

- Click to add new cam data
- Click to delete cam data
- X: Spindle Point
- Y: Slave Axis Point
- V: Slave Axis Speed
- A: Slave Axis Acceleration
- J: Slave Axis Jerk (Jerk)
- Segment Type: Curve Type

| Cam | Cam table | Tappets | Tappet table | X   | Y   | V | A | J | Segment Type | min(Position) | max(Position) | max( Velocity )    | max( Acceleration )  |
|-----|-----------|---------|--------------|-----|-----|---|---|---|--------------|---------------|---------------|--------------------|----------------------|
|     |           |         |              | 0   | 0   | 0 | 0 | 0 | Poly5        | 0             | 120           | 1.5120000000000007 | 0.032835282941414162 |
|     |           |         |              | 120 | 120 | 1 | 0 | 0 | Poly5        | 120           | 240           | 1                  | 0                    |
|     |           |         |              | 240 | 240 | 1 | 0 | 0 | Poly5        | 240           | 360           | 1.512              | 0.032835282941414141 |
|     |           |         |              | 360 | 360 | 0 | 0 | 0 |              |               |               |                    |                      |

6. Multiple tappets can be configured on the **Tappets** page, and several tappet points can be set for each tappet ID. After setting the **Tappet table**, a diagram which illustrates the relation between tappets and master axes would be shown on **Tappets** page. While dragging the points on **Tappets** page, the setting parameters on the **Tappet table** page change simultaneously.



7. You can configure tappets on Tappet table screen and use SMC\_GetTappetValue to read the status of the tappet, which can also be modified according to the settings in Tappet table and the direction when cam master passes the tappets.

- Click  to add a Track ID.
- Click  to delete Track ID.
- Track ID: track ID
- X: Tappet point position
- Positive pass: When forward rotation encounters the tappet point action, the action settings are as follows:
  - None: no action
  - Switch to ON: TRUE
  - Switch to OFF: FALSE
  - Invert: reverse
- Negative pass: When the reversal encounters the tappet point action, the action setting is as follows:
  - None: no action
  - Switch to ON: TRUE
  - Switch to OFF: FALSE
  - Invert: reverse

| Cam   | Cam table | Tappets | Tappet table |     |               |               |
|---|-----------|---------|--------------|-----|---------------|---------------|
|   |           |         | Track ID     | X   | positive pass | negative pass |
|  |           |         | 1            |     |               |               |
|  |           |         |              | 180 | switch ON     | switch OFF    |
|  |           |         |              | 360 | switch OFF    | none          |
|  |           |         | 2            |     |               |               |
|  |           |         |              | 90  | switch ON     | none          |
|  |           |         |              | 200 | invert        | switch OFF    |
|  |           |         |              |     |               |               |

## 7.7 Motion Control Functions

### 7.7.1 System Structure

The single axis motion instructions of MC function blocks can be used in three control modes - velocity control, position control, and torque control - to plan the motion trajectory of the axis according to the parameters set by the user.

The AX series controllers support the CoE (CANopen over EtherCAT) application protocol. According to the CiA402 standard, the motion modes supported include Cyclic Synchronous Position Mode, Cyclic Synchronous Velocity Mode, and Cyclic Synchronous Torque Mode, which will be further explained in the following sections.


### 7.7.2 Single-axis Control

#### 7.7.2.1 Cyclic Synchronous Position Mode

The data synchronization between AX series controllers and servo drives is accomplished via sync signal transmission from controllers to servo drives. These incoming data will not take effect until Distributed Clock (DC) in each servo drives are synchronized.

As shown in the figure below, four servo drives are connected and sent with control data at different timing ( $t_1$ ,  $t_2$ ,  $t_3$ ,  $t_4$ ) within one synchronous cycle ( $T$ ). However, the control data become valid only when all servo drives are synchronized with the SYNC event of the DC system.


\*1: Cyclic synchronous position mode is used for synchronous axes.



### 7.7.2.2 Profile Position Mode

After the servo drive receives the position command sent by the master device, it drives the motor to reach the target position. In profile position mode<sup>\*1</sup>, the master device only informs the drive of configuration about target position, velocity command, acceleration and deceleration at the beginning; the motion planning, from activation of command to achievement of target position, are executed by the trajectory generator inside servo drive.

\*1: The profile position mode is used for positioning axes.




### 7.7.2.3 Positioning

- Absolute positioning

The curve for motion planning is based on the input value set by the user and the current position. It enables the axis to move to the absolute coordinate of the target position with the origin as the reference point. In addition, the range of the absolute position for modulo axis is limited to the range of its rotation period. For more information, refer to the MC\_MoveAbsolute function block.

The motion trajectory of absolute positioning is shown in the figure below.



■ Rotary axes setting

- After selecting **Rotary Axis** for axis type, set the range of rotation for the rotary axis in **Modulo value**.


The screenshot displays the configuration interface for a rotary axis. On the left, a navigation pane lists 'General Setting', 'Commissioning', 'Homing Setting', 'SM\_Drive\_ETC\_Delta\_ASDA\_A2: IEC Objects', 'Status', and 'Information'. The main area is divided into several sections:

- Axis Type and Limits:** 'Modulo' is selected under 'Axis Type'. 'Linear Axis Software Limits' are set to 'Activated' with 'Negative [u]: 0' and 'Positive [u]: 1000'. 'Rotary Axis Modulo Settings' shows 'Modulo value [u]: 360'.
- Motion Parameter:** 'Velocity Ramp Type' is set to 'Trapezoid'. 'Error Reaction' has 'Quick Stop' checked. 'Dynamic Limits' are: Velocity [u/s]: 5, Acceleration [u/s²]: 100, Deceleration [u/s²]: 100, Jerk [u/s³]: 10000.
- Position Lag Supervision:** 'Position Lag Reaction' is 'Deactivated' and 'Lag Limit [u]: 1'.
- Transmission Mechanism:** 'Mechanism Type' is 'Ball Screw'. A diagram shows a motor (1) driving a gear (2) which meshes with another gear (3) on a shaft (4). 'Mechanism Settings' include '(1) Command pulse per motor rotation: 1280000 [ Pulse ]' and '(4) Pitch: 10000 [ Unit ]'.
- Gear Box:** 'Gear Ratio = (2) Gear ratio numerator / (3) Gear ratio denominator' is shown as 1/1.

● **Relative Positioning**

The curve for motion planning is based on the input value set by the user and the current position. It enables the axis to move to the relative coordinate of the target position in relation to the current actual position. For more information, refer to the MC\_MoveRelative function block.

The motion trajectory of relative positioning is shown in the figure below.



### 7.7.2.4 Stop Method

The stopping state can be achieved by giving motion control instructions, or enabling limit input which results in error stop.


- **Using motion control instructions to stop**

To stop single-axis movement, use MC\_Stop or MC\_Halt.

- **MC\_Stop**

- MC\_Stop stops the axis in motion according to the specified method and changes the axis state to **Stopping**.
- This instruction aborts any instructions in progress. When the axis state is **Stopping**, no instructions can be executed.
- The state **Stopping** continues until velocity reaches 0 or Execute becomes False. When velocity reaches 0, Done turns into True.
- When Done becomes True and Execute becomes False, the axis will enter **Standstill** state.

The motion trajectory of MC\_Stop is shown in the figure below. The velocity is determined according to the specified deceleration (Dt).



- **MC\_Halt**

- MC\_Halt temporarily stops the axis in motion and switches the axis state to **DiscreteMotion** until the axis velocity reaches 0. After the axis stops, the state turns into **Standstill**.
- During deceleration, other motion instructions can be executed to abort MC\_Halt operation.

- **Limit input stop**


- **Software limit**

Software limit can be activated / deactivated and configure its parameter settings on axis parameter setting page.


When the axis is approaching software limit, it will start decelerating based on the axis parameters and stop within the software limit.

Example:

- Set the positive limit to 10,000 and the negative limit to 0 with software limit **Activated**. Then set Deceleration to 1,000 (the item appears after Quick Stop is unchecked).




- Use function block MC\_MoveRelative and activate it after the position reaches 11,000. When the axis moves to around 8,000, Busy of the function block will shift from TRUE to FALSE while CommandAborted will shift from FALSE to TRUE. The axis then starts decelerating till stop within the software limit.



■ Hardware limit

As hardware signals are carried in the EtherCAT servo wires, the stop methods for hardware limit differ from manufacturers to manufacturers. In the following, Delta ASDA-A2-E is taken as an example for further explanation.


- Use MC\_Jog to perform forward rotation. Once the ahardware limit is reached during axis rotation, ASDA-A2-E servo drive will be stopped and error messages will be reported through communication.



After reaching software / hardware limit, you can use MC\_Reset to clear errors. The system will automatically synchronize the command position based on the values of the feedback position and keep the axis moving in the direction away from the limit so as to resume normal operation.


### 7.7.2.5 MC\_GearIn

Use MC\_GearIn instruction to control gear movements and MC\_GearOut instruction to cancel synchronization between master and slave axes. Please refer to the **AX Series Motion Controller Manual** for details about function blocks.



You can specify the master and slave axes, gear ratio numerator and denominator, acceleration and deceleration as well as jerk in MC\_GearIn.

- Execution order of instructions for electronic gears



When executing MC\_GearIn, the slave axis enters the state of synchronized motion; however, for MC\_GearOut execution, the slave axis gets out of the synchronized state, the slave axis will continue to move at the speed at the moment of separation, and the slave axis state machine enters Continuous Motion.


During synchronized motion, if executing MC\_Stop on the slave axis, MC\_GearIn will be aborted. The master axis maintains in Continuous Motion state while the slave axis enters Stopping state and will not return to Standstill until the MC\_Stop is Done.

When the slave axis is in the state of Synchronized motion, its velocity alters according to the velocity of the master axis through adjustment of gear ratio.


When the master axis and the slave axis are in synchronization state, use MC\_SetPosition to avoid accidents caused due to rapid rotational speed of motors.

- Set the gear ratio between master and slave axes through RatioNumerator and RatioDenominator in MC\_GearIn.


When the gear ratio is positive, the master and slave axes move in the same direction.



Conversely, when the gear ratio is negative, the master and slave axes move in opposite directions.



- Synchronization of master and slave axes is achieved when the slave axis velocity reaches the value set in the instruction.



When MC\_GearIn is enabled, the slave axis starts to engage with the master axis and its velocity is twice the master's velocity (RatioNumerator: RatioDenominator = 2:1).

When InGear is True, the master and slave axes are synchronized and the slave axis state enters Synchronized Motion.

When MC\_Stop is enabled, the master axis start decelerating and the slave axis also decelerates synchronously according to the gear ratio.


When MC\_Stop is in operation and MC\_GearOut is enabled, the master and slave axes are out of synchronization. The slave axis keeps moving at the velocity when synchronization is aborted and then enters the state of Continuous Motion.

### 7.7.2.6 MC\_GearInPos

MC\_GearInPos is adopted to assign the starting position for synchronization of master and slave axes.

- **MC\_GearInPos sequence**

In MC\_GearInPos, it is allowed to assign master axis and slave axis, gear ratio numerator and gear ratio denominator, synchronous starting position, master axis distance when starting synchronization and whether to enable reversal. The function block will automatically complete planning motion curve of the slave axis according to the settings, so as to engage the master and slave axes at the specified position.



The position where the master axis starts to synchronize is MasterSyncPosition (180) - MasterStartDistance (50). When the master axis reaches this position, StartSync ⇒ True starts to synchronize.


The slave axis generates a motion curve on its own based on other parameters. When the master axis reaches MasterSyncPosition (180), the slave axis also reaches SlaveSyncPosition (90). At this time, StartSync is False and InSync is True.

When MasterStartDistance ≤ 0, the function block is completed upon execution. In the meantime, the position of the slave axis jumps directly to the specified synchronous position.

If the slave reversal is not allowed, the user must set AvoidReversal to True.

### 7.7.2.7 MC\_CamIn

The slave axis synchronizes with the master axis based on cam table. You can use MC\_CamTableSelect to pre-assign the cam table to follow and designate master and slave axes. In addition, the instruction MC\_CamIn can be utilized for cam engagement whereas MC\_CamOut is used to remove gear engagement.



After engagement, synchronization between master and slave axes is achieved and the state of slave axis is Synchronized Motion. The following describes the information regarding E-CAM establishment:

- **Initial settings**

- Create E-CAM data

The E-CAM curve data can be drawn by the following two methods:

Method 1: The relation of master and slave positions is determined according to standard functions.


Method 2: The corresponding relation between the master and slave axes is measured in actual work.

- **Setting and operation of E-CAM master and slave axes**

By using MC\_CamIn and MC\_CamTableSelect, you can set up E-CAM master and slave axes and basic operation.

- Master and slave axes source setting

In function blocks, MC\_CamTableSelect and MC\_CamIn, the master source is determined by the input pin Master while the slave source is determined by the pin Slave\*1.



\*1: For information on pin function, refer to the **AX Series Motion Controller Manual**.



Relative mode (StartMode = 1): Cam changes in accordance with the current slave axis position. The slave position is derived by adding the current slave position. Also, Jump occurs when position at which the slave axis engages is different from the result of calculated starting position plus the current position.

Ramp mode (StartMode = 2, 3, 4): Add a curve for motion compensation based on VelocityDiff, Acceleration, Deceleration and Jerk to prevent Jemp during cam engagement.


| MC_CamTableSelect.MasterAbsolute | Master mode   |
|----------------------------------|---------------|
| absolute                         | Absolute mode |
| relative                         | Relative mode |

| MC_CamIn.StartMode | MC_CamTableSelect.SlaveAbsolute | Slave mode                    |
|--------------------|---------------------------------|-------------------------------|
| absolute           | True                            | Absolute mode                 |
| absolute           | False                           | Relative mode                 |
| relative           | True                            | Relative mode                 |
| relative           | False                           | Relative mode                 |
| ramp_in            | True                            | Ramp in Absolute mode         |
| ramp_in            | False                           | Ramp in Relative mode         |
| ramp_in_pos        | True                            | Forward Ramp in Absolute Mode |
| ramp_in_pos        | False                           | Forward Ramp in Relative mode |
| ramp_in_neg        | True                            | Reverse Ramp in Absolute mode |
| ramp_in_neg        | False                           | Reverse Ramp in Relative mode |


■ Offset and scaling (MasterOffset/MasterScaling/SlaveOffset/Slavescaling)

Although the cam relation between master and slave axis is pre-planned, during cam execution, you can still perform position offset or position scaling based on the relation via the parameters Offset or Scaling. For instance, only one kind of cam relation is required despite the fact that there are different sizes for the same product after being processed because you are able to change the parameters Offset and Scaling for adaption. The user can specify the offset and scaling factors for master and slave axes respectively.

The values of offset and scaling of the master and slave axes jointly determine the actual cam relation. The effect is described in the following example. Below is the preset cam relation:




When master and slave axes are in absolute mode and engaging with each other, the axis positions are both 0. Without offset and scaling (default), the cooresponding relation of actual master and slave positions during cam execution is shown in the figure below.



When the offset or scaling is not in default value, its influence on the corresponding relation between the actual position of master and slave axes during cam execution is drawn below:

- The influence of scaling ratio on relation between master and slave positions during cam execution when offset for both axes is 0:



7

**Case 1:** When the scaling ratio for master and slave is 1 and the offset is 0, the actual relation is consistent with the pre-planned one.

**Case 2:** When the scaling ratio for master is 1 and for slave is 2 with the offset as 0, the slave position in relation to the master position becomes twice the amount of the pre-planned one.


**Case 3:** When the master scaling ratio is 1, the slave scaling ratio is 0.5 and the offset is 0, the slave position in relation to the master position becomes half of the pre-planned value.

**Case 4:** When the master scaling ratio is 2, the slave scaling ratio is 1 and the offset is 0, the master position corresponding to the slave's becomes twice as planned. From the perspective of cam phase, the master cam phase is twice the amount of the pre-planned one, meaning that the master cam cycle changes from 360 to 180 while the slave cam phase remains unchanged.

**Case 5:** When the scaling ratio for master is 0.5 and for slave is 1 with the offset as 0, the master position corresponding to the slave position becomes half of the pre-planned one. From the perspective of cam phase, the master cam is half of the pre-planned one, meaning that the master cam cycle changes from 360 to 720 while the slave cam phase remains unchanged.

- The influence of offset on relation between master and slave positions during cam execution when scaling ratio for both axes is 1:

Master offset affects the horizontal movement of cam curves whereas slave offset affects the vertical movement of cam curves.




**Case 1:** When the scaling ratio is 1, the master offset is 0, and the slave offset is 60, the pre-planned value of the slave position corresponding to the master position is added 60. For instance, in the plan the master position is 180 and the slave position that corresponds is 180. But in the actual situation, the corresponding slave position is 240 ( $240=180+60$ ).

**Case 2:** When the scaling ratio is 1, the master offset is 90, and the slave offset is 0, the master position corresponding to the slave position offsets by 90 (adding offset value) based on the pre-planned value. For instance, in the plan the master position is 180 and the slave position that corresponds is 180; in the actual situation, the master position 90 corresponds to the slave position 180, which is the corresponding slave position of the pre-planned master position 180 ( $180=90+90$ ).

● **Cam Table**

By selecting **Cam** in DIADesigner-AX project tree, you can edit cam curve which determines the operation of slave cam.




■ **Features of cam curve table**

- The cam curve provides information on the movement of the corresponding slave axis at any time point including moving range, velocity, acceleration and jerk. The curve type between each key point can be set, for example, as straight line or quintic curve.
- By default, the master coordinate starts from 0 and end at 360, and can be modified according to the actual path.

■ Cam curve editing

- Graph editing in DIADesigner-AX:



Cam table is edited graphically. The abscissa indicates the master position and its length decides the range of cam operation. There are four curves above, which respectively represent position, velocity, acceleration and jerk (jump). In terms of cam design, curves that indicate position and velocity are used for motion range adjustment while curve representing acceleration are modified to achieve smoother movement.

- Cam table editing in DIADesigner-AX:

In addition to editing on graphics, the software allows revisions directly to cam table, including any increase or decrease on key points and positions.

| Cam X |           |         |              |   |   |         |          |          |           |           |
|-------|-----------|---------|--------------|---|---|---------|----------|----------|-----------|-----------|
| Cam   | Cam table | Tappets | Tappet table |   |   |         |          |          |           |           |
|       | X         | Y       | V            | A | J | Segm... | min(P... | max(P... | max( V... | max( A... |
|       | 0         | 0       | 0            | 0 | 0 |         |          |          |           |           |
| +     |           |         |              |   |   | Poly5   | 0        | 120      | 1.5120... | 0.0328... |
| +     | 120       | 120     | 1            | 0 | 0 |         |          |          |           |           |
| +     | 240       | 240     | 1            | 0 | 0 |         |          |          |           |           |
| +     |           |         |              |   |   | Poly5   | 240      | 360      | 1.512     | 0.0328... |
|       | 360       | 360     | 0            | 0 | 0 |         |          |          |           |           |


- Programming editing:

Users can also adopt function blocks to modify key points on cam table. But modifications through programming will not appear on software display accordingly.

Modification through the function block DMC\_CamWritePoint is as explained below:

- ① Specified cam table
- ① Execute function blocks


- ② Select the cam point number to be read
- ③ Position of cam master axis
- ④ Position of cam slave axis
- ⑤ Velocity of cam slave axis
- ⑥ Acceleration of cam slave axis



For details of function blocks, refer to the **AX Series Motion Controller Manual**.

■ Cam table properties

You can adjust the properties of cam table such as the starting and ending positions of master and slave axes, periodic parameters setup, required curve continuity and editing format on the **Properties** window.



■ E-Cam setup

1. Cam table configuration: set up the ranges for master and slave axes, create starting point, ending point and other key points, and adjust curve type.
2. Using MC\_CamTableSelect to connect the configured cam table to the actual one and obtain cam ID for further use in the following steps.
3. After obtaining cam ID, use MC\_CamIn to engage the specified master axis with the slave axis.
4. Use MC\_CamOut to terminate the master-slave relation. In addition, for synchronous movement, adopting MC\_Stop and MC\_Halt on the slave axis can stop synchronization between the axes.

■ Cam table switching

The reference cam table can be changed at runtime by using MC\_CAM\_REF to replace the reference cam table of MC\_CamTableSelect.

- Variable Declaration

```
P : MC_CAM_REF; //CamTable reference
CamTableID : INT; //CamTable Switch
```


- Switch cam table

```
CASE CamTableID OF
  0: P:=Cam;
  1: P:=Cam_1;
END_CASE
```


The example switches CamTableID to change MC\_CAM\_REF so as to switch between cam tables.

The two cam tables are as follows:


The first cam table (Cam)



The second cam table (Cam\_1)



Timing diagram for cam table switching



Switching the cam tables, the slave axis still follows the trajectory planned in the first table and turns to follow the trajectory of the second table until the master position reaches the next key point of the first table.

### 7.7.3 Velocity Control

Velocity control is classified into three servo control modes: Cyclic Synchronous Position (CSP), Cyclic Synchronous Velocity (CSV) and Profiel Velocity Mode.


#### 7.7.3.1 CSP Mode

As introduced in **Section 7.7.2.1**, the CSP mode stands for cyclic synchronous position mode. In this mode, the controller calculates the command position that it should reach in each cycle according to the assigned velocity (as well as acceleration, deceleration, and jerk), and then send the command position in every cycle to the servo for positioning.

If the current servo position falls behind the command position due to external interference, vibration occurs in order to compensate for the errors.

The application of function block MC\_MoveVelocity means executing velocity control in CSP mode, in which the axis will enter the continuous\_motion state. You can specify its acceleration, deceleration, and jerk before reaching the specified velocity or when buffering. MC\_Stop, MC\_Halt, or other instructions are used to stop the control mode when needed.

In the following diagram, MC\_MoveVelocity is used for velocity control and MC\_Halt is applied to stop it:




The velocity can be specified as 0. Although being stationary, the system is still in the state of continuous\_motion.

In the AX series, MC\_MoveVelocity can be used for single-axis velocity control in CSP mode. For details, please refer to the **AX Series Motion Controller Manual**.

### 7.7.3.2 CSV Mode

CSV mode stands for cyclic synchronous velocity mode. The velocity control is achieved by the controller calculating the velocity for each cycle according to the assigned velocity (as well as acceleration, deceleration, and jerk), and then send the command in each cycle to the servo for execution.




In this mode, there is no changes in velocity for compensation resulting from external interference like that in CSP mode since it is the command velocity given to the servo in each cycle.

In AX series, MC\_VelocityControl can be used for single-axis velocity control in CSV mode. For details of function blocks, refer to **AX Series Motion Controller Manual**.

### 7.7.3.3 Profile Velocity Mode

In profile velocity mode<sup>\*1</sup>, the motion trajectory is planned by the velocity trajectory generator based on the conditions such as velocity command, acceleration and deceleration specified by the host device.



\*1: This mode is used for positioning axes.

## 7.7.4 Torque Control


Torque control is classified into two servo control modes: Cyclic Synchronous Torque (CST) and Profile Torque (PT).

- **Profile Torque\*1 (PT)**


Use DMC\_TorqueControl to assign a single axis to continuously generate the specified torque output.

Precautions:

- When using DMC\_TorqueControl, the control mode is switched to cyclic synchronous torque mode.
- When using DMC\_TorqueControl, the control mode is switched to torque mode and function blocks regarding displacement or velocity are unavailable. Instead of using MC\_Stop to stop the motor, set DMC\_TorqueControl.Enable to False and you can stop it immediately.
- Torque cannot be set to 0. If so, DMC\_TorqueControl will be reported as error.
- The velocity of DMC\_TorqueControl can be utilized to set the maximum velocity for servo motors with the intention to avoid high-speed rotation as motor load declines in PT mode.
- Adopt TorqueRamp to set the torque change rate for achieving the target torque value.
- When Torque > 0, the motor runs in the forward direction.



- When Torque < 0, the motor runs in the reverse direction.



\*1:

ASDA-A3-E Series V1.1165 or later supports Profile Torque Mode.

ASDA-B3-E Series V1.0665 or later supports Profile Torque Mode.

## 7.7.5 Common Functions of Single-axis Control

The common functions of single-axis control are shown below.


### 7.7.5.1 Position Command

Positions in MC function modules can be subdivided into the following two types.

| Type             | Definition   |
|------------------|--|
| Command position | The function block output used to control the position of the axis |
| Actual position  | Feedback position from the servo drive*1                           |

\*1: If it is a virtual axis, since there is no position feedback from the servo drive, the command position directly substitutes for the actual position

The connection is drawn in the figure below:



Comparisons between the two types:

| Item           | Command Position  | Actual Position  |
|----------------|---|--|
| Counting mode  | Linear axis / rotary axis                                   | The same setting as in command position.                                 |
| Command unit   | Length unit (m, mm, inch...) / angle unit (degree) /...     | The same setting as in command position.                                 |
| Software limit | Set the limit of the position range for motion instructions | The same setting as in command position.                                 |
| Positioning    | Subject to be positioned to anywhere within a limited range | The same setting as in command position but possibly with position lag*1 |

\*1: Affected by the mechanism and servo settings, there may be subtle differences between command position and actual position, the so-called position lag. Position lag may increase slightly as the motion velocity increases. To control this gap, you can monitor position lag by adjusting axis settings and take actions in response to increasing position lag. There is no position lag when the actual position of a virtual axis equals its command position.

The relevant parameters are as follows:

- **Position unit**

The position unit refers to the command unit.

- **Setting of position lag**

| Setting                  | Value         | Definition   |
|--------------------------|---------------|--|
| Position lag supervision | deactivated   | Position lag is not checked.                                       |
|                          | disable drive | The axis is in Servo Off when position lag exceeds the set limit.  |
|                          | do quick stop | The axis is in quick stop when position lag exceeds the set limit. |
|                          | stay enabled  | The axis remains Servo On when position lag exceeds the set limit. |
| Lag limit [u]            | LREAL         | The limit of permissible error                                     |

Except for the value deactivated, the error SMC\_ERROR.SMC\_DI\_POSITIONLAGERROR will be reported when the limit of error is exceeded.

- **Software limits**

| Setting                   | Value               | Definition                        |
|---------------------------|---------------------|-----------------------------------|
| Software limits Activated | Checked / Unchecked | Whether to activate soft limits   |
| Negative [u]              | LREAL               | Soft limits in negative direction |
| Positive [u]              | LREAL               | Soft limits in positive direction |

- **Description of position in MC Function Modules**

There are two different descriptions for the input variables regarding position in MC function modules.

| Item     | Definition                          |
|----------|-------------------------------------|
| Position | Target position (absolute position) |
| Distance | Moving distance (relative position) |

- **Position monitoring**

Observation of position changes can be done by monitoring the following two axis variables (AXIS\_REF\_SM3 type).

| Variable Name | Position Type    | Data Type |
|---------------|------------------|-----------|
| .FSetposition | Command position | LREAL     |
| .fActPosition | Actual position  | LREAL     |

### 7.7.5.2 Velocity Command

There are two types of velocity in MC function modules.

| Type             | Definition   |
|------------------|--|
| Command velocity | The outputs of MC function modules is used to control the axis velocity                    |
| Actual velocity  | Velocity derived from the actual position provided by the servo drive at each time point*1 |

\*1: For virtual axis, since there is no servo drive, the command position will replace the actual position.

The relevant parameters are explained as follows:

- **Velocity unit**

The velocity unit: command unit/s.

- **Velocity ramp type**

| Setting            | Value              | Definition  |
|--------------------|--------------------|---|
| Velocity ramp type | Trapezoid          | The velocity curve is trapezoidal (the acceleration of each line segment is constant) |
|                    | Sin <sup>2</sup>   | Velocity curve as sin <sup>2</sup> function (fixed acceleration curve)                |
|                    | Quadratic          | The acceleration curve is trapezoidal (acceleration is limited by jerk) speed curve   |
|                    | Quadratic (smooth) | Same as Quadratic but the jerk (jump) curve is a continuous speed curve               |

- **Description of velocity in MC function modules**

The input variables related to speed in the motion function block are as follows:

| Item     | Definition        |
|----------|-------------------|
| Velocity | Target velocity*1 |

\*1: The target velocity might not be achieved due to inadequate trajectory length, poor acceleration and jerk, etc.

- **Velocity monitoring**

To observe the speed change, you can monitor the two axis variables (AXIS\_REF\_SM3 type):

| Variable Name | Type             | Data Type |
|---------------|------------------|-----------|
| .fSetVelocity | Command velocity | LREAL     |
| .fActVelocity | Actual velocity  | LREAL     |

### 7.7.5.3 Acceleration and Deceleration Command

Acceleration in MC function modules can be subdivided into the following two types.

| Position Type        | Definition  |
|----------------------|---|
| Command acceleration | Acceleration for axis control from the outputs of MC function modules |
| Actual acceleration  | Acceleration derived from actual the velocity                         |

The relevant parameters are explained as follows:

- **Acceleration unit**

The acceleration unit: command units/s<sup>2</sup>.

- **Acceleration ramp type**

Refer to **Section 7.7.5.2** of this manual.

- **Description of acceleration in MC function modules**

The input variables related to acceleration / deceleration in the MC function modules are as follows:


| Item         | Definition            |
|--------------|-----------------------|
| Acceleration | Target acceleration*1 |
| Deceleration | Target deceleration*1 |

\*1:

The target acceleration and deceleration might not be achieved due to inadequate trajectory length and jerk, etc.

The application standard of acceleration and deceleration is that when the absolute value of the current velocity needs to be reduced, Deceleration will be applied; on the contrary, when the absolute value of the current velocity needs to be increased, Acceleration will be applied.

For example, the following diagram depicts the velocity and acceleration curves under the situation when the current velocity is 500 and the motion command is in reverse direction (Velocity = 1000, Acceleration = 1200, Deceleration = 600):



- **Acceleration monitoring**

If observation of changes in acceleration is needed, you can monitor the following two axis variables (AXIS\_REF\_SM3 type):

| Variable          | Type                 | Data Type |
|-------------------|----------------------|-----------|
| .fSetAcceleration | Command acceleration | LREAL     |
| .fActAcceleration | Actual acceleration  | LREAL     |

### 7.7.5.4 Jerk Command

Jerk assigns the rate of changes in acceleration / deceleration. When the jerk is specified, the velocity ramp is in S-curve (the ramp is shown as increasing or decreasing without jerk), which reduces mechanical shock. There are two types of jerk:

| Type         | Definition   |
|--------------|--|
| Command jerk | The outputs of MC function modules used for jerk control |
| Actual jerk  | Jerk derived from the actual acceleration                |

The relevant parameters are described as follows:

- **Jerk unit**

The jerk unit: command unit/s<sup>3</sup>.

- **Jerk ramp type**


Refer to **section 7.7.5.2** of this manual.

- **Description of jerk in MC function modules**

The input variable related to jerk in MC function modules:

| Project | Function                  |
|---------|---------------------------|
| Jerk    | Target jerk <sup>*1</sup> |

\*1: When the velocity ramp type is Trapezoid or Sin2, the setting values of jerk are not applied in the movement; contrarily, when the velocity ramp type is Quadratic or Quadratic smooth, the setting values of jerk will affect the velocity ramp.



- **Jerk monitoring**

To observe changes in jerk, you can monitor the following two axis variables (AXIS\_REF\_SM3 type):

| Variable Name | location type | data type |
|---------------|---------------|-----------|
| .fSetJerk     | Command jerk  | LREAL     |
| .fActJerk     | Actual jerk   | LREAL     |

### 7.7.5.5 Axis Direction

The following cases require specified direction for operation:


- When the axis is moving at a constant velocity and the input value of velocity is an absolute value
- When the axis is set as a rotary one and is able to reach the target position in both forward and reverse directions

The input variables related to direction in MC function modules are as follows:

| Item      | Setting  | Definition  |
|-----------|----------|---|
| Direction | negative | Move in negative direction  |
|           | shortest | Move along the shortest path (only valid for rotary axis)                     |
|           | positive | Move in positive direction  |
|           | current  | Move along the current motion direction (only valid for rotary axis)          |
|           | fastest  | Move along the path which takes the least time (only valid for rotary axis)*1 |


\*1: shortest (moving distance) and fastest (moving time) are similar in concept, but not completely the same. Please refer to the following example:

- Settings:
  - Set the axis as rotary axis with a range of 360.
  - Set the velocity ramp type of the axis to Trapezoid.
- Steps:
  - Use MC\_MoveVelocity to move at constant velocity (velocity = 1000).
  - When the motor reaches 350 with the velocity coming to 1000, MC\_MoveAbsolute is executing twice respectively in different directions under the same circumstance.
    - Execute MC\_MoveAbsolute (Position=180, Velocity=Acceleration=Deceleration=1000, Direction=fastest).



When MC\_MoveAbsolute.Execute is triggered, the system determines that the least time-consuming direction to reach position 180 is to decelerate in positive direction to 0. The process takes about 1 second.

- Execute MC\_MoveAbsolute (Position = 180, Velocity = Acceleration = Deceleration = 1000, Direction = shortest).



When MC\_MoveAbsolute.Execute is triggered, the system determines that the shortest path to reach position 180 is to go in opposite direction ( $350 - 180 = 170$ ). However, it turns out to take more time because of reversal of the velocity during the process. The process takes about 2.5 seconds.

## 7.7.6 Axis Group Control

An axis group must consist of more than one axis to achieve axis group movement, which is configured via DIADesigner-AX. Up to six axes are supported for linear axes while three axes are supported by rotary axes with extra three axes as following axes.

### 7.7.6.1 Linear Interpolation

TransitionMode: Changing the interpolation trajectory while in motion may result in machine vibrations and noises. To alleviate the situation, it is suggested to apply the input variable TransitionMode.

- Available TransitionMode

| Mode    | Describe  |
|---------|---|
| None    | No effect (default)   |
| Overlap | Continue by combining the deceleration of the previous motion with the acceleration of the current motion |

- Buffer modes supported by TransitionMode

| Mode    | Aborting | Buffered | Blending Low | Blending Previous | Blending Next | Blending High |
|---------|----------|----------|--------------|-------------------|---------------|---------------|
| None    | A        | A        | N            | N                 | N             | N             |
| Overlap | A        | A        | D            | D                 | D             | D             |


A = Supported

N = Not supported


D = Continue with Blending mode

- TransitionMode

In the situation below, set the mode to None or Overlap and then select Buffered.




In the situation below, set the mode to Overlap and then select Blending. It is suggested referring to the deceleration and acceleration given to the motion function blocks of each axis group for planning.



### 7.7.6.2 Helical Interpolation

In helical interpolation, it supports three axes and performs X, Y, Z axes movement in a 3D system with three additional following axes.




- **Concept of following axes in axis group**


The following axes (A, B, C) move synchronously in a proportional manner as the axes (X, Y, Z) are moving.

The movement of the axis group starts from 0, in which the axes (X, Y, Z) move to (30, 40, 0) with a distance of 50 and the following axes move to (100, 200, 300). The following figures show the synchronous movements of each following axis:


- The following axis A



- The following axis B



- The following axis C



When the axes (X, Y, Z) stay still, the input velocity given to the axis group is instead applied to the following axis which keeps the longest distance; and, the other following axes will follow synchronously in proportion to the distance.

### 7.7.6.3 Stop Command for Axis Group

There are two ways to stop an axis group:

- **Programming stop**


Adopt DMC\_GroupStop in programming to decelerate and stop the axis group at its current position. At this time, the axis group state switches to GroupStopping in which no motion instruction can be executed.

The velocity for deceleration stop should be set to the IrDeceleration pin.

- **Error stop**

The axis group stops running once it encounters errors during movement.


For example, if Hardware Limit is reached while the axis group is in motion, the velocity drops to zero as a result of the output of CommandAborted.



## 7.7.7 High-speed I/O

This chapter provides information regarding I/Os including configurations as well as parameter settings.

### 7.7.7.1 I/O Configuration




The following configurations are available for high-speed I/Os on the CPU module:

- DIO: Filtering, polarity and other functions are set here. Details are in **Section 7.7.7.2**.
- SSI Encoder: SSI encoder, clock frequency and SSI data size are set here. Details are in **Section 7.7.7.3**.
- Pulse Encoder: Variable declaration of high-speed counter/ timer and pulse-type encoder and encoder Z inverse are set here. Details are in **Section 7.7.7.4**.
- Capture / Compare: Variable declarations of high-speed capture or high-speed comparator are set here. Details are in **Section 7.7.7.5**.

### 7.7.7.2 DIO Settings

This section introduces functions including filtering and polarity of I/Os on device with DIO.


Double-click **DIO** to enter the setting page.



- **Configuration**

| Function           | Description  |
|--------------------|--|
| ① Filter           | Set the filter time: default is NotFilter.<br>Drop-down list:<br>Not Filter, 0.1ms, 0.5ms, 1ms             |
| ② X0 Function Type | Set X0 Function Type, default is GeneralInput.<br>Drop-down list:<br>GeneralInput ` Stop/Start PLC Control |
| ③ Polarity         | Set the output Inverse, default is not reverse.<br>True: Reverse<br>False: Not Reverse                     |


- Stop / Start PLC Control



### 7.7.7.3 SSI Encoder Settings


AX Series PLC supports one set of SSI Encoder through Rx and Tx connection with the controller, providing 5V power input to support the encoder. User needs to set the Serial Communication Mode as SSI and activate DFB\_SSI\_Encoder. After setting up the preferred parameters, dataset can be received through the hardware channel.

- **SSI Encoder Structure**




- **Serial Communication Mode**

- Go to **Device > System Parameter** and select **SSI** in the **Serial Communication Mode** drop-down list.
- Parameter settings in the offline mode
- Effective after downloading



- **DFB\_SSI\_Encoder**



### 7.7.7.4 Pulse Encoder Settings


AX-8 Series PLC CPU supports:

- 1 differential input: A, B and Z encoder connecting to the PLC can be utilized to count / time the pulse value or the frequency of the encoder.
- 8 sets of open collector inputs: connecting through the blocks installed on the I/O board; up to 8 sets of high-speed counters / timers can be utilized to count or time the pulse value or the frequency of the encoder.

You need to enable pulse-type encoder function and set up the required parameters before you can receive data via the configured hardware channel.

The following section introduces the function modules of the pulse-type encoder. The maximum group of high-speed counters and timers supported by AX-8 is up to 9.

- **High-speed counter (Cnt)**




- **Differential input high-speed counting**

- Double-click **BuiltIn\_Pulse\_Encoder** to enter I/O Mapping setting page.

The screenshot shows the 'BuiltIn\_Pulse\_Encoder' configuration window. The left pane shows a tree view with 'BuiltIn\_Pulse\_Encoder' selected. The right pane displays a table of parameters:


| Parameter                     | Type                | Value     | Default Value | Unit | Description  |
|-------------------------------|---------------------|-----------|---------------|------|--|
| Pulse Encoder Parameters      |                     |           |               |      |  |
| Pulse Encoder input type      | Enumeration of BOOL | A/B Phase | A/B Phase     |      | A/B Phase or CW/CCW                                  |
| Pulse Encoder input direction | BOOL                | FALSE     | FALSE         |      | [TRUE]Inverse [FALSE]Normal                          |
| Pulse Encoder Z Inverse       | BOOL                | FALSE     | FALSE         |      | [TRUE]Inverse [FALSE]Normal                          |
| Pulse Encoder Filter Level    | USINT(1..100)       | 1         | 1             |      | Range : 1~100, if value is 1 then filter will closed |



■ Configuration.


| Function             | Description  |
|----------------------|--|
| Encoder Type         | Settings of the differential input encoder type, the default is A/B Phase.<br>Drop-down list: A/B Phase, CW/CCW  |
| Encoder direction    | Settings of the differential input encoder direction.<br>True: Reverse<br>False: Not Reverse   |
| Encoder Z Inverse    | Settings of the encoder Z inverse polarity; the default is not reverse.<br>True: Reverse<br>False: Not Reverse   |
| Encoder Filter Level | Settings of differential input filter level, setting range: 1~100. 1 stands for no filter and 100 represents moving average of the pulse input (including the 100th) within 100 periods.             |
| Counter              | Settings of PLC program variables and Channel Counter for Mapping. The differential input pulse count can be read through variables in the program.  |
| Reset                | Settings of PLC program variables and Channel Reset for Mapping. The differential input pulse count can be cleared through the upper source trigger variables in the program.<br>True → False: Valid |

■ Reset Diagram



● Differential input high-speed counting used in the program

- Add SMC\_FreeEncoder in the project and use SMC\_FreeEncoder.dEncoderPosition and Channel Counter for Mapping.




BuiltIn\_Pulse\_Encoder x

BuiltIn\_Pulse\_Encoder Parameters Find Filter Show all

| Variable                                     | Mapping | Channel | Address |
|--|---------|---------|---------|
| Application.SMC_FreeEncoder.dEncoderPosition |         | Counter | %ID±    |
|  |         | Reset   | %QX1.0  |

BuiltIn\_Pulse\_Encoder I/O Mapping

BuiltIn\_Pulse\_Encoder IEC Objects



BuiltIn\_Pulse\_Encoder


BuiltIn\_Pulse\_Encoder Parameters Find Filter Show all

| Variable                                      | Mapping | Channel | Address |
|---|---------|---------|---------|
| Application.SMC_FreeEncoder.diEncoderPosition |         | Counter | %ID8    |
|   |         | Reset   | %QX29.0 |

BuiltIn\_Pulse\_Encoder I/O Mapping

BuiltIn\_Pulse\_Encoder IEC Objects

- Use the **MC\_GearIn** function block in POU. The source of the master axis is SMC\_FreeEncoder.



● **Open collector input high-speed counting**

Setting and activation through DFB\_Counter. Maximum of 8 sets of high-speed counters / timers can be utilized to count or time the pulse value or the frequency of the encoder.

- DFB\_Counter



- Counter\_Mode


For example: Up to 8 sets of high-speed counting in Mode3. When Counter Number 0 is enabled, user can count up or down through the X0 input of I/O panel.

| Number | 0    | 1    | 2    | 3    | 4    | 5    | 6    | 7    |        |
|--------|------|------|------|------|------|------|------|------|--------|
| Mode 3 | U/D1 | U/D2 | U/D3 | U/D4 | U/D5 | U/D6 | U/D7 | U/D8 | 8 sets |
| Mode 4 | U/D1 | R1   | U/D3 | R3   | U/D5 | R5   | U/D7 | R7   | 4 sets |
| Mode 5 | U/D1 | DI 1 | R1   | S1   | U/D5 | DI 5 | R5   | S5   | 2 sets |
| Mode 6 | U1   | D1   | R1   | S1   | U5   | D5   | R5   | S5   | 2 sets |

### 7.7.7.5 Capture / Compare Settings


This section is about the function modules of capture and compare. A maximum of 4 groups of high-speed captures and one set of high-speed compare are supported by AX series motion controllers. The high-speed compare allows a maximum of 256 compare units.

- **Capture**




- **DFB\_Capture**

Here you can choose from X0~X3 to set up the TriggerDevice. For example, select X0 as trigger source and activate Capture function. As the X0 is triggered, the function block will capture the A and B impulse input value.



- **Compare**



- **DFB\_Compare**

After setting up the comparison position table and the output pulse length then activate the comparison function, the output Y0 will be enabled according to the pulse length. A maximum of 256 positions can be written into the table.



## 7.7.8 Other Features

### 7.7.8.1 Changing Current Position


- **MC\_SetPosition**

Execution on servo axis turns the current position into the specified target position; on the other hand, execution on encoder axis changes the current feedback position to the specified target position.

Change of the commanded current position also influence the current feedback position. The position lag between two positions remains unchanged.

This function block executes in the way of shifting the coordinate system without any displacement in servo or motor.


- **Timing Diagram**



### 7.7.8.2 Software Limit

In addition to hardware limit, software limit serves as another way to limit the range for axis movement.

Values of range for forward and reverse limit must be set in advance of activating software limit\*1. To avoid damage to the device resulting from inappropriate operation, software limit is not activated as default.



\*1 : For examples on Stop Method, refer to **Section 7.7.2.4**.

### 7.7.8.3 Position Lag Settings

The command position and the actual position reported back are 0 when the axis moves, and a runtime error is output when the difference between the command position and the reported actual position is too large.

By default, the position lag function is not enabled.

| Name          | Function  |
|---------------|---|
| Deactivated   | Not enabled.  |
| Disable drive | When the position lag exceeds the set limit, the axis shifts to Servo Off.  |
| Do quickstop  | When the position lag exceeds the set limit, the axis shifts to quick stop. |
| Stay enabled  | When the position lag exceeds the set limit, the axis remains Servo On.     |

The screenshot shows the configuration interface for the SM Drive ETC Delta ASDA A2. The 'Position Lag Supervision' section is highlighted with a red box, indicating the current settings: 'Position Lag Reaction' is set to 'Stay Enabled' and 'Lag Limit [u]' is set to '1'. Other visible settings include 'Velocity Ramp Type' (Trapezoid), 'Dynamic Limits' (Velocity: 5, Acceleration: 100, Deceleration: 100, Jerk: 10000), and 'Mechanism Settings' (Command pulse per motor rotation: 1280000, Pitch: 10000). The 'Transmission Mechanism' section shows a diagram of a ball screw mechanism with numbered callouts (1, 2, 3, 4) and a gear box configuration with 'Gear ratio numerator' and 'Gear ratio denominator' both set to 1.

### 7.7.8.4 Cam Switch


- **MC\_DigitalCamSwitch**

Designate the tappet position. It is True when the axis moves to the specified position and turns False when passing by. The following is an example in which two switches are used in the same track with MC\_DigitalCamSwitch instruction.

- Parameter setting

| Parameter           | Type | Switch1    | Switch2 |
|---------------------|------|------------|---------|
| TrackNumber         | INT  | 1          | 1       |
| FirstOnPosition [u] | REAL | 200        | 400     |
| LastOnPosition [u]  | REAL | 300        | -       |
| AxisDirection       | INT  | 0=Both     | 0=Both  |
| CamSwitchMode       | INT  | 0=Position | 1=TIME  |
| Duration            | TIME | -          | 2500ms  |

- Trigger and timing



- Switch1 on Track1 turns on when the position reaches 200 and turns off when reaching 300.
- Switch1 turns on again when the position reaches 400 but turns off after passing 2500ms.

### 7.7.8.5 Position Capture


In function block MC\_TouchProbe, a sensor is used as trigger signal. The current position of the servo is captured and recorded when a trigger event occurs.

For each axis it is allowed to set two trigger signals.

Plus, MC\_AbortTrigger is used to abort the capture function.

- **Function description**

- When the input pin Execute of the function block MC\_TouchProbe is True, only the effective position value of the first trigger signal will be captured and the subsequent signals are ignored.
- One function block instance only relates to one MC\_TouchProbe instruction. If there are multiple MC\_TouchProbe instances on the same axis, another TouchProbeID will be added to MC\_TRIGGER\_REF to distinguish different TouchProbe actions. TouchProbeID is also associated with MC\_AbortTrigger.
- The operation of window mask function in MC\_TouchProbe:



- For the first trigger signal input, the signal is not captured because the axis position has not reached the Window Mask section.
- For the second input, the signal is captured as the axis position has reached the Window Mask section. And the signal Done is output as True in the following cycle right after the capture is completed.

## 7.8 Programming Example

A programming example is elaborated in the following sections.

### 7.8.1 Device Framework

The following devices are applied in the example.

| Device      | Model Name      |
|-------------|-----------------|
| CPU         | AX-8            |
| Power       | DVP-PS02        |
| Servo drive | Delta ASDA-A2-E |
| Servo motor | Delta ECMA-C    |

#### 7.8.1.1 Utilization

Please refer to the following manuals for information regarding device configuration and wiring.

| Device                    | Reference  |
|---------------------------|--|
| CPU and power             | Chapter 2  |
| Server drive              | Delta servo drive manuals                                  |
| Wiring for EtherCAT slave | Delta ASDA A2-E EtherCAT Interface Servo Drive User Manual |


#### 7.8.1.2 Configuration

The following configuration is applied in the example.


| Device                  | Configuration Setting   |
|-------------------------|---|
| Controller              | The default settings in Chapter 2 in this manual are applied.                   |
| Motion control settings | Chapter 7   |
| Servo Parameters        | The default settings of ASDA-A2-E slave (gear ratio = 10000:10000) are applied. |

## 7.8.2 Examples


The following example takes the same POU in the EtherCAT task for demonstration. All variables used are declared and utilized in this POU task (the POU naming in LD and ST languages is different for demonstration purpose).



The time for EtherCAT synchronization is set to 4ms.



The electronic gear ratio is set to 10000:10000.



### 7.8.2.1 Servo On


In this example, when EtherCAT data communication is established, the MC\_Power (Servo On) instruction is executed to enable the servo drive. Ladder diagram (LD) and structured text (ST) languages are provided in the following example.

- Main variables used in programming

| Name             | Data Type    | Initial Value | Annotation  |
|------------------|--------------|---------------|---|
| SM_Drive_Virtual | AXIS_REF_SM3 | -             | Virtual Axis Variables                                      |
| Start            | BOOL         | FALSE         | When turning on the servo, switch to True to start Servo On |

- LD language

When Start is True, confirm whether the EtherCAT network communication works. If the communication is normal, enable MC\_Power via Servo On output. The activation is succeeded when Status is True.



- ST language

When Start is True, confirm whether the EtherCAT network communication works. If the communication is normal, enable MC\_Power via Servo On output. The activation is succeeded when Status is True.

At the same time, you can also observe the output status of the variables through monitoring window with no need to name the output variables.

```
IF Start THEN
    ServoOn :=TRUE;
ELSE
    ServoOn :=FALSE;
END_IF
```

```
//MC_Power
MC_Power_0(
    Axis:= SM_Drive_Virtual,
    Enable:= ServoOn,
    bRegulatorOn:= TRUE,
    bDriveStart:= TRUE,
    Status=> ,
    bRegulatorRealState=> ,
    bDriveStartRealState=> ,
    Busy=> ,
    Error=> ,
    ErrorID=> );
```


### 7.8.2.2 Resetting and Monitoring Single-axis Errors

In this example, the error information of variable state can be viewed through the watch table. Take MC\_MoveVelocity input as example. When the acceleration is set to 0, Execute is True and Error is True with the ErrorID status shown as Row Data 301, the error message SMC\_MV\_INVALID\_ACCDEC\_VALUES can be checked in the watch table. After troubleshooting is done, MC\_MoveVelocity functions well by shifting Execute from False to True. As for MC\_Reset, it is specially for servo error clearance. Ladder diagram (LD) and structured text (ST) languages are provided in the following example.


- **Main variables used in programming**

| Name                          | Data Type     | Initial Value | Annotation   |
|-------------------------------|---------------|---------------|--|
| SM_Drive_Virtual              | AXIS_REF_SM3  | -             | Virtual axis variables   |
| ServoOn                       | BOOL          | FALSE         | To enable MC_Power   |
| MC_MoveVelocity0_Execute      | BOOL          | FALSE         | Velocity command for Execute   |
| MC_MoveVelocity0_Acceleration | LREAL         | 0             | Velocity command for Acceleration, used to set acceleration                    |
| MC_DIRECTION.positive         | MC_Direction  | -             | Specify the moving direction as forward  |
| FBErrorOccured                | MC_ReadStatus | FALSE         | True when an error occurs  |
| ClearErr                      | BOOL          | FALSE         | When FBErrorOccured is True, SMC_ClearFBError can be triggered to clear errors |


- **Timing diagram**




● LD language



When an error occurs, the output FBErrorOccured of MC\_ReadStatus can be cleared via SMC\_ClearFBError. As the input to SMC\_ClearFBError is transmitted through pointers, it is necessary to add ADR (input variable) and use bool to clear the error flag in function block.



Disable Execute input in MC\_MoveVelocity to update the status of Error output.



Set the MC\_MoveVelocity acceleration to 10000 and then restart Execute to True. The output of MC\_MoveVelocity is Busy and the fSetVelocity and fSetPosition on the watch table are operating normally.

| Expression                    | Application        | Type      | Value              | Prepared v... | Executionpoint    | Address | Comment                    |
|-------------------------------|--------------------|-----------|--------------------|---------------|-------------------|---------|----------------------------|
| SM_Drive_Virtual.fSetPosition | Device.Application | LREAL     | 33520.000000000007 |               | Cyclic Monitoring |         | Parameter number: 1100, 1  |
| SM_Drive_Virtual.factVelocity | Device.Application | LREAL     | 10000              |               | Cyclic Monitoring |         | Parameter number: 1111, 10 |
| PLC_PRG.MC_MoveVelocity_0...  | Device.Application | SMC_ERROR | SMC_NO_ERROR       |               | Cyclic Monitoring |         | Error identification       |

● **ST language**

```

MC_MoveVelocity_0(
  Axis:= SM_Drive_Virtual,
  Execute:= MC_MoveVelocity0_Execute,
  Velocity:= 10000,
  Acceleration:= MC_MoveVelocity0_Acceleration,
  Deceleration:= 10000,
  Jerk:= 10000,
  Direction:= MC_DIRECTION.positive,
  InVelocity=> ,
  Busy=> ,
  CommandAborted=> ,
  Error=> ,
  ErrorID=>);
    
```

```

MC_ReadStatus_0(
  Axis:= SM_Drive_Virtual,
  Enable:= TRUE);
    
```

Set the MC\_MoveVelocity acceleration to 10000 and then restart Execute to True. The output of MC\_MoveVelocity is Busy and the fSetVelocity and fSetPosition on the watch table are operating normally.

```

MC_MoveVelocity_0(
  Axis:= SM_Drive_Virtual,
  Execute:= MC_MoveVelocity0_Execute,
    
```

```
Velocity:= 10000,  
Acceleration:= MC_MoveVelocity0_Acceleration := 10000,  
Deceleration:= 10000,  
Jerk:= 10000,  
Direction:= MC_DIRECTION.positive,  
InVelocity=> ,  
Busy=> ,  
CommandAborted=> ,  
Error=> ,  
ErrorID=> );
```

```
MC_ReadStatus_0(  
Axis:= SM_Drive_Virtual,  
Enable:= TRUE );
```

### 7.8.2.3 Monitoring Instruction Errors

In this example, if an error occurs while executing the MC\_Power (Servo On) instruction, no further processing will be performed. However, the ProgNext will indicate whether to proceed with the execution. Ladder diagram (LD) and structured text (ST) languages are provided in the following example.

- **Main variables used in programming**


| Name              | Data Type    | Initial Value | Annotation   |
|-------------------|--------------|---------------|--|
| SM_Drive_Virtual  | AXIS_REF_SM3 | -             | Virtual axis variables   |
| ServoOn           | BOOL         | FALSE         | To enable MC_Power   |
| ProgNext          | BOOL         | FALSE         | ProgNext indicates whether further execution is possible                 |
| MC_Power_0.Status | BOOL         | FALSE         | Axis is ready to move when the state is True                             |
| MC_Power_0.Busy   | BOOL         | FALSE         | Execution of function block has not yet completed when the state is True |

- **Timing diagram**



● **LD language**

Check if there is any error in MC\_Power before further processing.



● **ST language**

```

IF Start THEN
    ServoOn :=TRUE;
ELSE
    ServoOn :=FALSE;
END_IF

IF (MC_Power_0.Status=TRUE) OR (MC_Power_0.Busy=TRUE) THEN
    ProgNext :=TRUE;
ELSE
    ProgNext :=FALSE;
END_IF

//MC_Power
MC_Power_0(
    Axis:= SM_Drive_Virtual,
    Enable:= ServoOn,
    bRegulatorOn:= TRUE,
    bDriveStart:= TRUE,
    Status=> ,
    bRegulatorRealState=> ,
    bDriveStartRealState=> ,
    Busy=> ,
    Error=> ,
    ErrorID=> );
    
```


### 7.8.2.4 Quick Stop for Single Axis

In this example, if minor error occurs during the execution of MC\_MoveAbsolute (absolute positioning), use MC\_Stop to stop single-axis movement. Ladder diagram (LD) and structured text (ST) languages are provided in the following example.

- **Main variables used in programming**


| Name                     | Data Type    | Initial Value | Annotation   |
|--------------------------|--------------|---------------|--|
| SM_Drive_Virtual         | AXIS_REF_SM3 | -             | Virtual axis variables   |
| ServoOn                  | BOOL         | FALSE         | To enable MC_Power   |
| MC_MoveAbsolute0_Execute | BOOL         | FALSE         | Execute input of MC_MoveAbsolute                               |
| MC_DIRECTION.positive    | MC_Direction | -             | Specify the moving direction - forward (valid for rotary axis) |
| StopOn                   | BOOL         | FALSE         | Activate MC_Stop when the state is True                        |
| MC_Stop_0.Done           | BOOL         | FALSE         | MC_Stop is done when the state is True                         |

- **Timing diagram**



● **LD language**

Execute homing when the status of MC\_Power output is normal. Once homing is completed, execute MC\_MoveAbsolute (absolute positioning). If an emergency stop is in need, you can execute MC\_Stop where absolute positioning will be aborted with the state of CommandAborted output being True. At this time, the axis stops according to the assigned deceleration, and the Done output of MC\_Stop shifts to True after the stop instruction is completed.



● **ST language**

The process is the same as that of LD. After MC\_Home is finished, the state would be in StandStill.

```
//MC_Power
MC_Power_0(
    Axis:= SM_Drive_Virtual,
    Enable:= ServoOn,
    bRegulatorOn:= TRUE,
    bDriveStart:= TRUE,
    Status=> ,
    bRegulatorRealState=> ,
    bDriveStartRealState=> ,
    Busy=> ,
    Error=> ,
    ErrorID=> );

//MC_Home
IF MC_Power_0.Status THEN
    MC_Home_0(
        Axis:= SM_Drive_Virtual,
        Execute:= MC_Home_0_Execute,
        Position:= 0,
        Done=> ,
        Busy=> ,
        CommandAborted=> ,
        Error=> ,
        ErrorID=>);
END_IF
```

Execute MC\_Stop if an emergency stop is required during execution of MC\_MoveAbsolute. As a result, absolute positioning is aborted and the state would be in Stopping.

```
//MC_MoveAbsolute & MC_Stop
MC_MoveAbsolute_0(
    Axis:= SM_Drive_Virtual,
    Execute:= MC_MoveAbsolute0_Execute,
    Position:= 10000.0,
    Velocity:= 500.0,
    Acceleration:= 500.0,
    Deceleration:= 500.0,
    Jerk:= ,
    Direction:= MC_DIRECTION.positive,
    Done=> ,
    Busy=> ,
    CommandAborted=> ,
    Error=> ,
    ErrorID=>);
MC_Stop_0(
    Axis:= SM_Drive_Virtual,
    Execute:= StopOn,
    Deceleration:= 5000.0,
    Jerk:= ,
    Done=> ,
    Busy=> ,
    Error=> ,
    ErrorID=>);
```

### 7.8.2.5 Homing

Delta currently supports homing modes 0-35, and the OD used is 6098 (Homing method) / 6099sub1 (Speed during search for switch) / 6099sub2 (Speed during search for zero). For details, refer to the user manual **Delta AC Servo Drive ASDA-A2-E Series**.

In this section, the application of homing instruction is introduced with the example below.


Add A2-E servo to the EtherCAT slave, then specify the parameters of the abovementioned OD:

Homing method = 33 (perform homing once meeting Z pulse)

Speed during search for switch =1000[unit 1.0rpm] (search for limit switch at the speed of 100rpm)

Speed during search for z phase pulse=20[unit 0.1rpm] (search for zero at the speed of 2rpm)


After setup, execute MC\_Home in either LD or ST language with the cooresponding OD.



● **Main variables used in programming**


| Name    | Data Type    | Initial Value | Annotation          |
|---------|--------------|---------------|---------------------|
| Axis_1  | AXIS_REF_SM3 | -             | Real axis variables |
| ServoOn | BOOL         | FALSE         | To enable MC_Power  |

● **Timing diagram**



- **LD language**

Confirm that the output status of MC\_Power is normal and the state is in Standstill. Then execute MC\_Home with the state shifting to homing and back to Standstill after completion.



- **ST language**

The process is the same as that of LD. After MC\_Home is completed, the state returns to StandStill. The output status can be checked by assigning variables or through the watch table.

```
MC_Home_0(
  Axis:= Axis_1,
  Execute:= ,
  Position:= 0,
  Done=> ,
  Busy=> ,
  CommandAborted=> ,
  Error=> ,
  ErrorID=> );
```

```
MC_ReadStatus_0(
  Axis:= Axis_1,
  Enable:= TRUE,
  Valid=> ,
  Busy=> ,
  Error=> ,
  ErrorID=> ,
  Disabled=> ,
  Errorstop=> ,
  Stopping=> ,
  StandStill=> ,
  DiscreteMotion=> ,
  ContinuousMotion=> ,
  SynchronizedMotion=> ,
  Homing=> ,
  ConstantVelocity=> ,
  Accelerating=> ,
  Decelerating=> ,
  FBErrorOccured=>);
```

### 7.8.2.6 Absolute Positioning

The example below introduces the way to perform displacement at one speed via MC\_MoveAbsolute.

Ladder diagram (LD) and structured text (ST) languages are provided in the following example.

- Main variables used in programming


| Name                     | Data Type    | Initial Value | Annotation   |
|--------------------------|--------------|---------------|--|
| Axis_1                   | AXIS_REF_SM3 | -             | Real axis variables  |
| ServoOn                  | BOOL         | FALSE         | To enable MC_Power   |
| MC_MoveAbsolute0_Execute | BOOL         | FALSE         | Execute input of MC_MoveAbsolute                               |
| MC_DIRECTION.positive    | MC_Direction | -             | Specify the moving direction - forward (valid for rotary axis) |

- Timing diagram



- LD language

Confirm that the output status of MC\_Power is normal. Then execute MC\_MoveAbsolute to move from the starting position 0 to the assigned position 50000.



- **ST language**

```
MC_Home_0(  
  Axis:= Axis_1,  
  Execute:= ,  
  Position:= 0,  
  Done=> ,  
  Busy=> ,  
  CommandAborted=> ,  
  Error=> ,  
  ErrorID=> );
```

```
MC_MoveAbsolute_0(  
  Axis:= Axis_1,  
  Execute:= MC_MoveAbsolute0_Execute,  
  Position:= 50000,  
  Velocity:= 10000,  
  Acceleration:= 100000,  
  Deceleration:= 100000,  
  Jerk:= 100000,  
  Direction:= SM3_Basic.MC_DIRECTION.positive,  
  Done=> ,  
  Busy=> ,  
  CommandAborted=> ,  
  Error=> ,  
  ErrorID=> );
```

### 7.8.2.7 Switching Cam Tables during Cam Operation

The example shows how to switch cam table when the cam is in operation.


Add master and slave axes and create two MC\_CamIn instructions to switch between two cam tables. Different output parameters are configured for the two cams. Use CamTable1 when the instruction position of the master axis is below 3000 and switch to CamTable2 when the position exceeds 3000.

Two programming languages, ladder diagram (LD) and structured text (ST), are provided in the following example.


- **Main variables used in programming**

| Name             | Variable Type        | Initial Value | Annotation   |
|------------------|----------------------|---------------|--|
| Axis_Master      | AXIS_REF_VIRTUAL_SM3 | -             | Master-related axis variables  |
| Axis_Slave       | AXIS_REF_VIRTUAL_SM3 | -             | Slave-related axis variables   |
| CamTable1        | MC_CAM_REF           | -             | Relevant variables in cam table 1  |
| CamTable2        | MC_CAM_REF           | -             | Relevant variables in cam table 2  |
| StartFlag        | BOOL                 | FALSE         | If this variable is TRUE and communication with the axes is normal, Servo On will be activated with the subsequent actions being performed |
| MC_Power0_Status | BOOL                 | FALSE         | Variables of MC_Power output Status for master; TRUE when Servo On   |
| MC_Power1_Status | BOOL                 | FALSE         | Variables of MC_Power output Status for slave; TRUE when Servo On  |
| MC_Home0_Done    | BOOL                 | FALSE         | Variables of MC_Home output Done for master; TRUE when homing is completed   |
| MC_Home1_Done    | BOOL                 | FALSE         | Variables of MC_Home output Done for slave; TRUE when homing is completed  |
| MC_MoveAbs_Busy  | BOOL                 | FALSE         | Variables of MC_MoveAbsolute output Busy for master; TRUE when in execution  |
| CamTableSelect   | MC_CAM_REF           | -             | Variables of the corresponding cam table which is specified  |
| CamTable1_En     | BOOL                 | FALSE         | TRUE when CamTable1 is chosen  |
| CamTable2_En     | BOOL                 | FALSE         | TRUE when CamTable2 is chosen  |
| CamTableID       | MC_CAM_ID            | -             | The internal data structure of the selected cam table, which is from MC_CamTableSelect and used as MC_CamIn input                          |
| MC_CamIn1_InSync | BOOL                 | FALSE         | Variables of MC_CamIn output InSync in cam table 1; TRUE when master and slave cams are synchronized                                       |
| MC_CamIn2_InSync | BOOL                 | FALSE         | Variables of MC_CamIn output InSync in cam table 2; TRUE when master and slave cams are synchronized                                       |


● **CamTable1:**



● **CamTable2:**



● **Timing Diagram**



● LD language


Set StartFlag to True, then it will check whether the communication of the master axis and slave axes is normal or not.




If normal, the master and slave axes are then set to the state of Servo On.




If the master and slave axes are in the Servo On state with unsure starting point, perform homing once.




After homing of the master axis is completed, execute MC\_MoveAbsolute.




Use CamTable1 when the instruction position of the master axis is under 3000 (CamTable1\_En=True; CamTable2\_En=False); instead, choose CamTable2 when it is greater than 3000 (CamTable1\_En=False, CamTable2\_En=True). Set the respective cam table according to the instruction MC\_CamTableSelect.



When the master axis performs absolute positioning and CamTable1\_En=True, go with CamTable1.



When the master axis performs absolute positioning and CamTable2\_En=True, go with CamTable2.



- **ST language**

Set StartFlag to True, then it will check whether the communication of the master axis and slave axes is normal or not.

```
IF StartFlag = TRUE THEN
  IF Axis_Master.bCommunication = TRUE THEN
    MC_Power0_Enable := TRUE;
    MC_Power0_RegulatorOn := TRUE;
    MC_Power0_DriveStart := TRUE;
  END_IF

  IF Axis_Slave.bCommunication = TRUE THEN
    MC_Power1_Enable := TRUE;
    MC_Power1_RegulatorOn := TRUE;
    MC_Power1_DriveStart := TRUE;
  END_IF
END_IF
```

If normal, the master and slave axes are then set to the state of Servo On.

```
MC_Power_0(
  Axis:= Axis_Master,
  Enable:= MC_Power0_Enable,
  bRegulatorOn:= MC_Power0_RegulatorOn,
  bDriveStart:= MC_Power0_DriveStart,
  Status=> MC_Power0_Status,
  bRegulatorRealState=> ,
  bDriveStartRealState=> ,
  Busy=> ,
  Error=> ,
  ErrorID=> );
```

```
MC_Power_1(
  Axis:= Axis_Slave,
  Enable:= MC_Power1_Enable,
  bRegulatorOn:= MC_Power1_RegulatorOn,
  bDriveStart:= MC_Power1_DriveStart,
  Status=> MC_Power1_Status,
  bRegulatorRealState=> ,
  bDriveStartRealState=> ,
  Busy=> ,
  Error=> ,
  ErrorID=> );
```

If the master and slave axes are in the Servo On state with unsure starting point, perform homing once.

```
IF MC_Power0_Status = TRUE THEN
  MC_Home0_Execute := TRUE;
END_IF
IF MC_Power1_Status = TRUE THEN
  MC_Home1_Execute := TRUE;
END_IF
```

```

MC_Home_0(
  Axis:= Axis_Master,
  Execute:= MC_Home0_Execute,
  Position:= 0,
  Done=> MC_Home0_Done,
  Busy=> ,
  CommandAborted=> ,
  Error=> ,
  ErrorID=>);

```

```

MC_Home_1(
  Axis:= Axis_Slave,
  Execute:= MC_Home1_Execute,
  Position:= 0,
  Done=> MC_Home1_Done,
  Busy=> ,
  CommandAborted=> ,
  Error=> ,
  ErrorID=> );

```

After homing of the master axis is completed, execute MC\_MoveAbsolute.

```

MC_MoveAbsolute(
  Axis:= Axis_Master,
  Execute:= MC_Home1_Done,
  Position:= 6000,
  Velocity:= 500,
  Acceleration:= 1000,
  Deceleration:= 1000,
  Jerk:= ,
  Direction:= positive,
  Done=> MC_MoveAbs_Done,
  Busy=> MC_MoveAbs_Busy,
  CommandAborted=> ,
  Error=> ,
  ErrorID=> );

```

Use CamTable1 when the instruction position of the master axis is under 3000 (CamTable1\_En=True; CamTable2\_En=False); instead, choose CamTable2 when it is greater than 3000 (CamTable1\_En=False, CamTable2\_En=True). Set the respective cam table according to the instruction MC\_CamTableSelect.

```

IF Axis_Master.fSetPosition > 3000 THEN
  CamTableSelect := CamTable2;
  CamTable1_En := FALSE;
  CamTable2_En := TRUE;
ELSE
  CamTableSelect := CamTable1;
  CamTable1_En := TRUE;
  CamTable2_En := FALSE;
END_IF

```

```
IF (CamTable1_En = TRUE) OR (CamTable2_En = TRUE) THEN
    CamTable_En := TRUE;
END_IF
```

```
MC_CamTableSelect(
    Master:= Axis_Master,
    Slave:= Axis_Slave,
    CamTable:= CamTableSelect,
    Execute:= CamTable_En,
    Periodic:= TRUE,
    MasterAbsolute:= FALSE,
    SlaveAbsolute:= FALSE,
    Done=> MC_CamTableSelect_Done,
    Busy=> ,
    Error=> ,
    ErrorID=> ,
    CamTableID=> CamTableID);
```

When the master axis performs absolute positioning and CamTable1\_En=True, go with CamTable1.

```
IF (MC_MoveAbs_Busy = TRUE) AND (CamTable1_En = TRUE) THEN
    MC_CamIn_1(
        Master:= Axis_Master,
        Slave:= Axis_Slave,
        Execute:= TRUE,
        MasterOffset:= 0,
        SlaveOffset:= 0,
        MasterScaling:= 1,
        SlaveScaling:= 1,
        StartMode:= relative,
        CamTableID:= CamTableID,
        VelocityDiff:= 1000,
        Acceleration:= 1000,
        Deceleration:= 1000,
        Jerk:= ,
        TappetHysteresis:= ,
        InSync=> MC_CamIn1_Insync,
        Busy=> ,
        CommandAborted=> ,
        Error=> ,
        ErrorID=> ,
        EndOfProfile=> ,
        Tappets=> );
END_IF
```

When the master axis performs absolute positioning and CamTable2\_En=True, go with CamTable2.

```
IF (MC_MoveAbs_Busy = TRUE) AND (CamTable2_En = TRUE) THEN
    MC_CamIn_2(
        Master:= Axis_Master,
```


```

Slave:= Axis_Slave,
Execute:= TRUE,
MasterOffset:= 0,
SlaveOffset:= 0,
MasterScaling:= 1,
SlaveScaling:= 1,
StartMode:= relative,
CamTableID:= CamTableID,
VelocityDiff:= 1000,
Acceleration:= 1000,
Deceleration:= 1000,
Jerk:= ,
TappetHysteresis:= ,
InSync=> MC_CamIn2_Insync,
Busy=> ,
CommandAborted=> ,
Error=> ,
ErrorID=> ,
EndOfProfile=> ,
Tappets=> );

```

END\_IF

Based on the settings above, switch between two different cam tables when the master position is over 3000.



### 7.8.2.8 Executing Master Phase Offset during Cam Operation

After the slave axis is aborted during execution of MC\_phasing, it synchronizes with the master axis which is under control. When PhasingActive is True, execute MC\_Phasing to compensate the phase offset of the master axis. The slave axis will move synchronously after offset is done.


Two programming languages, ladder diagram (LD) and structured text (ST), are provided in the following example.

#### ● Main Variables Used in Programming


| Name                       | Variable Type        | Initial Value | Annotation  |
|----------------------------|----------------------|---------------|---|
| Axis_Master                | AXIS_REF_VIRTUAL_SM3 | -             | Master-related axis variables   |
| Axis_Slave                 | AXIS_REF_VIRTUAL_SM3 | -             | Slave-related axis variables  |
| CamTable                   | MC_CAM_REF           | -             | Relevant variables of cam table   |
| StartFlag                  | BOOL                 | FALSE         | If this variable is TRUE and axis communication is normal, Servo On will be activated with the subsequent actions being performed |
| MC_Power0_Status           | BOOL                 | FALSE         | Variables of MC_Power output Status for master; TRUE when Servo On  |
| MC_Power1_Status           | BOOL                 | FALSE         | Variables of MC_Power output Status for slave; TRUE when Servo On   |
| MC_Home0_Done              | BOOL                 | FALSE         | Variables of MC_Home output Done for master; TRUE when homing is completed  |
| MC_Home1_Done              | BOOL                 | FALSE         | Variables of MC_Home output Done for slave; TRUE when homing is completed   |
| MC_MoveVelocity_Velocity   | LREAL                | 500           | The target velocity for the master axis to move at a constant velocity  |
| MC_MoveVelocity_InVelocity | BOOL                 | FALSE         | The variables of MC_MoveVelocity output InVelocity; TRUE when the specified velocity reaches the target velocity                  |
| CamTableID                 | MC_CAM_ID            | -             | The internal data structure of the selected cam table, which is from MC_CamTableSelect and used as MC_CamIn input                 |
| MC_CamIn1_InSync           | BOOL                 | FALSE         | Variables of MC_CamIn output InSync in cam table 1; TRUE when master and slave cams are synchronized                              |
| PhasingActive              | BOOL                 | FALSE         | If this variable is TRUE and the cam is in InSync, MC_Phasing begins execution  |
| MC_Phasing_PhaseShift      | LREAL                | 500           | Specify the relative phase offset for the master axis and the slave axis  |
| MC_Phasing_Velocity        | LREAL                | 300           | Specify the relative velocity of the master axis and slave axis when performing phase offset                                      |

| Name            | Variable Type | Initial Value | Annotation  |
|-----------------|---------------|---------------|---|
| MC_Phasing_Done | BOOL          | FALSE         | The variable of MC_Phasing output Done; TRUE when phase offset is completed |

■ CamTable



● Timing diagram




● LD language

Set StartFlag to True, then it will check whether the communication of the master axis and the slave axis is normal or not.




If normal, the master and slave axes are then set to the state of Servo On.




7


If the master and slave axes are in the Servo On state with unsure starting point, perform homing once.




After homing of the master axis is completed, execute MC\_MoveVelocity.



After the master axis attains the target velocity, set the respective cam table based on MC\_CamTableSelect settings to execute cam motion.




If PhasingActive is True and the cam is synchronizing, it starts phase offset between the master axis and the slave axis. Where the original master-slave axis relationship in cam is broken, the slave axis starts phase synchronization with the master axis according to the setting of MC\_Phasing.



When performing phase offset of the master axis based on the settings above, the slave axis will synchronize with the phase after offset is done and the phase difference is fixed.

Take the cursor timing 3500-3000 in the figure as example, the PhaseShift is 500 and the velocity of the slave axis is 200 (velocity of the master axis 500 minus velocity 300) when offset is performed.



● **ST language**

Set StartFlag to True, then it will check whether the communication of the master axis and the slave axis is normal or not.

IF StartFlag = TRUE THEN

IF Axis\_Master.bCommunication = TRUE THEN

MC\_Power0\_Enable := TRUE;  
 MC\_Power0\_RegulatorOn := TRUE;  
 MC\_Power0\_DriveStart := TRUE;

END\_IF

IF Axis\_Slave.bCommunication = TRUE THEN

MC\_Power1\_Enable := TRUE;  
 MC\_Power1\_RegulatorOn := TRUE;  
 MC\_Power1\_DriveStart := TRUE;

END\_IF

END\_IF

If normal, the master and slave axes are then set to the state of Servo On.

MC\_Power\_0(  
 Axis:= Axis\_Master,  
 Enable:= MC\_Power0\_Enable,  
 bRegulatorOn:= MC\_Power0\_RegulatorOn,  
 bDriveStart:= MC\_Power0\_DriveStart,  
 Status=> MC\_Power0\_Status,  
 bRegulatorRealState=> ,  
 bDriveStartRealState=> ,  
 Busy=> ,

7

```
Error=> ,
ErrorID=> );
```

```
MC_Power_1(
  Axis:= Axis_Slave,
  Enable:= MC_Power1_Enable,
  bRegulatorOn:= MC_Power1_RegulatorOn,
  bDriveStart:= MC_Power1_DriveStart,
  Status=> MC_Power1_Status,
  bRegulatorRealState=> ,
  bDriveStartRealState=> ,
  Busy=> ,
  Error=> ,
  ErrorID=> );
```

If the master and slave axes are in the Servo On state with unsure starting point, perform homing once.

```
IF MC_Power0_Status = TRUE THEN
  MC_Home0_Execute := TRUE;
END_IF
```

```
IF MC_Power1_Status = TRUE THEN
  MC_Home1_Execute := TRUE;
END_IF
```

```
MC_Home_0(
  Axis:= Axis_Master,
  Execute:= MC_Home0_Execute,
  Position:= 0,
  Done=> MC_Home0_Done,
  Busy=> ,
  CommandAborted=> ,
  Error=> ,
  ErrorID=> );
```

```
MC_Home_1(
  Axis:= Axis_Slave,
  Execute:= MC_Home1_Execute,
  Position:= 0,
  Done=> MC_Home1_Done,
  Busy=> ,
  CommandAborted=> ,
  Error=> ,
  ErrorID=> );
```

After homing of the master axis is completed, execute MC\_MoveVelocity.

```
MC_MoveVelocity(
  Axis:= Axis_Master,
  Execute:= MC_Home0_Done,
  Velocity:= MC_MoveVelocity_Velocity,
```

```
Acceleration:= MC_MoveVelocity_Acc,  
Deceleration:= MC_MoveVelocity_Dec,  
Jerk:= ,  
Direction:= current,  
InVelocity=> MC_MoveVelocity_InVelocity,  
Busy=> ,  
CommandAborted=> ,  
Error=> ,  
ErrorID=> );
```

After the master axis attains the target velocity, set the respective cam table based on MC\_CamTableSelect settings to execute cam motion.

```
MC_CamTableSelect(  
  Master:= Axis_Master,  
  Slave:= Axis_Slave,  
  CamTable:= CamTable,  
  Execute:= TRUE,  
  Periodic:= TRUE,  
  MasterAbsolute:= FALSE,  
  SlaveAbsolute:= FALSE,  
  Done=> MC_CamTableSelect_Done,  
  Busy=> ,  
  Error=> ,  
  ErrorID=> ,  
  CamTableID=> CamTableID);
```

IF MC\_MoveVelocity\_InVelocity = TRUE THEN

```
  MC_CamIn_1(  
    Master:= Axis_Master,  
    Slave:= Axis_Slave,  
    Execute:= TRUE,  
    MasterOffset:= 0,  
    SlaveOffset:= 0,  
    MasterScaling:= 1,  
    SlaveScaling:= 1,  
    StartMode:= relative,  
    CamTableID:= CamTableID,  
    VelocityDiff:= 1000,  
    Acceleration:= 1000,  
    Deceleration:= 1000,  
    Jerk:= ,  
    TappetHysteresis:= ,  
    InSync=> MC_CamIn1_Insync,  
    Busy=> ,  
    CommandAborted=> ,  
    Error=> ,  
    ErrorID=> ,  
    EndOfProfile=> ,  
    Tappets=> );
```

END\_IF

If PhasingActive is True and the cam is synchronizing, it starts phase offset between the master axis and the slave axis. Where the original master-slave axis relationship in cam is broken, the slave axis starts phase synchronization with the master axis according to the setting of MC\_Phasing.

IF (PhasingActive = TRUE) AND (MC\_CamIn1\_Insync = TRUE) THEN

    MC\_Phasing\_Execute := TRUE;

END\_IF

MC\_Phasing(

    Master:= Axis\_Master,  
    Slave:= Axis\_Slave,  
    Execute:= MC\_Phasing\_Execute,  
    PhaseShift:= MC\_Phasing\_PhaseShift,  
    Velocity:= MC\_Phasing\_Velocity,  
    Acceleration:= MC\_Phasing\_Acc,  
    Deceleration:= MC\_Phasing\_Dec,  
    Jerk:= ,  
    Done=> MC\_Phasing\_Done,  
    Busy=> ,  
    CommandAborted=> ,  
    Error=> ,  
    ErrorID=> );

### 7.8.2.9 Changing Current Position in Movement


To change the current position of the axis in the coordinate system to the specified target position in movement, change the current feedback position to the specified target position. In this example, the interactive influence of the function blocks MC\_MoveRelative and MC\_SetPosition is explained.

Two programming languages, ladder diagram (LD) and structured text (ST), are provided in the following example.

- **Main variables used in programming**


| Name                    | Variable Type        | Initial Value | Annotation  |
|-------------------------|----------------------|---------------|---|
| Axis_Virtual            | AXIS_REF_VIRTUAL_SM3 | -             | Relevant variables of axis  |
| StartFlag               | BOOL                 | FALSE         | If this variable is TRUE and axis communication is normal, Servo On will be activated with the subsequent actions being performed |
| MC_Power0_Status        | BOOL                 | FALSE         | Variables of MC_Power output Status; TRUE when Servo On   |
| MC_Home0_Done           | BOOL                 | FALSE         | Variables of MC_Home output Done; TRUE when homing is completed   |
| MC_MoveRel_Distance     | LREAL                | 8000          | Target relative position of MC_MoveRelative   |
| MC_MoveRel_Done         | BOOL                 | FALSE         | Variables of MC_MoveRelative output Done; TRUE when relative positioning is complete  |
| MC_MoveRel_Busy         | BOOL                 | FALSE         | Variable of MC_MoveRelative output Busy; TRUE when the instruction is triggered and executed                                      |
| MC_SetPosition_Execute  | BOOL                 | FALSE         | If TRUE, MC_SetPosition is executed   |
| MC_SetPosition_Position | LREAL                | 3000          | The absolute position or relative distance changed by MC_SetPosition  |
| MC_SetPosition_Mode     | BOOL                 | TRUE          | MC_SetPosition is to set the axis position to be the absolute or relative position  |
| MC_SetPosition_Done     | BOOL                 | FALSE         | Variables of MC_SetPosition output Done; TRUE when position is modified   |

● Timing diagram




● LD language


Set StartFlag to True, then it will check whether the axis communication is normal or not.



If normal, set the axis to the state of Servo On.




If it is in the state of Servo On with unsure starting point, perform homing once.




After homing is completed, execute MC\_MoveRelative.


The target position for relative displacement = 8000.




When the current position of the axis passes 4000, execute MC\_SetPosition (Mode = Relative, Distance = 3000) and change the current position to be the specified target position.



According to the above settings, the current position of the axis in the coordinate system is changed to the relative target position in movement control, and the final position reaches 11000 as changed ( $11000 = 4000 + 3000 + (8000 - 4000)$ ). The execution has no influence on the displacement of the physical mechanism in MC\_MoveRelative operation, and the moving distance is the same as the set originally, which is 8000 ( $8000 = (4000 - 0) + (11000 - 7000)$ ).



The difference between the picture below and the picture above is that the Mode of MC\_SetPosition is changed to Absolute (Position = 3000), and the current position of the axis in the coordinate system is changed to the absolute target position, and the final position reaches 7000 after the change ( $7000 = 3000 + (8000 - 4000)$ ), the execution of the change command position will not affect the displacement of the physical movement mechanism in the MC\_MoveRelative operation, and the moving distance is the same as the original setting of 8000 ( $8000 = (4000 - 0) + (7000 - 3000)$ ).



### ● ST language

Set StartFlag to True, then it will check whether the axis communication is normal or not.

```
IF StartFlag = TRUE THEN
  IF Axis_Virtual.bCommunication = TRUE THEN
    MC_Power0_Enable := TRUE;
    MC_Power0_RegulatorOn := TRUE;
    MC_Power0_DriveStart := TRUE;
  END_IF
END_IF
```

If normal, set the axis to the state of Servo On.

```
MC_Power_0(
  Axis:= Axis_Virtual,
  Enable:= MC_Power0_Enable,
  bRegulatorOn:= MC_Power0_RegulatorOn,
  bDriveStart:= MC_Power0_DriveStart,
  Status=> MC_Power0_Status,
  bRegulatorRealState=> ,
  bDriveStartRealState=> ,
  Busy=> ,
  Error=> ,
  ErrorID=> );
```

If it is in the state of Servo On with unsure starting point, perform homing once.

```
IF MC_Power0_Status = TRUE THEN
    MC_Home0_Execute := TRUE;
END_IF
```

```
MC_Home_0(
    Axis:= Axis_Virtual,
    Execute:= MC_Home0_Execute,
    Position:= 0,
    Done=> MC_Home0_Done,
    Busy=> ,
    CommandAborted=> ,
    Error=> ,
    ErrorID=> );
```

After homing is completed, execute MC\_MoveRelative. The target position for relative displacement = 8000.

```
MC_MoveRelative(
    Axis:= Axis_Virtual,
    Execute:= MC_Home0_Done,
    Distance:= MC_MoveRel_Distance,
    Velocity:= MC_MoveRel_Velocity,
    Acceleration:= MC_MoveRel_Acc,
    Deceleration:= MC_MoveRel_Dec,
    Jerk:= ,
    Done=> MC_MoveRel_Done,
    Busy=> MC_MoveRel_Busy,
    CommandAborted=> ,
    Error=> ,
    ErrorID=> );
```

When the current position of the axis passes 4000, execute MC\_SetPosition (Mode = Relative, Distance = 3000) and change the current position to be the specified target position.

```
IF (MC_MoveRel_Busy = TRUE) AND (Axis_Virtual.fSetPosition >= 4000) THEN
    MC_SetPosition_Execute := TRUE;
END_IF
```

```
MC_SetPosition(
    Axis:= Axis_Virtual,
    Execute:= MC_SetPosition_Execute,
    Position:= MC_SetPosition_Position,
    Mode:= MC_SetPosition_Mode,
    Done=> MC_SetPosition_Done,
    Busy=> ,
    Error=> ,
    ErrorID=> );
```

### 7.8.2.10 Performing Superimposition during Gear Engagement

Perform MC\_MoveSuperImposed on the designated slave axis while the master and slave axes engage with each other. The final target position of the slave axis will be the relative displacement to the master axis according to the gear ratio plus the specific distance superimposed during movement.


Two programming languages, ladder diagram (LD) and structured text (ST), are provided in the following example.

- **Main variables used in programming**

| Name                       | Variable Type        | Initial Value | Annotation  |
|----------------------------|----------------------|---------------|---|
| Axis_Master                | AXIS_REF_VIRTUAL_SM3 | -             | Master-related axis variables   |
| Axis_Slave                 | AXIS_REF_VIRTUAL_SM3 | -             | Slave-related axis variables  |
| StartFlag                  | BOOL                 | FALSE         | If this variable is TRUE and axis communication is normal, Servo On will be activated with the subsequent actions being performed |
| MC_Power0_Status           | BOOL                 | FALSE         | Variables of MC_Power output Status for master; TRUE when Servo On  |
| MC_Power1_Status           | BOOL                 | FALSE         | Variables of MC_Power output Status for slave; TRUE when Servo On   |
| MC_Home0_Done              | BOOL                 | FALSE         | Variables of MC_Home output Done for master; TRUE when homing is completed  |
| MC_Home1_Done              | BOOL                 | FALSE         | Variables of MC_Home output Done for slave; TRUE when homing is completed   |
| MC_GearIn_InGear           | BOOL                 | FALSE         | Variables of MC_GearIn output InGear; TRUE when the engagement is completed   |
| MC_GearIn_RatioNumerator   | DINT                 | 2             | Numerator of the gear ratio between the master and slave axes   |
| MC_GearIn_RatioDenominator | UDINT                | 1             | Denominator of the gear ratio between the master and slave axes   |
| MC_MoveAbs_Execute         | BOOL                 | FALSE         | MC_MoveAbsolute is executed when this variable is TRUE,   |
| MC_MoveAbs_Position        | LREAL                | 3000          | Specify the absolute target position of the master axis   |
| MC_MoveAbs_Velocity        | LREAL                | 1000          | Specify the target velocity of the master axis  |

| Name                             | Variable Type | Initial Value | Annotation   |
|----------------------------------|---------------|---------------|--|
| MC_MoveAbs_Done                  | BOOL          | FALSE         | Variables of MC_MoveAbsolute output Done for master; TRUE when absolute positioning is completed.  |
| MC_MoveAbs_Busy                  | BOOL          | FALSE         | Variables of MC_MoveAbsolute output Busy for master; TRUE when the instruction is executed         |
| MC_MoveSuperImposed_Execute      | BOOL          | FALSE         | MC_MoveSuperImposed is executed when this variable is TRUE   |
| MC_MoveSuperImposed_Done         | BOOL          | FALSE         | Variables of MC_MoveSuperImposed output Done for slave; TRUE when superimposition is completed.    |
| MC_MoveSuperImposed_Distance     | LREAL         | 1000          | Specify the superimposed displacement of the slave axis  |
| MC_MoveSuperImposed_VelocityDiff | LREAL         | 1500          | Specify the relative velocity of the slave axis during superimposition compared to the master axis |

● Timing diagram




● LD language


Set StartFlag to True, then it will check whether the communication of the master axis and the slave axis is normal or not.




If normal, the master and slave axes are then set to the state of Servo On.




If the axes are in the state of Servo On with unsure starting point, perform homing once.




After homing of the master axis is completed, execute MC\_GearIn to establish gear synchronization between the axes.



Right after the engagement InGear is completed, execute MC\_MoveAbsolute on the master axis.



As for the slave axis, MC\_MoveSuperImposed is executed when it moves in the manner of engagement to the preset triggering position 2000, in which the slave axis will move at a distance of the preset target position derived from the original gear ration plus the superimposed displacement.



Based on the settings above, the slave axis moves at a velocity set when superimposition is implemented on it and to the final target position which is the relative displacement to the master axis according to the gear ratio plus the specific distance superimposed during movement.

In the figure below, the moving distance of the master axis is 3000. As for the slave axis, its original target position is 6000 as derived from the gear ratio of 1:2; however, the target position increases to 7000 because an extra distance of 1000 is superimposed on the slave axis. During engagement, the master axis moving at the velocity 1000 and the slave axis at 2000. Yet, the velocity of the slave axis becomes 3500 (original velocity 2000 plus VelocityDiff 1500) during superimposition.



- **ST language**

Set StartFlag to True, then it will check whether the communication of the master axis and the slave axis is normal or not.

```
IF StartFlag = TRUE THEN
```

```
  IF Axis_Master.bCommunication = TRUE THEN
```

```
    MC_Power0_Enable := TRUE;
```

```
    MC_Power0_RegulatorOn := TRUE;
```

```
    MC_Power0_DriveStart := TRUE;
```

```
  END_IF
```

```
  IF Axis_Slave.bCommunication = TRUE THEN
```

```
    MC_Power1_Enable := TRUE;
```

```
    MC_Power1_RegulatorOn := TRUE;
```

```
    MC_Power1_DriveStart := TRUE;
```

```
  END_IF
```

```
END_IF
```

If normal, the master and slave axes are then set to the state of Servo On.

```
MC_Power_0(
```

```
  Axis:= Axis_Master,
```

```
  Enable:= MC_Power0_Enable,
```

```
  bRegulatorOn:= MC_Power0_RegulatorOn,
```

```
  bDriveStart:= MC_Power0_DriveStart,
```

```
  Status=> MC_Power0_Status,
```

```
  bRegulatorRealState=> ,
```

```
  bDriveStartRealState=> ,
```

```
  Busy=> ,
```

```
  Error=> ,
```

```
  ErrorID=> );
```

```
MC_Power_1(
```

```
Axis:= Axis_Slave,  
Enable:= MC_Power1_Enable,  
bRegulatorOn:= MC_Power1_RegulatorOn,  
bDriveStart:= MC_Power1_DriveStart,  
Status=> MC_Power1_Status,  
bRegulatorRealState=> ,  
bDriveStartRealState=> ,  
Busy=> ,  
Error=> ,  
ErrorID=> );
```

If the axes are in the state of Servo On with unsure starting point, perform homing once.

```
IF MC_Power0_Status = TRUE THEN  
    MC_Home0_Execute := TRUE;  
END_IF
```

```
IF MC_Power1_Status = TRUE THEN  
    MC_Home1_Execute := TRUE;  
END_IF
```

```
MC_Home_0(  
    Axis:= Axis_Master,  
    Execute:= MC_Home0_Execute,  
    Position:= 0,  
    Done=> MC_Home0_Done,  
    Busy=> ,  
    CommandAborted=> ,  
    Error=> ,  
    ErrorID=> );
```

```
MC_Home_1(  
    Axis:= Axis_Slave,  
    Execute:= MC_Home1_Execute,  
    Position:= 0,  
    Done=> MC_Home1_Done,  
    Busy=> ,  
    CommandAborted=> ,  
    Error=> ,  
    ErrorID=> );
```

After homing of the master axis is completed, execute MC\_GearIn to establish gear synchronization between the axes.

```
MC_GearIn(  
    Master:= Axis_Master,  
    Slave:= Axis_Slave,  
    Execute:= MC_Home0_Done,  
    RatioNumerator:= MC_GearIn_RatioNumerator,  
    RatioDenominator:= MC_GearIn_RatioDenominator,  
    Acceleration:= MC_GearIn_Acc,  
    Deceleration:= MC_GearIn_Dec,
```

```

Jerk:= ,
InGear=> MC_GearIn_InGear,
Busy=> ,
CommandAborted=> ,
Error=> ,
ErrorID=> );

```

```

IF MC_GearIn_InGear = TRUE THEN
  MC_MoveAbs_Execute := TRUE;
END_IF

```

Right after the engagement InGear is completed, execute MC\_MoveAbsolute on the master axis.

```

MC_MoveAbsolute(
  Axis:= Axis_Master,
  Execute:= MC_MoveAbs_Execute,
  Position:= MC_MoveAbs_Position,
  Velocity:= MC_MoveAbs_Velocity,
  Acceleration:= MC_MoveAbs_Acc,
  Deceleration:= MC_MoveAbs_Dec,
  Jerk:= ,
  Direction:= Positive,
  Done=> MC_MoveAbs_Done,
  Busy=> MC_MoveAbs_Busy,
  CommandAborted=> ,
  Error=> ,
  ErrorID=> );

```

As for the slave axis, MC\_MoveSuperImposed is executed when it moves in the manner of engagement to the preset triggering position 2000, in which the slave axis will move at a distance of superimposing the specified displacement on the preset target position of the original gear ratio.

```

IF MC_MoveAbs_Busy = TRUE THEN
  IF Axis_Slave.fSetPosition >= 2000 THEN
    MC_MoveSuperImposed_Execute := TRUE;
  END_IF
END_IF

```

```

MC_MoveSuperImposed(
  Axis:= Axis_Slave,
  Execute:= MC_MoveSuperImposed_Execute,
  Distance:= MC_MoveSuperImposed_Distance,
  VelocityDiff:= MC_MoveSuperImposed_VelocityDiff,
  Acceleration:= MC_MoveSuperImposed_Acc,
  Deceleration:= MC_MoveSuperImposed_Dec,
  Jerk:= ,
  Done=> MC_MoveSuperImposed_Done,
  Busy=> ,
  CommandAborted=> ,
  Error=> ,
  ErrorID=> );

```

**MEMO**

---

## Chapter 8 OPC UA Server

### Table of Contents

|            |   |            |
|------------|---|------------|
| <b>8.1</b> | <b>OPC UA Server .....</b>  | <b>8-2</b> |
| 8.1.1      | Creating a Project for OPC UA Access .....                        | 8-2        |
| <b>8.2</b> | <b>Connection Settings.....</b>                                   | <b>8-4</b> |
| 8.2.1      | Setting Up a Connection with UaExpert.....                        | 8-4        |
| <b>8.3</b> | <b>Setting Up an Encrypted Connection.....</b>                    | <b>8-7</b> |
| 8.3.1      | Setting Up User Account and Password .....                        | 8-7        |
| 8.3.2      | CODESYS Security Agent .....                                      | 8-8        |
| 8.3.3      | Setting Up an Encrypted Connection with Prosys OPC UA Client..... | 8-10       |
| 8.3.4      | Setting Up an Encrypted Connection with UaExpert.....             | 8-14       |

## 8.1 OPC UA Server

The standard installation of DIADesigner-AX includes an OPC UA server. You can use it to access the variable interface of the controller via a client. The OPC UA server communicates with connected OPC UA clients over a separate TCP connection. Therefore, the connections should be examined again separately for security purpose. Currently the OPC UA server can be safeguarded by using encrypted communication to protect the client and OPC UA user management. Details about the settings can be found in the following sections.


Below are features supported by the OPC UA server:

- Browse through data types and variables
- Standard read / write services
- Notification of value changes (focus on subscription and monitored items)
- Encrypted communication according to OPC UA standard (profile: Basic256SHA256)

### 8.1.1 Creating a Project for OPC UA Access


Before using OPC UA server, the first thing is creating a project for OPC UA access. Follow the steps below:

1. Create a new DIADesigner-AX project.
2. Declare some variables of different types in **PLC\_PRG** program.




| Expression | Type                  | Value | Prepared value | Address | Comment |
|------------|-----------------------|-------|----------------|---------|---------|
| wval1      | WORD                  | 0     |                |         |         |
| dwval2     | DWORD                 | 0     |                |         |         |
| bval3      | BOOL                  | FALSE |                |         |         |
| anyval4    | ARRAY [0..20] OF B... |       |                |         |         |


3. Go to **Application > Add Object > Symbol Configuration** to add a Symbol Configuration object.




4. Select **Support OPC UA features** and then click **Add** on the setting page of **Add Symbol Configuration**.



5. The tab **Symbol Configuration** appears in the setting window with a warning message. Click **Build** then the projects and variables are displayed in a tree structure. The warning message disappears after the click.



6. Select the variables whereof configuration and monitoring by OPC UA clients are allowed. Specify the access rights of each variable and then click **Build** again to complete the setting.



7. Lastly, download the project to the AX-8 Series PLC.

## 8.2 Connection Settings


### 8.2.1 Setting Up a Connection with UaExpert

Connect the client to the OPC UA server using unencrypted connection. The following illustrates how to set up the connection between the OPC UA server and the client, **UaExpert**. The steps can also be applied to other OPC UA clients.


The OPC UA client, UaExpert, is freely accessible here:

<https://www.unified-automation.com/downloads/opc-ua-clients.html>.

1. Double-click  to start **UaExpert**.
2. Right-click **Servers** and then click **Add** to open the **Add Server** window.




3. Go to **Custom Discovery** > **<Double click to Add Server...>** > **Enter URL:** enter **opc.tcp://192.168.0.10** and click **OK**.




8


4. The window below pops up right after. You can find **AX-816E** under **opc.tcp://192.168.0.10**. Click **OK** to close the window. As mentioned, we are using the unencrypted connection so only the node **None-None** is detected.




5. To edit the server properties, go back to the starting page. Expand the option under **Project**. Then right-click **OPCUAServer@X82ME1Txxxx** and select **Properties...** to open the **Server Settings** window.




- Rewrite **Endpoint Url** as **opc.tcp://192.168.0.10:4840**. Click **OK** to close the window.



- Right-click **OPCUAServer@X82ME1Txxxx** and select **Connect** on the context menu.



- After the connection is built, you are able to change the variables via OPC UA client. Drag the variable you would like to modify from **Address Space** to **Data Access View**. Then double-click the variables in the column **Value** to edit.




## 8.3 Setting Up an Encrypted Connection

To have a secure and encrypted connection, it is recommended to follow the instructions below to create certificates for OPC UA server and OPC UA client.

### 8.3.1 Setting Up User Account and Password

Account and password setup for OPC UA server is the same as the way for controller. Refer to **section 4.2.1.8** of this manual for more information.


Below is an example of setting up a new account as guest. The default account is Administrator. And here you can see two accounts in the image.




### 8.3.2 CODESYS Security Agent

In order to encrypt data and exchange it with the client safely, when the connection is established for the first time, a certificate which has been classified as trusted by the client is required for the OPC UA server. And, CODESYS Security Agent is indispensable for creating a certificate for DIADesigner-AX


1. Visit CODESYS Store to download the software for free:  
<https://store.codesys.com/matrikon-flex-opc-ua-editor.html? SID=U>
2. Install the add-on  **CODESYS Security Agent**. After installation, you should restart DIADesigner-AX. The window after installation is as shown below:




3. Open DIADesigner-AX to create a project. Click **View** on the toolbar and then select **Security Screen** to open the setting page.




4. Select the **Devices** tab.




5. Click  to refresh and all services that require a certificate are listed on the right-hand side of the window.




6. Click  to open the **Certificate Settings** window for creating a new certificate for the device.
- a. Click the service **OPU UA Server (not available)**.



- b. Select **Encrypted Application**.



7. Then you have created two certificates **OPC UA Server** and **Encrypted Application** on the controller\*1.



\*1: You need to power off the controller and restart again to enable the certificates.


### 8.3.3 Setting Up an Encrypted Connection with Prosys OPC UA Client

In this section, we use **Prosys OPC UA Client V3.2.0** as an example for connection to the OPC UA server. The following illustrates how to set up the connection and the steps can also be applied to other OPC UA clients.


The OPC UA client, **Prosys OPC UA Client**, is freely accessible here:

<https://downloads.prosysopc.com/opc-ua-client-downloads.php>.


1. Double-click  to start **Prosys OPC UA Client**.
2. Type in the OPC UA Server IP address **opc.tcp://192.168.0.10:4840** in the field of **Disconnected** as shown in ①.




3. Click ③  to open the **Security Settings** window (only the connection type **Basic256SHA256** is supported). Check **Show only modes that are supported by the server** and select both **Sign & Encrypt** and **Basic256SHA256** in the window. Then click **OK**.




After click **OK**, you will see a warning message **Untrusted certificate error**, stating that **the server does not accept this application's certificate**.





4. Click ④  to set up **Username and Password** in the **User Authentication** setting window. Click **Apply** after the setting is done and then click ②  to connect to the controller.



You will see a warning message **Untrusted certificate error** stating that the server does not accept this application's certificate. It is because ProsysOpcUaClient is not a trusted certificate for the AX-8 Series PLC.




5. To deal with the error described in point 3 and 4, go back to DIADesigner-AX. Click **View** on the toolbar and go to **Security Screen > Quarantined Certificates**. Find **ProsysOpcUaClient** and drag it to the folder **Trusted Certificates**. Note that you must make sure the AX-8 Series PLC has been connected to the software beforehand.




6. Back to ProsysOpcUaClient and you can find the connection to OPC UA Server showed in ⑤. Then you can edit the settings in the controller through ProsysOpcUaClient in ⑥.

- a. User: Administrator



b. User: Guest (not authorized to write)




### 8.3.4 Setting Up an Encrypted Connection with UaExpert


In this section, we use **UaExpert V1.5** as an example to connect to the OPC UA server. The following illustrates how to set up the connection and the steps can also be applied to other OPC UA clients.

The OPC UA client, UaExpert, is freely accessible here:  
<https://www.unified-automation.com/downloads/opc-ua-clients.html>.

1. Double-click  to start UaExpert.
2. Right-click **Servers** and then click **Add** to open **Add Server** window.




3. Go to **Custom Discovery** > **<Double click to Add Server...>** > **Enter URL**: enter `opc.tcp://192.168.0.10` and click **OK**.




8


4. The window below pops up right after. You can find **AX-816E** under **opc.tcp://192.168.0.10**. Select **Basic256Sha256** and set up **Username** and **Password** in the **Authentication Settings** field. Click **OK** to create an encrypted connection.




5. To edit the server properties, go back to the starting page. Expand the option under **Project**. Then right-click **OPCUAServer@X8xxxxxx** and select **Properties...** to open the **Server Settings** window.



- Rewrite the **Endpoint Url** as **opc.tcp://192.168.0.10:4840**. Click **OK** to close the window.




- Right-click **OPCUAServer@X8xxxxxx** and select **Connect** on the context menu.




8


8. You will see a warning message as shown below. Click **Trust Server Certificate**.



9. Go back to DIADesigner-AX. Click **View** on the toolbar and open **Security Screen** setting page. Select the **Devices** tab to find **UaExpert** under **Quarantined Certificates**. Drag **UaExpert** to the folder **Trusted Certificates**.



- Repeat step 7 to connect to the OPC UA server as an administrator. After the connection is established, you will see the tree node on the left side and the settings in the controller can be edited through UaExpert.



---

## Chapter 9 Communication

### Table of Contents

|            |  |             |
|------------|--|-------------|
| <b>9.1</b> | <b>Introduction to EtherCAT Communication.....</b>       | <b>9-3</b>  |
| 9.1.1      | Features of EtherCAT Fieldbus .....                      | 9-3         |
| 9.1.2      | Setting Up EtherCAT Master .....                         | 9-4         |
| 9.1.3      | Setting Up EtherCAT Slave .....                          | 9-6         |
| 9.1.4      | Backup Parameters for EtherCAT Slaves .....              | 9-9         |
| 9.1.4.1    | Data Backup Procedure .....                              | 9-9         |
| 9.1.4.2    | Introduction to Backup and Restore .....                 | 9-10        |
| 9.1.4.2.1  | Operation for Backup Function .....                      | 9-12        |
| 9.1.4.2.2  | Operation for Restore Function .....                     | 9-14        |
| <b>9.2</b> | <b>Introduction to Modbus Serial Communication .....</b> | <b>9-16</b> |
| 9.2.1      | Modbus Serial Port .....                                 | 9-16        |
| 9.2.1.1    | Adding Delta Modbus COM .....                            | 9-16        |
| 9.2.1.2    | Setting Up Delta Modbus COM .....                        | 9-19        |
| 9.2.2      | Modbus Serial Master .....                               | 9-21        |
| 9.2.2.1    | Adding Delta Modbus Master/Slave COM .....               | 9-21        |
| 9.2.2.2    | Setting Up Modbus Serial Master .....                    | 9-24        |
| 9.2.2.3    | Setting Up Modbus Serial Slave .....                     | 9-27        |
| 9.2.3      | Modbus Serial Slave .....                                | 9-33        |
| 9.2.3.1    | Adding a Modbus Serial Device .....                      | 9-33        |
| 9.2.3.2    | Setting Up the Modbus Serial Device .....                | 9-35        |
| <b>9.3</b> | <b>Introduction to Ethernet Communication.....</b>       | <b>9-37</b> |
| 9.3.1      | Ethernet .....   | 9-37        |
| 9.3.1.1    | Adding an Ethernet Adapter Device .....                  | 9-37        |
| 9.3.1.2    | Setting Up the Ethernet .....                            | 9-38        |
| 9.3.2      | Modbus TCP Master .....                                  | 9-41        |
| 9.3.2.1    | Adding a Modbus TCP Master / Slave .....                 | 9-42        |
| 9.3.2.2    | Setting Up the Modbus TCP Master .....                   | 9-46        |
| 9.3.2.3    | Setting Up the Modbus TCP Slave .....                    | 9-47        |
| 9.3.3      | Modbus TCP Slave .....                                   | 9-52        |
| 9.3.3.1    | Adding a Modbus TCP Slave Device .....                   | 9-53        |
| 9.3.3.2    | Setting Up the Modbus TCP Slave Device .....             | 9-55        |
| <b>9.4</b> | <b>EtherNet/IP.....</b>                                  | <b>9-57</b> |


|            |   |             |
|------------|---|-------------|
| 9.4.1      | Introduction to EtherNet/IP .....                 | 9-57        |
| 9.4.1.1    | EtherNet/IP Overview .....                        | 9-57        |
| 9.4.1.2    | Definition.....                                   | 9-57        |
| 9.4.1.3    | Features of Ethernet .....                        | 9-58        |
| 9.4.1.3.1  | Delta EIP Structure .....                         | 9-58        |
| 9.4.1.3.2  | Features of EIP .....                             | 9-58        |
| 9.4.2      | EtherNet/IP Scanner Function .....                | 9-59        |
| 9.4.2.1    | Setting Up AX-8 Series PLC.....                   | 9-59        |
| 9.4.2.1.1  | Hardware Configuration .....                      | 9-59        |
| 9.4.2.1.2  | Read-Write Setting for Implicit Messages .....    | 9-60        |
| 9.4.2.1.3  | CIP Object Read-Write for Explicit Messages.....  | 9-62        |
| 9.4.3      | Adapter Function .....                            | 9-63        |
| 9.4.3.1    | Create an EDS File .....                          | 9-63        |
| 9.4.3.2    | Import an EDS File.....                           | 9-68        |
| 9.4.4      | CIP Object .....                                  | 9-71        |
| 9.4.4.1    | Object List .....                                 | 9-71        |
| 9.4.4.2    | Data Type .....                                   | 9-72        |
| 9.4.4.3    | Identity Object (Class ID: 01 Hex) .....          | 9-75        |
| 9.4.4.4    | Assembly Object (Class ID: 04 Hex).....           | 9-77        |
| 9.4.4.5    | TCP/IP Interface Object (Class ID: F5 Hex) .....  | 9-78        |
| 9.4.4.6    | Ethernet Link Object (Class ID : F6 Hex) .....    | 9-81        |
| 9.4.5      | Delta EIP Product List.....                       | 9-84        |
| 9.4.5.1    | Delta EIP Product List (Adapters Supported) ..... | 9-84        |
| 9.4.5.2    | Delta EIP Product List (Scanners Supported) ..... | 9-84        |
| <b>9.5</b> | <b>Network Security.....</b>                      | <b>9-85</b> |

## 9.1 Introduction to EtherCAT Communication

### 9.1.1 Features of EtherCAT Fieldbus

The EtherCAT bus is the Ethernet-based fieldbus. The communication rate of the EtherCAT network is 100Mbps and the distance between two adjacent nodes is within 50 meters. The EtherCAT network is noticeably very different from the general Ethernet network. One EtherCAT network has just one EtherCAT master and EtherCAT slaves contain ESC chips (EtherCAT Slave Controller) specially used for processing EtherCAT communication data and inserting the data which slaves need to transmit to the master into the EtherCAT frame. The last EtherCAT slave in the network will return the data which have been handled to the master in chronological order. See the illustration of data transmission shown below.


Thanks to the ESC chips in slaves, the master can make a communication with all slaves in an EtherCAT data frame and thus the communication efficiency is enhanced.



- **EtherCAT Communication between the Controller and Slaves**


Since the EtherCAT bus is the EtherNet-based fieldbus, the EtherCAT data frame still adopts the UDP/IP Ethernet data frame structure.

EtherCAT data field includes 2 bytes of EtherCAT data header and 44~1498 bytes of EtherCAT data. EtherCAT Data field consists of one or more EtherCAT datagrams. EtherCAT Data can be defined and analyzed in a protocol as long as the master and slaves comply with the protocol. Currently, the mostly used two protocols are COE (CANopen Over EtherCAT) and SOE (Sercos Over EtherCAT). EtherCAT data frame structure is as displayed below.



## 9.1.2 Setting Up EtherCAT Master

This section introduces functions in the tab of EtherCAT\_Master.



- **General**

① Autoconfig Master/Slaves: Enable this option to have basic configurations done. Suggested to use this option.

② EtherCAT NIC Setting:

- Destination address (MAC): MAC address of the device in the EtherCAT network that is to receive the telegrams.
- Source address (MAC): MAC address of the controller (Browse Scan Slave Station and choose ECAT)
- Network name: Name or MAC of the network, depending on which of the following options is activated.
- Select network by MAC<sup>\*1</sup>: The network is specified by the MAC ID (The default name is ECAT<sup>\*1</sup>).
- Select network by name: Network is identified by the network name and the project is device-independent.

\*1: The default name is ECAT.

③ Distributed Clock

- Cycle time: Master sends out corresponding data to the Slaves in a cycle time specified here.
- Sync offset: Parameter for setting the delay time between the Distributed Clock time base of the EtherCAT slave and the cycle start of the PLC. With the default value of 20%, the PLC cycle starts 20% of the bus cycle time after the sync interrupt of the slave. For the controller program, 80% of the cycle is always available. Here the Sync offset determines only when the EtherCAT data of the master is exchanged to and from the slaves relative to the time base of the EtherCAT slave.
- Sync window monitoring: Enabled to monitor the synchronization of the slaves.
- Sync window: Time for Sync window monitoring.

#### ④ Options

- Use LRW instead of LWR/LRD: Use combined read/write commands/PDO (LRW) instead of separating read (LRD) and write commands (LWR).
- Automatic restart slaves: In the case of a communication breakdown, the master immediately attempts to restart the slaves.

#### ● Log


Here you can view the PLC log. It lists the events that was recorded on the target system. Refer to **section 4.2.1.5 Log** for more information.

| Severity | Time Stamp          | Description   | Component     |
|----------|---------------------|---|---------------|
| Info     | 15.06.2023 11:13:44 | Preparation successfull   | IoDrvEtherCAT |
| Info     | 15.06.2023 11:13:44 | Networkadapter opened   | IoDrvEtherCAT |
| Info     | 15.06.2023 11:13:44 | No slaves added to the master   | IoDrvEtherCAT |
| Warning  | 15.06.2023 11:13:44 | Checking slaves: perhaps slave(s) missing, mismatch to configuration or no com... | IoDrvEtherCAT |
| Info     | 15.06.2023 11:13:40 | Preparation successfull   | IoDrvEtherCAT |
| Info     | 15.06.2023 11:13:40 | Networkadapter opened   | IoDrvEtherCAT |
| Info     | 15.06.2023 11:13:40 | No slaves added to the master   | IoDrvEtherCAT |
| Warning  | 15.06.2023 11:13:40 | Checking slaves: perhaps slave(s) missing, mismatch to configuration or no com... | IoDrvEtherCAT |
| Info     | 15.06.2023 11:13:36 | Preparation successfull   | IoDrvEtherCAT |
| Info     | 15.06.2023 11:13:36 | Networkadapter opened   | IoDrvEtherCAT |
| Info     | 15.06.2023 11:13:36 | No slaves added to the master   | IoDrvEtherCAT |
| Info     | 15.06.2023 11:11:01 | Preparation successfull   | IoDrvEtherCAT |
| Info     | 15.06.2023 11:11:01 | Networkadapter opened   | IoDrvEtherCAT |
| Info     | 15.06.2023 11:11:01 | No slaves added to the master   | IoDrvEtherCAT |
| Warning  | 15.06.2023 10:22:42 | Checking slaves: perhaps slave(s) missing, mismatch to configuration or no com... | IoDrvEtherCAT |
| Info     | 15.06.2023 10:22:38 | Preparation successfull   | IoDrvEtherCAT |
| Info     | 15.06.2023 10:22:38 | Networkadapter opened   | IoDrvEtherCAT |
| Info     | 15.06.2023 10:22:38 | No slaves added to the master   | IoDrvEtherCAT |

#### ● EtherCAT I/O Mapping


Here you can select the bus cycle task for EtherCAT communication. The bus cycle task selected will be synchronized with the specified EtherCAT\_Master cycle time.

- Bus cycle task: Select a bus cycle task to synchronize with the EtherCAT communication time. When the option “Use parent bus cycle setting is selected”, the system uses the shortest cycle time as the EtherCAT cycle time.



### 9.1.3 Setting Up EtherCAT Slave

This section introduces functions in the tab of Slave. You can either add slaves from the Product list or scan the network to add the slaves in.



- **General**

- **Address**

- ① EtherCAT address: Final address of the slaves, assigned by the master during bootup. The address is independent of the position of the slave in the network.

- **Distributed Clocks**

- ② Select DC: Cycle time for the data exchange.

- **③ Startup Checking**


| Function              | Description   |
|-----------------------|---|
| Check vendor ID       | Once the system starts, it checks if the vendor ID and product ID are the same as the configured. If not, the system stops without any further operation. |
| Check product ID      |   |
| Check revision number | Once the system starts, it checks if the revision number is the same as the drop-down list showed.  |

- ④ Timeouts

| Function      | Description  |
|---------------|--|
| SDO access    | Once the system starts, the SDO also starts transmitting. Unit: ms   |
| I → P         | Switching from Init mode to Pre-operational mode. Unit: ms   |
| P → S / S → O | Switching from Pre-operational mode to Safe Operational mode. Or switching from Safe-Op mode to Operational mode. Unit: ms |

- **Process Data**

The data mapping of the EtherCAT network is a cyclic data exchange between the master and slave through the CoE-based PDO mapping. The data that a slave sends to the master are packed in TxPDO and the data that the slave reads from the master are packed in RxPDO. The inputs and outputs on the pages of Select the Outputs and Select the Inputs contain the lists of PDOs which are available for data exchange and can be edited. For ESI file of a device, the PDOs and PDO contents for option have been defined and some PDO contents can be edited by users themselves as defined in ESI.




If outputs of the device are activated here (for writing), these outputs can be assigned to project variables in the EtherCAT I/O Mapping window. And if inputs of the device are activated here (for reading), these inputs can be assigned to project variables in the EtherCAT I/O Mapping window. It takes more PLC system resources, if you use more PDOs.


- **Startup Parameters**

The table shows the commands which have been defined by default in ESI file when the master will read and write values to the slave in the specific status of EtherCAT network operation. Users can add or reduce or modify commands in the table.

| Function Button | Description  |
|-----------------|--|
| Add             | By specifying new index/subindex entries, a new object can be added to the SDO that is not yet described in the EDS file. This is useful if only an incomplete object directory or none at all is present. |
| Edit            | In this window you can change the parameters of the SDO before the SDO is added to the configuration.  |
| Move Up         | Moves the selected line upwards by one line.   |
| Move Down       | Moves the selected line downwards by one line.   |



Click **Add** button to open the **Select Item from Object Directory** window. And select the parameter that you'd like to add and then click **OK** to add the item in.




## 9.1.4 Backup Parameters for EtherCAT Slaves


While using EtherCAT communication, we provide customized parameter storage feature for ASDA series servo drives with the backup feature to backup and restore parameters of all slave stations.

### 9.1.4.1 Data Backup Procedure

- Backup procedure



- Recover procedure



If there's any existing axis error while executing parameter backup or recovery, the corresponding slave station would be skipped in the backup/ recovery procedure. After the backup/ recovery of all the rest of slave stations are completed, all the related messages of axis errors would be displayed.

### 9.1.4.2 Introduction to Backup and Restore


- **Supported version for backup and recovery**

- AX-8 series firmware version: V1.0.x.x and above
- DIADesigner-AX version: V1.5 and above
- Only models ASDA-A3-E and ASDA-B3-E are supported for parameter backup and recovery.
  - ASDA-A3-E firmware version: V11165 sub 92 and above
  - ASDA-B3-E firmware version: V10665 sub 75 and above


- **Data that is backed up**

Servo parameters P0~P4 (Not including P0.001 and P4.000), P5.0003 + P5.0008~P5.0009 + P5.0020~P5.0030 + P6.0000~P6.0001.

- **Enter the parameter backup page**



- Enter the parameter restore page



| Name  | Function   |
|---|--|
| Online Device   | Select the target device to connect.   |
| Generate Target Device List from  | Select EtherCAT project tree <ul style="list-style-type: none"> <li>■ Archive File → EtherCAT topology file</li> <li>■ Online Topology → Online EtherCAT topology</li> </ul>   |
| Action  | Select the target action <ul style="list-style-type: none"> <li>■ Backup to File → Backup parameters to files.</li> <li>■ Backup to SD Card → Backup parameters to external SD cards.</li> <li>■ Restore from File → Restore parameters from files.</li> <li>■ Restore from SD Card → Restore parameters from SD cards.</li> </ul> |
|  | Save the current EtherCAT topology (Archive File)  |
|  | Execute the backup / restore feature   |


- External SD card backup path

External SD card path: /PLC CARD/AX\_/SysDup/ECAT/BackupRestore/ (The “\_” in the path represents model types. For example, model AX-8 would be defined as AX8 here.)


### 9.1.4.2.1 Operation for Backup Function

- **Parameter backup**


- ① Select Device
- ② Configure EtherCAT topology for the current project
- ③ Set Action to "Backup to File"
- ④ Execute backup




- **Change the PLC state to Stop.**



- Click Close after the parameter backup is completed.



- Backup directory




| Name                   | Function  |
|------------------------|---|
| File Name              | Set the name for parameter backup file.           |
| Directory              | Set the backup directory.                         |
| Clone to Other Devices | Change all the backup directory of other devices. |


### 9.1.4.2.2 Operation for Restore Function

- **Parameter restoration**


- ① Select Device
- ② Configure EtherCAT topology for the current project
- ③ Set Action to **Restore from File**




- **Click on the target device and set the path to the file to restore.**




- **Activate the restore function**



- **Change the PLC state to Stop.**



- **Click Yes after the restoration is completed, then reboot the device.**




## 9.2 Introduction to Modbus Serial Communication



### 9.2.1 Modbus Serial Port

Related parameters of serial communication can be modified by adding new Modbus Serial Port. AX-8 Series supports the following Modbus network types, including one RS-422 and one RS-485, and each Modbus Serial Port allows one master. Follow the below section to set up the basic settings for communication via the serial port for the Modbus serial port.


#### 9.2.1.1 Adding Delta Modbus COM




Find **Modbus COM** (Modbus > Modbus Serial Port > Modbus COM) and then double-click it or click **Add Device** to add this port in.



● **Modbus Serial COM Port Number**



For AX-8 with the Windows operating system, the setting value for **COM port** must be the same as the port number in Device Manager of the Windows system.




For AX-8 with the Linux operating system, the setting for **COM port** is fixed to 3 when the RS-485 or RS-422 port is used. If a USB-to-COM port device is used, the setting for **COM port** varies with different extension devices. If it is identified as a ttyACM device, the port number is in the range 8 to 11, in the order of device inserting. If it is identified as a ttyUSB device, the port number is in the range 4 to 7, in the order of device inserting.

### 9.2.1.2 Setting Up Delta Modbus COM


- **System Parameters**

Here you can configure Serial Port Parameters. Settings include Serial Communication Mode (RS-422/RS-485).



- **Status**


Here you can find the device status information, for example **Running** or **Stopped**, and specific diagnostic messages from the respective device, also information about the card used and the internal bus system.



| Item       | Description                               |
|------------|---|
| SerialPort | The status of Modbus Serial Communication |

- **Information**

Here you can find general information that originates from the device description file: name, vendor, categories, version, order number, description, and other relevant information.




## 9.2.2 Modbus Serial Master


In addition to providing the standard Modbus communication protocol, the AX-8 Series PLC further executes the Delta controller internal device conversion (X, M, D devices, etc.), eliminating the need for you to check the conversion table. When AX-8 is set to act as a Modbus Serial Master, you need to first create Modbus Master COM port and then add Modbus Slave COM port to continue further settings. Follow the below section to set up the Modbus Serial Master.

### 9.2.2.1 Adding Delta Modbus Master/Slave COM


1. Right-click the created **Modbus\_COM (Modbus COM)** in the tree view to open a context menu. And click **Add Device...** to open the Add Device setting window.




- Find and double-click **Modbus Master COM Port** (Fieldbuses > Modbus > Modbus Serial Master > Modbus Master COM Port) or click **Add Device** to add this port in.



- Find the added port **Modbus\_Master\_COM\_Port (Modbus Master COM Port)** in the tree view and double-click it to open the setting window to set up.




4. Find and double-click **Modbus Slave COM port** (Fieldbuses > Modbus > Modbus Serial Slave > Modbus Slave COM Port) or click **Add Device** to add this port in.




### 9.2.2.2 Setting Up Modbus Serial Master

Double-click the created **Modbus Master COM Port** to open the setting menu.



- **General**

Here you can configure the basic settings for Modbus Master COM Port.




| Item                              | Description  |
|-----------------------------------|--|
| <b>Auto-restart communication</b> | Enable this option to have this port to reconnect automatically if an error occurs or connection timeout occurs. |

- **Modbus GenericSerial Master I/O Mapping**


Here you can select the bus cycle task of Modbus Serial Master to synchronize with the Modbus communication time.

Refer to **section 4.2.1.6 PLC Settings** for more information.



- **Modbus Serial Master IEC Objects**


Here you can check the status of Modbus Serial Master under this tab.



| Expression                    | Description  |
|-------------------------------|--|
| bStop                         | Stop sending the Slave any new request             |
| bResetComPort                 | Reset the COM port                                 |
| uiNumberOfCommunicatingSlaves | The number of the Slaves that are in communication |
| bAllSlavesOk                  | The communication status of the Slave              |


● **Status**

Here you can find the device status information, for example **Running** or **Stopped**, and specific diagnostic messages from the respective device, also information about the card used and the internal bus system.



● **Information**

Here you can find general information that originates from the device description file: name, vendor, categories, version, order number, description, and other relevant information.




Note:

1. Each Modbus Serial Port allows one master. A maximum of 32 slaves can be attached to a master.
2. Since RS-422 has no multipoint capability, only point-to-point connection is possible. And only the FIRST slave can communicate with the master. Since RS-485 has multipoint capability, RS-485 does NOT have such limitations.


### 9.2.2.3 Setting Up Modbus Serial Slave

In the tree view, find the added port **Modbus\_Slave\_COM\_Port (Modbus Slave COM Port)**. Double-click it to open the setting window to set up.



- **General**

Here you can configure the basic settings for Modbus Slave COM Port, such as Slave Address, Response Timeout and Device Type.



| Item                    | Description   |
|-------------------------|---|
| <b>Slave Address</b>    | Address of a serial Modbus device   |
| <b>Response Timeout</b> | Time interval for the master to wait for the response from the slave. This is especially configured for this slave node and overwrites the general response timeout setting of the respective master. |

● **Modbus Slave Channel**

Here you can define slave channels. Each channel represents a single Modbus request. You can create up to 10 channels for each slave. AX-8 Series PLC will send out Modbus request packets in chronological order. All channels share the same Modbus connection.

| Name        | Access Type                                      | Trigger         | READ Offset | Length | Error Handling  | WRITE Offset |
|-------------|--|-----------------|-------------|--------|-----------------|--------------|
| 0 Channel 0 | Write Multiple Registers (Function Code 16)      | Cyclic, t#100ms |             |        |                 | 16#0000      |
| 1 Channel 1 | Read Coils (Function Code 01)                    | Cyclic, t#100ms | 16#0000     | 1      | Keep last value |              |
| 2 Channel 2 | Read Discrete Inputs (Function Code 02)          | Cyclic, t#100ms | 16#0000     | 1      | Keep last value |              |
| 3 Channel 3 | Read Holding Registers (Function Code 03)        | Cyclic, t#100ms | 16#0000     | 1      | Keep last value |              |
| 4 Channel 4 | Read Input Registers (Function Code 04)          | Cyclic, t#100ms | 16#0000     | 1      | Keep last value |              |
| 5 Channel 5 | Write Single Coil (Function Code 05)             | Cyclic, t#100ms |             |        |                 | 16#0000      |
| 6 Channel 6 | Write Single Register (Function Code 06)         | Cyclic, t#100ms |             |        |                 | 16#0000      |
| 7 Channel 7 | Write Multiple Coils (Function Code 15)          | Cyclic, t#100ms |             |        |                 | 16#0000      |
| 8 Channel 8 | Write Multiple Registers (Function Code 16)      | Cyclic, t#100ms |             |        |                 | 16#0000      |
| 9 Channel 9 | Read/Write Multiple Registers (Function Code 23) | Cyclic, t#100ms | 16#0000     | 1      | Keep last value | 16#0000      |

Device Type : Standard Modbus Device

Device Type : AH Series

Modbus Channel

Enable

Channel

Name: Channel 0

Access Type: Read Coils

Trigger: Cyclic, 100 ms

Comment:

Read Register

Device Address: 0x0

Length: 1

Error Handling: Keep last Value

OK Cancel

Modbus Channel

Enable

Channel

Name: Channel 0

Access Type: Read Coils

Trigger: Cyclic, 100 ms

Comment:

Read Register

Device Address: X Coil

Length: 1


Error Handling: Keep last Value

OK Cancel

| Item           | Description  |  |
|----------------|--|--|
| Device Type    | Standard Modbus Device   | Delta Series Device  |
| Enable         | Activates this channel   |  |
| Name           | Defines this channel name  |  |
| Access Type    | Modbus function code <ul style="list-style-type: none"> <li>● Read Coils (0x01)</li> <li>● Read discrete inputs (0x02)</li> <li>● Read holding Registers (0x03)</li> <li>● Read input Registers (0x04)</li> <li>● Read single Coil (0x05)</li> <li>● Write single Register (0x06)</li> <li>● Write multiple Coils (0x0F)</li> <li>● Write multiple Registers (0x10)</li> <li>● Read/Write multiple Registers (0x17)</li> </ul> | Read/Write Registers <ul style="list-style-type: none"> <li>● Read Coils</li> <li>● Read Registers</li> <li>● Write Coils</li> <li>● Write Registers</li> </ul> <p>Note: PLC uses the corresponding Modbus function code according to the read/write register of the device type.</p>  |
| Trigger        | <ul style="list-style-type: none"> <li>● <b>Cyclic:</b> The request occurs periodically.</li> <li>● <b>Rising edge:</b> The request occurs as a reaction to a rising edge of the Boolean trigger variables. The trigger variable is defined in the tab I/O Mapping.</li> <li>● <b>Application:</b> The Modbus request is triggered by <b>DFB_ModbusComChannel</b></li> </ul>   | <ul style="list-style-type: none"> <li>● <b>Cyclic:</b> The request occurs periodically.</li> <li>● <b>Rising edge:</b> The request occurs as a reaction to a rising edge of the Boolean trigger variables. The trigger variable is defined in the tab I/O Mapping.</li> <li>● <b>Application:</b> The Modbus request is triggered by <b>DFB_ModbusComChannel</b></li> </ul> |
| Comment        | Description of the channel   |  |
| Device Address | Modbus protocol address  | Delta register address (will be converted into Modbus protocol in the background)  |
| Length         | Number of the register to be read/written to. (up to 100 coils and 100 registers)  | Number of the register to be read/written to. (up to 256 coils and 100 registers)  |
| Error Handling | What to do with the data in case of a communication error: <ul style="list-style-type: none"> <li>● Set To ZERO</li> <li>● Keep last value</li> </ul>  |  |


● **Modbus Slave Init**

After the Modbus connection between AX-8 Series PLC and the slaves is established, you can use **Add Channel** button to edit the Initialization Value of the Coil/Registers.




Click **New**, you can edit the Access Type, Device Address, Length, Initialization Value and Comment.

Click **OK** to confirm the settings.



● **Modbus Generic Serial Slave I/O Mapping**


After you have added channels under the tab of **Modbus Slave COM Port**, you can find the variables and the set access types under this tab.



- ① The descriptions here reflect what you have set for the Access Type in Modbus Slave Channel tab.
- ② The triggered Boolean variable for this channel. When the Trigger type is set to Rising edge in Modbus Slave Channel
- ③ The controller Coils/Registers that are read/written by this channel.

● **Modbus Generic Serial Slave IEC Objects**

Here you can check the status of Modbus Serial Slave under this tab.




| Expression | Description   |
|------------|---|
| bTrigger   | Trigger all Modbus channels at one time.  |
| bReset     | Re-establish the connection and reset bError and ModbusRrror when the connection status shows error. And this function is only available when the option "Auto-Reconnect" is NOT enabled. |

| Expression    | Description   |
|---------------|---|
| bAcknowledge  | Re-establish the connection and continue to execute the data transmission from the Modbus channels that showed error previously. And this function is only available when the option "Auto-Reconnect" is NOT enabled. |
| bDolnit       | Initialized the Slave.  |
| bInnitDone    | The initialization of the Slave is completed.   |
| bBusy         | This channel is in data transmission.   |
| bDone         | The data transmission via this channel is completed.  |
| bError        | Error occurs when this channel is in data transmission.   |
| ModbusError   | Records of the Modbus error.  |
| iChannelIndex | The number of the channel that is in execution.   |


● **Status**

Here you can find the Modbus Slave COM Port status information, for example **Running** or **Stopped**, and specific diagnostic messages from the respective device, also information about the card used and the internal bus system.



● **Information**

Here you can find general information that originates from the device description file: name, vendor, categories, version, order number, description, and other relevant information.




## 9.2.3 Modbus Serial Slave


When AX-8 Series PLC is set to act as a Modbus Serial Slave, you need to add Modbus Serial Device in and set up the allowable areas for Coils/Register. If Modbus Serial Master uses Delta device communication protocol, there is no access restrictions. Follow the below section to set up the Modbus Serial Slave.

### 9.2.3.1 Adding a Modbus Serial Device


1. Right-click the created **Modbus\_COM (Modbus COM)** in the tree view to open a context menu. And click **Add Device...** to open the Add Device setting window.



- Find and double-click **Modbus Serial Device** (Fieldbuses > Modbus > Modbus Serial Device > Modbus Serial Device) or click **Add Device** to add this port in.




- Find the added port **Modbus\_Serial\_Device (Modbus Serial Device)** in the tree view and double-click it to open the setting window to set up.



### 9.2.3.2 Setting Up the Modbus Serial Device


- **General**

Here you can configure the basic settings for Modbus Serial Device. Set up the allowable areas for Coils/Registers. If Modbus Serial Master uses Delta device communication protocol, there is no access restrictions.




- **Modbus Serial Device I/O Mapping**

Here you can select the bus cycle task of Modbus TCP Slave Device to synchronize with the Modbus communication time. Refer to **section 4.2.1.6 PLC Settings** for more information.




- **Modbus Serial Device IEC Objects**

Here you can check the status of Modbus Serial Device under this tab.




- **Status**

Here you can find the Modbus Serial Slave Device status information, for example **Running** or **Stopped**, and specific diagnostic messages from the respective device, also information about the card used and the internal bus system.



- **Information**

Here you can find general information that originates from the device description file: name, vendor, categories, version, order number, description, and other relevant information.




## 9.3 Introduction to Ethernet Communication

Network-related parameters can be modified by adding new Ethernet device. All functions related to network must be adjusted under this tab (e.g. Modbus TCP and EtherNet/IP). Follow the below section to set up the basic settings for communication via the Ethernet Adapter.


### 9.3.1 Ethernet

- Ethernet tree diagram




#### 9.3.1.1 Adding an Ethernet Adapter Device

1. Right-click the PLC in the tree view to see a context menu. Click **Add Device...** to open the setting window.




- Find and double-click **Ethernet** (Fieldbuses > Ethernet Adapter > Ethernet) or click **Add Device** to add it in.




### 9.3.1.2 Setting Up the Ethernet

Find the added **Ethernet (Ethernet)** in the tree view and double-click it to open the setting window for setup.




- **General**



| Item              | Description                     |
|-------------------|---------------------------------|
| Network Interface | Current communication interface |

- **Status**


Here you can find the device status information, for example **Running** or **Stopped**, and specific diagnostic messages from the respective device.



| Item                    | Description                          |
|-------------------------|--------------------------------------|
| Ethernet Device         | The status of Ethernet Communication |
| Last Diagnostic Message | Network diagnosis                    |


- **Ethernet Device I/O Mapping**

Here you can select the bus cycle task of Ethernet Device to synchronize with the communication time. Refer to **section 4.2.1.6 PLC Settings** for more information.




- **Ethernet Device IEC Objects**

Here you can find the objects defined by Ethernet Device. “Objects” are listed that allow for access to the device from the IEC application. In online mode, you can use the table of IEC objects as a monitoring view.



- **Information**


Here you can find general information that originates from the device description file: name, vendor, categories, version, order number, description, and other relevant information.



### 9.3.2 Modbus TCP Master


In addition to providing the standard Modbus communication protocol, the AX-8 Series PLC further executes the Delta controller internal device conversion (X, M, D devices, etc.), eliminating the need for you to check the conversion table. When AX-8 Series PLC is set to act as a Modbus TCP Master, you need to first create Modbus TCP Master and then add Modbus TCP Slave to continue further settings. Follow the below section to set up the Modbus TCP Master.

- **Modbus TCP Master tree diagram**




### 9.3.2.1 Adding a Modbus TCP Master / Slave


1. Right-click the **Ethernet (Ethernet)** node in the tree view to open a context menu. And click **Add Device...** to open the Add Device setting window.




2. Find and double-click **Modbus TCP Master** or click **Add Device** to add this port in. After that you can find **Modbus\_TCP\_Master** under the Ethernet node in the tree view.




3. Right-click **Modbus\_TCP\_Master** under the **Ethernet** node in the tree view to open a context menu. And click **Add Device...** to open the Add Device setting window.



4. Find and double-click **Modbus TCP Slave** (Fieldbuses > Modbus > Modbus TCP Slave > Modbus TCP Slave) or click **Add Device** to add it in.




### 9.3.2.2 Setting Up the Modbus TCP Master



| Expression                    | Description   |
|-------------------------------|---|
| Modbus TCP Master I/O Mapping | Users can select the bus cycle task of Modbus TCP Master to synchronize with the Modbus communication time. Refer to <b>4.2.1.6 section PLC Settings</b> for more information.  |
| Modbus TCP Master IEC Objects | <p>You can check the status of Modbus TCP Master under this tab.</p> <ul style="list-style-type: none"> <li>● bStop: TRUE &gt; Stop sending Modbus TCP packets.</li> <li>● bSlaveError: TRUE &gt; connection/communication with the Slave is abnormal</li> <li>● uiConnectedSlaves: the number of the connected Slaves</li> </ul> <p>e.g.(ST programming language): Modbus TCP Master.bStop:= TRUE;</p> |
| Status                        | Here you can find the device status information as well as information about the card used and the internal bus system.   |
| Information                   | Here you can find general information that originates from the device description file: name, vendor, categories, version, order number, description, and other relevant information.   |


### 9.3.2.3 Setting Up the Modbus TCP Slave

In the tree view, find the **Modbus\_TCP\_Slave (Modbus TCP Slave)** and double-click it to open the setting window to set up.



- **General**


Here you can configure the basic settings for Modbus TCP Slave, such as Slave Address, Response Timeout and Device Type.



| Item             | Description   |
|------------------|---|
| Slave IP Address | Address of the slave IP   |
| Response Timeout | Time interval for the master to wait for the response from the slave. This is especially configured for this slave node and overwrites the general response timeout setting of the respective master. |
| Port             | Slave communication port  |

● **Modbus Slave Channel**

Here you can define slave channels. Each channel represents a single Modbus request. You can create up to 100 channels for each slave. AX-8 Series PLC will send out Modbus request packets in chronological order. All channels share the same Modbus TCP connection.




| Device Type        | Standard Modbus Device   | Series Device   |
|--------------------|--|---|
| <b>Enable</b>      | Activates this channel   |   |
| <b>Name</b>        | Defines this channel name  |   |
| <b>Access Type</b> | Modbus function code <ul style="list-style-type: none"> <li>● Read Coils (0x01)</li> <li>● Read discrete inputs (0x02)</li> <li>● Read holding Registers (0x03)</li> <li>● Read input Registers (0x04)</li> <li>● Read single Coil (0x05)</li> <li>● Write single Register (0x06)</li> <li>● Write multiple Coils (0x0F)</li> <li>● Write multiple Registers (0x10)</li> <li>● Read/Write multiple Registers (0x17)</li> </ul> | Read/Write Registers <ul style="list-style-type: none"> <li>● Read Coils</li> <li>● Read Registers</li> <li>● Write Coils</li> <li>● Write Registers</li> </ul> Note: PLC uses the corresponding Modbus function code according to the read/write register of the device type.  |
| <b>Trigger</b>     | <ul style="list-style-type: none"> <li>● <b>Cyclic:</b> The request occurs periodically.</li> <li>● <b>Rising edge:</b> The request occurs as a reaction to a rising edge of the Boolean trigger variables. The trigger variable is defined in the tab I/O Mapping.</li> <li>● <b>Application:</b> The Modbus request is</li> </ul>  | <ul style="list-style-type: none"> <li>● <b>Cyclic:</b> The request occurs periodically.</li> <li>● <b>Rising edge:</b> The request occurs as a reaction to a rising edge of the Boolean trigger variables. The trigger variable is defined in the tab I/O Mapping.</li> <li>● <b>Application:</b> The Modbus request is triggered</li> </ul> |

|                       |   |   |
|-----------------------|---|---|
|                       | triggered by <b>DFB_ModbusTCPChannel</b>  | by <b>DFB_ModbusTCPChannel</b>  |
| <b>Comment</b>        | Description of the channel  |   |
| <b>Device Address</b> | Modbus protocol address   | Delta register address (will be converted into Modbus protocol in the background) |
| <b>Length</b>         | Number of the register to be read/written to.   | Number of the register to be read/written to. (up to 256 coils and 100 registers) |
| <b>Error Handling</b> | What to do with the data in case of a communication error: <ul style="list-style-type: none"> <li>● Set To ZERO</li> <li>● Keep last value</li> </ul> |   |


- **Modbus Slave Init**

After the Modbus connection between AX-8 Series PLC and the slaves is established, you can use **Add Channel** button to edit the Initialization Value of the Coil/Registers.



● **Modbus TCP Slave I/O Mapping**


After you have added channels under the tab of Modbus Slave Channel, you can find the variables and the set access types under this tab.



- ① The descriptions here reflect what you have set for the **Access Type** in Modbus Slave Channel tab.
- ② The controller registers that are read/written by this channel.
- ③ Timing for the data refreshing; refer to **section 4.2.1.6 PLC Settings** for more information.

● **Modbus TCP Slave IEC Object**

You can check the status of Modbus TCP Slave under this tab.




9

| Expression    | Description  |
|---------------|--|
| bConfirmError | If the option "Auto-Reconnect" is NOT enabled, during the data transmission, any channel that showed error stops. After the bConfirmError shows "TRUE", the channel that showed error previously continues to execute. |
| bDoInit       | Initialized the Slave.   |

| Expression    | Description   |
|---------------|---|
| bInitDone     | The initialization of the Slave is completed.           |
| bBusy         | This channel is in data transmission.                   |
| bDone         | The data transmission via this channel is completed.    |
| bError        | Error occurs when this channel is in data transmission. |
| ModbusError   | Records of the Modbus error.                            |
| iChannelIndex | The number of the channel that is in execution.         |


- **Status**

Here you can find the Modbus TCP Slave status information, for example **Running** or **Stopped**, and specific diagnostic messages from the respective device, also information about the card used and the internal bus system.



- **Information**


Here you can find general information that originates from the device description file: name, vendor, categories, version, order number, description, and other relevant information.



### 9.3.3 Modbus TCP Slave


If AX-8 Series PLC is set to act as a Modbus TCP Slave, you need to add Modbus TCP Slave Device in and set up the allowable areas for Coils/Registers. If Modbus TCP Master uses Delta device communication protocol, there is no access restrictions. Follow the below section to set up the Modbus TCP Slave.

- **Modbus TCP Slave tree diagram**




### 9.3.3.1 Adding a Modbus TCP Slave Device

1. Right-click the **Ethernet (Ethernet)** node in the tree view to open a context menu. And click **Add Device...** to open the Add Device setting window.




2. Find and double-click **Modbus TCP Slave Device** or click **Add Device** to add this port in.



### 9.3.3.2 Setting Up the Modbus TCP Slave Device


- **General**

Here you can configure the basic settings for Modbus TCP Slave Device. Set up the allowable areas for Coils/Registers. If Modbus TCP Slave uses Delta device communication protocol, there is no access restrictions.




- **Modbus TCP Slave Device I/O Mapping**

Here you can select the bus cycle task of Modbus TCP Slave Device to synchronize with the Modbus communication time. Refer to **section 4.2.1.6 PLC Settings** for more information.




● **Status**

Here you can find the Modbus TCP Slave Device status information, for example **Running** or **Stopped**, and specific diagnostic messages from the respective device, also information about the card used and the internal bus system.



● **Information**

Here you can find general information that originates from the device description file: name, vendor, categories, version, order number, description, and other relevant information.



## 9.4 EtherNet/IP

Network-related parameters can be modified by adding new Ethernet device. All functions related to network must be adjusted under this tab (e.g. Modbus TCP and EtherNet/IP). Follow the below section to set up the basic settings for communication via the Ethernet Adapter.

### 9.4.1 Introduction to EtherNet/IP

#### 9.4.1.1 EtherNet/IP Overview

Ethernet Industrial Protocol (EtherNet/IP) is an open industrial networking standard, managed by ODVA (Open DeviceNet Vendors Association).

EtherNet/IP works on a TCP/UDP/IP based Ethernet network and uses most widely deployed collections of Ethernet standards to provide a broad range of applications in different industries that require high-speed and stability including Factory Automation (FA), Building Automation (BA), Process Automation (PA) and many more.

Delta covers a full range of controller and drive products supported by EtherNet/IP, including Programmable Logic Controllers (PLC), inverters, Human Machine Interfaces (HMI) and so on. Refer to **section 9.4.5** for a full product list supported by EtherNet/IP. In addition, users can also use the EDS file to connect to the EtherNet/IP devices of other brands.

#### 9.4.1.2 Definition


| Term             | Definition   |
|------------------|--|
| ODVA             | Open DeviceNet Vendor Association for EtherNet/IP  |
| EIP              | EtherNet/IP, an industrial Ethernet network, provides interoperability for system providers. IP stands for Industrial Protocol. The term "EIP" (EtherNet/IP) will be used throughout this manual.  |
| I/O Connection   | Via the I/O connection to connect to EtherNet/IP and to exchange data cyclically   |
| Explicit Message | Connect to EtherNet/IP and to exchange data non-cyclically. Data will be exchanged piece by piece via instructions.  |
| RPI              | Requested Packet Interval, via the I/O connection to connect to EtherNet/IP to exchange data at regular time intervals   |
| ACD              | Address Conflict Detection to detect IP address duplications.  |
| P/C TAG          | Produced / Consumed TAG. A produced TAG sends its data to consumed TAGs (consumers) without using logic. TAGs are the methods used for assigning and referencing memory locations for Rockwell PLCs, the same as the registers for Delta PLCs. |
| EDS              | Electronic Data Sheets; EDS files are simple text files used by EtherNet/IP network configuration tools to help you identify EtherNet/IP products and easily commission them on a network.   |
| Data Mapping     | Exchange data between devices.   |

|             |   |
|-------------|---|
| EIP Scanner | The master station is called Scanner in EtherNet/IP.                    |
| EIP Adapter | The slave station is called Adapter in EtherNet/IP.                     |
| MODBUS TCP  | MODBUS TCP is a MODBUS communication protocol, widely used on Ethernet. |

### 9.4.1.3 Features of Ethernet

#### 9.4.1.3.1 Delta EIP Structure

This typical Delta EIP architecture includes EIP Scanner and Adapter; data mapping can be achieved between devices via an I/O connection and explicit message.



#### 9.4.1.3.2 Features of EIP


- **Flexibility**
  - Flexible topology: EIP devices may include an Ethernet single port as well as Ethernet dual port, and provide applicable networks such as linear topology, ring topology and ring topology for faster expansion and easier management.
  - Network compatible: IT specialists are not required for Internet connection setup, while the Wi-Fi connection is provided.
- **Simplicity**
  - Via a connector: Delta provides a full range of product line, including human machine interfaces (HMI), programmable logic controllers (PLC) and inverter drives, for application in an industrial operation. Simply via a RJ-45 connector, a network can be built up, saving costs on cables and other connecting tools.
  - Single network: In replace with the 3-tier industrial architecture, single network architecture provides 100Mbps high-speed cyclical and non-cyclical data mapping function, ensuring a complete network diagnosis and effectively shortening debugging time.

## 9.4.2 EtherNet/IP Scanner Function

### 9.4.2.1 Setting Up AX-8 Series PLC

#### 9.4.2.1.1 Hardware Configuration

This application example is to connect AX-8 Series PLC to AX-332 via Ethernet.



### 9.4.2.1.2 Read-Write Setting for Implicit Messages


Map the read/write address to the register in option card via the master station (Scanner) to exchange data cyclically and one-time read/write data via the register for implicit messages in EtherNet/IP.

- **Example for creating EIP**


The IP address of the devices applied in this example are shown as follows:

|                |               |                        |
|----------------|---------------|------------------------|
| <b>Devices</b> | <b>AX-8</b>   | 192.168.1.10 (default) |
|                | <b>AX-332</b> | 192.168.1.11           |


1. Right-click the PLC in the tree view to see a context menu. Click **Add Device...** to open the setting window and create Ethernet Device.




2. Create Interface. Go to **Ethernet (Ethernet) > General**.



- Right-click the **Ethernet (Ethernet)** node in the tree view to see a context menu. Click **Add Device...** to open the setting window and create **EtherNet/IP Scanner**.



- Adapters can be created via **Scan for Devices**.



### 9.4.2.1.3 CIP Object Read-Write for Explicit Messages

Please refer to **Appendix A <EtherNet/IP Service and Object>** in VFD EtherNet/IP Application Manual to check the objects supported by the option card and make sure to understand read-write methods for explicit messages before using this function. The master is allowed to configure the setting values of drives directly with the relevant Object Class address. The object class code is 0x300 for drives and the address is formatted as the following shown.

EIP communication data format

|              |   |           |   |            |
|--------------|---|-----------|---|------------|
| Object class |   | Instance  |   | Attribute  |
| 0x300        | + | Pr. Group | + | Pr. Number |

- **Read-write Example**

To read and write parameter 09-30 (decoding with Ethernet/IP):


- Declare function blocks and variables.

```


PROGRAM PLC_PRG
VAR

    Get_Attribute_Single_0: ENIP.Get_Attribute_Single;
    Set_Attribute_Single_0: ENIP.Set_Attribute_Single;
    getsingledata: ARRAY[0..999] OF BYTE;
    setsingledata: ARRAY[0..999] OF BYTE;
END_VAR
    
```

- Read parameter 9-30 via the function block as shown below.



- Write 1 to parameter 9-30 via the function block as shown below.





## 9.4.3 Adapter Function

This section will explain how to add an adapter and set up its data structure. Refer to the following steps for configuration.



### 9.4.3.1 Create an EDS File


This section will introduce how AX-8 Series PLC creates an EDS File.

- Add an Ethernet Device



● Add EtherNet\_IP\_Adapter Device







#### ■ General- EDS File Settings

| General                         | EDS File   |
|---------------------------------|--|
| Tags                            | Vendor name: 3S - Smart Software Solutions GmbH  |
| Log                             | Vendor ID: 1285  |
| EtherNet/IP Adapter I/O Mapping | Product name: EtherNet/IP Adapter  |
| EtherNet/IP Adapter IEC Objects | Product code: 120  |
| Status                          | Major revision: 1  |
| Information                     | Minor revision: 1  |
|                                 | Support ACD: <input checked="" type="checkbox"/>   |
|                                 | Enable ACD: <input type="checkbox"/>   |
|                                 | Enable LLDP: <input checked="" type="checkbox"/>   |
|                                 | <input type="button" value="Install to Device Repository..."/> <input type="button" value="Export EDS File..."/> |

| Item                         | Description   | Default                            |
|------------------------------|---|------------------------------------|
| Vender name                  | The name of the supplier  | 3S - Smart Software Solutions GmbH |
| Vendor ID                    | Supplier ID   | 1285                               |
| Product name                 | The name of the product   | EtherNet/IP Adapter                |
| Product code                 | Product code  | 120                                |
| Major revision               | Major revision  | 1                                  |
| Minor revision               | Minor revision  | 1                                  |
| Install to Device Repository | In case that a device with the same device identification has already been installed, you would be asked whether the device should be overwritten. If the device is taken as the remote adapter inserted directly below the EtherNet/IP scanner, you would be asked to update the device automatically. |                                    |
| Export EDS File              | The EDS file is created and stored on the local computer. In this way, the EDS file can be used in an external configuration file.  |                                    |


● Add EtherNet/IP Module to create data file






- **Export EDS File**

After the configuration is completed, export the EDS file and store the EDS file – EtherNet\_IP Adapter.eds in the PC.




### 9.4.3.2 Import an EDS File


1. Choose **Tools > Device Repository**.



2. Choose **Install** and select the target EDS file to download: EtherNet\_IP Adapter.ed5.




3. Import successfully when you see **Device "EtherNet/IP Adapter" installed to device repository.**



## 9.4.4 CIP Object

### 9.4.4.1 Object List

In EtherNet/IP, object is referred to as a set of parameters that is structured accordingly by Class, Instance and Attribute. For example, Instance 0 contains basic information of every object, e.g. version and length. While Instance 1~N creates connection or status of required parameters for each product. Users can obtain product parameters from the supported service code via objects (see diagram below).



Read or write objects by using EtherNet/IP Services.library or explicit message tool. The supported EtherNet/IP objects are listed below. Refer to the **section 9.4.4.2** for the data type definition. Refer to the **section 9.4.4.3 ~ 9.4.4.6** for object contents.

| Object Name             | Function  | Class ID   |
|-------------------------|---|------------|
| Identity Object         | Provides information including manufacturer, device types and versions. | 1 (H'01)   |
| Assembly Object         | Defines parameter of I/O connection data exchange                       | 4 (H'04)   |
| TCP/IP Interface Object | Displays methods of IP configuration and interface                      | 245 (H'F5) |
| Ethernet Link Object    | Shows the connection status of each Ethernet port on the device.        | 246 (H'F6) |

### 9.4.4.2 Data Type

This section will provide an overview of the supported data types by objects.

| Data Type   | Description   |                        |                              |                              |                              |      |       |        |        |     |      |      |         |    |    |    |    |    |    |     |      |      |    |    |    |    |    |    |      |      |      |      |      |    |    |    |    |      |      |      |      |      |      |      |      |      |
|---|---|------------------------|------------------------------|------------------------------|------------------------------|------|-------|--------|--------|-----|------|------|---------|----|----|----|----|----|----|-----|------|------|----|----|----|----|----|----|------|------|------|------|------|----|----|----|----|------|------|------|------|------|------|------|------|------|
| BOOL  | False ( H'00 ) or True ( H'01 )   |                        |                              |                              |                              |      |       |        |        |     |      |      |         |    |    |    |    |    |    |     |      |      |    |    |    |    |    |    |      |      |      |      |      |    |    |    |    |      |      |      |      |      |      |      |      |      |
| SIGNED<br>INTEGER   | SINT ( 1 byte ) · INT ( 2 bytes ) · DINT ( 4 bytes ) · LINT ( 8 bytes )   |                        |                              |                              |                              |      |       |        |        |     |      |      |         |    |    |    |    |    |    |     |      |      |    |    |    |    |    |    |      |      |      |      |      |    |    |    |    |      |      |      |      |      |      |      |      |      |
|   | <table border="1"> <thead> <tr> <th>Number</th> <th>1st</th> <th>2nd</th> <th>3rd</th> <th>4th</th> <th>5th</th> <th>6th</th> <th>7th</th> <th>8th</th> </tr> </thead> <tbody> <tr> <td>SINT</td> <td>0LSB</td> <td>--</td> <td>--</td> <td>--</td> <td>--</td> <td>--</td> <td>--</td> <td>--</td> </tr> <tr> <td>INT</td> <td>0LSB</td> <td>1LSB</td> <td>--</td> <td>--</td> <td>--</td> <td>--</td> <td>--</td> <td>--</td> </tr> <tr> <td>DINT</td> <td>0LSB</td> <td>1LSB</td> <td>2LSB</td> <td>3LSB</td> <td>--</td> <td>--</td> <td>--</td> <td>--</td> </tr> <tr> <td>LINT</td> <td>0LSB</td> <td>1LSB</td> <td>2LSB</td> <td>3LSB</td> <td>4LSB</td> <td>5LSB</td> <td>6LSB</td> <td>7LSB</td> </tr> </tbody> </table> | Number                 | 1st                          | 2nd                          | 3rd                          | 4th  | 5th   | 6th    | 7th    | 8th | SINT | 0LSB | --      | -- | -- | -- | -- | -- | -- | INT | 0LSB | 1LSB | -- | -- | -- | -- | -- | -- | DINT | 0LSB | 1LSB | 2LSB | 3LSB | -- | -- | -- | -- | LINT | 0LSB | 1LSB | 2LSB | 3LSB | 4LSB | 5LSB | 6LSB | 7LSB |
|   | Number  | 1st                    | 2nd                          | 3rd                          | 4th                          | 5th  | 6th   | 7th    | 8th    |     |      |      |         |    |    |    |    |    |    |     |      |      |    |    |    |    |    |    |      |      |      |      |      |    |    |    |    |      |      |      |      |      |      |      |      |      |
|   | SINT  | 0LSB                   | --                           | --                           | --                           | --   | --    | --     | --     |     |      |      |         |    |    |    |    |    |    |     |      |      |    |    |    |    |    |    |      |      |      |      |      |    |    |    |    |      |      |      |      |      |      |      |      |      |
|   | INT   | 0LSB                   | 1LSB                         | --                           | --                           | --   | --    | --     | --     |     |      |      |         |    |    |    |    |    |    |     |      |      |    |    |    |    |    |    |      |      |      |      |      |    |    |    |    |      |      |      |      |      |      |      |      |      |
| DINT  | 0LSB  | 1LSB                   | 2LSB                         | 3LSB                         | --                           | --   | --    | --     |        |     |      |      |         |    |    |    |    |    |    |     |      |      |    |    |    |    |    |    |      |      |      |      |      |    |    |    |    |      |      |      |      |      |      |      |      |      |
| LINT  | 0LSB  | 1LSB                   | 2LSB                         | 3LSB                         | 4LSB                         | 5LSB | 6LSB  | 7LSB   |        |     |      |      |         |    |    |    |    |    |    |     |      |      |    |    |    |    |    |    |      |      |      |      |      |    |    |    |    |      |      |      |      |      |      |      |      |      |
| E.g. DINT value = H'12345678  |   |                        |                              |                              |                              |      |       |        |        |     |      |      |         |    |    |    |    |    |    |     |      |      |    |    |    |    |    |    |      |      |      |      |      |    |    |    |    |      |      |      |      |      |      |      |      |      |
| <table border="1"> <thead> <tr> <th>Number</th> <th>1st</th> <th>2nd</th> <th>3rd</th> <th>4th</th> </tr> </thead> <tbody> <tr> <td>DINT</td> <td>78</td> <td>56</td> <td>34</td> <td>12</td> </tr> </tbody> </table>   | Number  | 1st                    | 2nd                          | 3rd                          | 4th                          | DINT | 78    | 56     | 34     | 12  |      |      |         |    |    |    |    |    |    |     |      |      |    |    |    |    |    |    |      |      |      |      |      |    |    |    |    |      |      |      |      |      |      |      |      |      |
| Number  | 1st   | 2nd                    | 3rd                          | 4th                          |                              |      |       |        |        |     |      |      |         |    |    |    |    |    |    |     |      |      |    |    |    |    |    |    |      |      |      |      |      |    |    |    |    |      |      |      |      |      |      |      |      |      |
| DINT  | 78  | 56                     | 34                           | 12                           |                              |      |       |        |        |     |      |      |         |    |    |    |    |    |    |     |      |      |    |    |    |    |    |    |      |      |      |      |      |    |    |    |    |      |      |      |      |      |      |      |      |      |
| UNSIGNED<br>INTEGER   | USINT ( 1 byte ) · UINT ( 2 bytes ) · UDINT ( 4 bytes ) · ULINT ( 8 bytes )   |                        |                              |                              |                              |      |       |        |        |     |      |      |         |    |    |    |    |    |    |     |      |      |    |    |    |    |    |    |      |      |      |      |      |    |    |    |    |      |      |      |      |      |      |      |      |      |
|   | E.g. UDINT value = H'AABBCCDD   |                        |                              |                              |                              |      |       |        |        |     |      |      |         |    |    |    |    |    |    |     |      |      |    |    |    |    |    |    |      |      |      |      |      |    |    |    |    |      |      |      |      |      |      |      |      |      |
|   | <table border="1"> <thead> <tr> <th>Number</th> <th>1st</th> <th>2nd</th> <th>3rd</th> <th>4th</th> </tr> </thead> <tbody> <tr> <td>UDINT</td> <td>DD</td> <td>CC</td> <td>BB</td> <td>AA</td> </tr> </tbody> </table>  | Number                 | 1st                          | 2nd                          | 3rd                          | 4th  | UDINT | DD     | CC     | BB  | AA   |      |         |    |    |    |    |    |    |     |      |      |    |    |    |    |    |    |      |      |      |      |      |    |    |    |    |      |      |      |      |      |      |      |      |      |
| Number  | 1st   | 2nd                    | 3rd                          | 4th                          |                              |      |       |        |        |     |      |      |         |    |    |    |    |    |    |     |      |      |    |    |    |    |    |    |      |      |      |      |      |    |    |    |    |      |      |      |      |      |      |      |      |      |
| UDINT   | DD  | CC                     | BB                           | AA                           |                              |      |       |        |        |     |      |      |         |    |    |    |    |    |    |     |      |      |    |    |    |    |    |    |      |      |      |      |      |    |    |    |    |      |      |      |      |      |      |      |      |      |
| STRING  | ASCII, 1 or 2 bytes   |                        |                              |                              |                              |      |       |        |        |     |      |      |         |    |    |    |    |    |    |     |      |      |    |    |    |    |    |    |      |      |      |      |      |    |    |    |    |      |      |      |      |      |      |      |      |      |
|   | STRING : 2 bytes character count + 1 byte character   |                        |                              |                              |                              |      |       |        |        |     |      |      |         |    |    |    |    |    |    |     |      |      |    |    |    |    |    |    |      |      |      |      |      |    |    |    |    |      |      |      |      |      |      |      |      |      |
|   | <table border="1"> <thead> <tr> <th></th> <th colspan="2">Contents ( Charcount )</th> <th colspan="4">Contents ( String contents )</th> </tr> </thead> <tbody> <tr> <td>STRING</td> <td>04</td> <td>00</td> <td>4D</td> <td>69</td> <td>6C</td> <td>6C</td> </tr> </tbody> </table>   |                        | Contents ( Charcount )       |                              | Contents ( String contents ) |      |       |        | STRING | 04  | 00   | 4D   | 69      | 6C | 6C |    |    |    |    |     |      |      |    |    |    |    |    |    |      |      |      |      |      |    |    |    |    |      |      |      |      |      |      |      |      |      |
|   |   | Contents ( Charcount ) |                              | Contents ( String contents ) |                              |      |       |        |        |     |      |      |         |    |    |    |    |    |    |     |      |      |    |    |    |    |    |    |      |      |      |      |      |    |    |    |    |      |      |      |      |      |      |      |      |      |
|   | STRING  | 04                     | 00                           | 4D                           | 69                           | 6C   | 6C    |        |        |     |      |      |         |    |    |    |    |    |    |     |      |      |    |    |    |    |    |    |      |      |      |      |      |    |    |    |    |      |      |      |      |      |      |      |      |      |
|   | STRING2 : 2 bytes character count + 2 byte character  |                        |                              |                              |                              |      |       |        |        |     |      |      |         |    |    |    |    |    |    |     |      |      |    |    |    |    |    |    |      |      |      |      |      |    |    |    |    |      |      |      |      |      |      |      |      |      |
|   | <table border="1"> <thead> <tr> <th></th> <th colspan="2">Contents ( Charcount )</th> <th colspan="8">Contents ( String contents )</th> </tr> </thead> <tbody> <tr> <td>STRING2</td> <td>04</td> <td>00</td> <td>4D</td> <td>00</td> <td>69</td> <td>00</td> <td>6C</td> <td>00</td> <td>6C</td> <td>00</td> </tr> </tbody> </table>  |                        | Contents ( Charcount )       |                              | Contents ( String contents ) |      |       |        |        |     |      |      | STRING2 | 04 | 00 | 4D | 00 | 69 | 00 | 6C  | 00   | 6C   | 00 |    |    |    |    |    |      |      |      |      |      |    |    |    |    |      |      |      |      |      |      |      |      |      |
|   | Contents ( Charcount )  |                        | Contents ( String contents ) |                              |                              |      |       |        |        |     |      |      |         |    |    |    |    |    |    |     |      |      |    |    |    |    |    |    |      |      |      |      |      |    |    |    |    |      |      |      |      |      |      |      |      |      |
| STRING2   | 04  | 00                     | 4D                           | 00                           | 69                           | 00   | 6C    | 00     | 6C     | 00  |      |      |         |    |    |    |    |    |    |     |      |      |    |    |    |    |    |    |      |      |      |      |      |    |    |    |    |      |      |      |      |      |      |      |      |      |
| SHORT_STRING : 1 byte character count + 1 byte character  |   |                        |                              |                              |                              |      |       |        |        |     |      |      |         |    |    |    |    |    |    |     |      |      |    |    |    |    |    |    |      |      |      |      |      |    |    |    |    |      |      |      |      |      |      |      |      |      |
| <table border="1"> <thead> <tr> <th></th> <th colspan="2">Contents ( Charcount )</th> <th colspan="4">Contents ( String contents )</th> </tr> </thead> <tbody> <tr> <td>STRING</td> <td>04</td> <td></td> <td>4D</td> <td>69</td> <td>6C</td> <td>6C</td> </tr> </tbody> </table> |   | Contents ( Charcount ) |                              | Contents ( String contents ) |                              |      |       | STRING | 04     |     | 4D   | 69   | 6C      | 6C |    |    |    |    |    |     |      |      |    |    |    |    |    |    |      |      |      |      |      |    |    |    |    |      |      |      |      |      |      |      |      |      |
|   | Contents ( Charcount )  |                        | Contents ( String contents ) |                              |                              |      |       |        |        |     |      |      |         |    |    |    |    |    |    |     |      |      |    |    |    |    |    |    |      |      |      |      |      |    |    |    |    |      |      |      |      |      |      |      |      |      |
| STRING  | 04  |                        | 4D                           | 69                           | 6C                           | 6C   |       |        |        |     |      |      |         |    |    |    |    |    |    |     |      |      |    |    |    |    |    |    |      |      |      |      |      |    |    |    |    |      |      |      |      |      |      |      |      |      |

| Data Type                  | Description  |                 |                             |                  |         |   |         |         |     |
|----------------------------|--|-----------------|-----------------------------|------------------|---------|---|---------|---------|-----|
| Fixed LENGTH<br>BIT STRING | BYTE ( 1 byte ) · WORD ( 2 bytes ) · DWORD ( 4 bytes ) · LWORD ( 8 bytes ) |                 |                             |                  |         |   |         |         |     |
|                            |  | 1st             | 2nd                         | 3rd              | 4th     | 5th   | 6th     | 7th     | 8th |
|                            | Byte   | 7...0           | --                          | --               | --      | --  | --      | --      | --  |
|                            | WORD   | 7...0           | 15...8                      | --               | --      | --  | --      | --      | --  |
|                            | DWORD  | 7...0           | 15...8                      | 23...16          | 31...24 | --  | --      | --      | --  |
| LWORD                      | 7...0  | 15...8          | 23...16                     | 31...24          | 39...32 | 47...40   | 55...48 | 63...56 |     |
| STRINGI                    | A single string consists multiple language representation.                 |                 |                             |                  |         |   |         |         |     |
|                            | Name   |                 | Data Type                   |                  |         | Meaning   |         |         |     |
|                            | Number   |                 | USINT                       |                  |         | The number of internationalized character strings   |         |         |     |
|                            | Strings  |                 | Array of :<br>Struct of :   |                  |         | Array of individual internationalized character strings   |         |         |     |
|                            | LanguageChar1  |                 | USINT                       |                  |         | The first ASCII character of the ISO 639-2/T language   |         |         |     |
|                            | LanguageChar2  |                 | USINT                       |                  |         | The second ASCII character of the ISO 639-2/T language  |         |         |     |
|                            | LanguageChar3  |                 | USINT                       |                  |         | The third ASCII character of the ISO 639-2/T language   |         |         |     |
|                            | CharStringStruct   |                 | USINT                       |                  |         | The structure of the character string · limited to the Elementary Data type value 0xD0 ( STRING ) · 0xD5 ( STRING2 ) · 0xD9 ( STRINGN ) and 0xDA ( SHORT_STRING ) |         |         |     |
|                            | CharSet  |                 | UINT                        |                  |         | The character set which the character string is based on which comes from IANA MIB Printer Code ( RFC 1759 ) .  |         |         |     |
|                            | InternationalString  |                 | Defined in CharStringStruct |                  |         | An array of 8-bit octet elements which is the actual international character string   |         |         |     |
| ISO 639-2/T language :     |  |                 |                             |                  |         |   |         |         |     |
| Language                   |  | First Character |                             | Second Character |         | Third Character   |         |         |     |
| English                    |  | e               |                             | n                |         | G   |         |         |     |
| French                     |  | f               |                             | r                |         | e   |         |         |     |
| Spanish                    |  | s               |                             | p                |         | a   |         |         |     |

| Data Type | Description  |     |     |     |     |     |     |  |        |     |     |     |     |     |     |       |      |    |    |    |    |    |    |    |
|-----------|--|-----|-----|-----|-----|-----|-----|--|--------|-----|-----|-----|-----|-----|-----|-------|------|----|----|----|----|----|----|----|
|           | Italian  | i   | t   | a   |     |     |     |  |        |     |     |     |     |     |     |       |      |    |    |    |    |    |    |    |
| STRUCT    | <p>STRUCT of : Any Data Type composes the structure.<br/>                     E.g. STRUCT of { BOOL · UINT · DINT } = { TRUE · H'1234 · H'56789ABC }</p> <table border="1" data-bbox="336 461 1348 573"> <thead> <tr> <th></th> <th>1st</th> <th>2nd</th> <th>3rd</th> <th>4th</th> <th>5th</th> <th>6th</th> <th>7th</th> </tr> </thead> <tbody> <tr> <td>Byte</td> <td>01</td> <td>34</td> <td>12</td> <td>BC</td> <td>9A</td> <td>78</td> <td>56</td> </tr> </tbody> </table> |     |     |     |     |     |     |  |        | 1st | 2nd | 3rd | 4th | 5th | 6th | 7th   | Byte | 01 | 34 | 12 | BC | 9A | 78 | 56 |
|           | 1st  | 2nd | 3rd | 4th | 5th | 6th | 7th |  |        |     |     |     |     |     |     |       |      |    |    |    |    |    |    |    |
| Byte      | 01   | 34  | 12  | BC  | 9A  | 78  | 56  |  |        |     |     |     |     |     |     |       |      |    |    |    |    |    |    |    |
| ARRAY     | <p>Array of : Any Data Type composes the array.<br/>                     E.g. ARRAY of UINTs = { 1 · 2 · 3 }</p> <table border="1" data-bbox="336 680 1329 792"> <thead> <tr> <th>Number</th> <th>1st</th> <th>2nd</th> <th>3rd</th> <th>4th</th> <th>5th</th> <th>6th</th> </tr> </thead> <tbody> <tr> <td>Array</td> <td>01</td> <td>00</td> <td>02</td> <td>00</td> <td>03</td> <td>00</td> </tr> </tbody> </table>   |     |     |     |     |     |     |  | Number | 1st | 2nd | 3rd | 4th | 5th | 6th | Array | 01   | 00 | 02 | 00 | 03 | 00 |    |    |
| Number    | 1st  | 2nd | 3rd | 4th | 5th | 6th |     |  |        |     |     |     |     |     |     |       |      |    |    |    |    |    |    |    |
| Array     | 01   | 00  | 02  | 00  | 03  | 00  |     |  |        |     |     |     |     |     |     |       |      |    |    |    |    |    |    |    |
| EPATH     | <p>It's a path that consists of multiple segments and references the class, instance and attribute of another object.<br/>                     E.g. Identity Object, Instance attribute 5 = "20 01 24 01 30 05 "</p>   |     |     |     |     |     |     |  |        |     |     |     |     |     |     |       |      |    |    |    |    |    |    |    |

### 9.4.4.3 Identity Object (Class ID: 01 Hex)

Identity information is stored in the Identity Object and consists of the Vendor ID, Device Type, Product Code and Major Revision for your device.

- **Service Code**

| Service code | Service Name         | Attribute       |                    | Description              |
|--------------|----------------------|-----------------|--------------------|--------------------------|
|              |                      | Class Attribute | Instance Attribute |                          |
| H'01         | Get_Attributes_All   | X               | V                  | Read all attributes.     |
| H'05         | Reset                | X               | V                  | Reset.                   |
| H'0E         | Get_Attribute_Single | X               | V                  | Read a single attribute. |

- **Class**

- Class ID : H'01

- **Instance**

- H'01 : Instance Attribute
- When Instance =1, Instance Attribute are listed below:

| Instance Attribute | Name           | Access Rule | Data Type    | Values  | Description  |
|--------------------|----------------|-------------|--------------|---|--|
| H'01               | Vendor ID      | Get         | UINT         | H'31F   | Delta Electronics, Inc.                                    |
| H'02               | Device Type    | Get         | UINT         | H'0C  | Data Type:<br>Communication Adapter                        |
| H'03               | Product Code   | Get         | UINT         | H'4002  | Product code   |
| H'04               | Revision       | Get         | STRUCT       | --  | Revision of this device:<br>Major, Minor.                  |
|                    | Major Revision |             | USINT        | H'01  | Major Revision Range:<br>H'01~H'7F                         |
|                    | Minor Revision |             | USINT        | H'01  | Minor Revision Range:<br>H'01~H'FF                         |
| H'05               | Status         | Get         | WORD         | H'64  | Status* <sup>1</sup>                                       |
| H'06               | Serial Number  | Get         | UDINT        | H'2374F75C  | The last 8 characters of the<br>MAC address 23: 74: f7: 5C |
| H'07               | Product Name   | Get         | SHORT_STRING | The maximum number of a product name is<br>32 words.<br>(Data length +Product Name) |  |

| Instance Attribute | Name | Access Rule | Data Type | Values   | Description   |
|--------------------|------|-------------|-----------|----------|---------------|
|                    |      |             |           | ( H'0D ) | AX-816EP0ME1T |

\*1 : Status Description (H'05)

| Bit ( s ) | Name                      | Description   |
|-----------|---------------------------|---|
| 0         | Owned                     | Display if the device has an owner connection.<br>0: No<br>1: Yes   |
| 1         | Reserved                  | 0 : Always OFF  |
| 2         | Configured                | Display if the device is configured or not.<br>0: No<br>1: Yes  |
| 3         | Reserved                  | 0 : Always OFF  |
| 4-7       | Extended Device Status    | 0 : Self-Testing<br>1 : Firmware Update<br>2 : At least one faulted I/O connection<br>3 : No I/O connections established<br>4 : Non-Volatile Configuration bad<br>5 : Major Fault<br>6 : At least one I/O connection in run mode<br>7 : At least one I/O connection established · all in idle mode<br>8-15 : Reserved |
| 8         | Minor Recoverable Fault   | 0: No minor recoverable fault detected<br>1: Minor recoverable fault detected   |
| 9         | Minor Unrecoverable Fault | 0: No minor unrecoverable fault detected<br>1: Minor unrecoverable fault detected   |
| 10        | Major Recoverable Fault   | 0: No major recoverable fault detected<br>1: Major recoverable fault detected   |
| 11        | Major Unrecoverable Fault | 0: No major unrecoverable fault detected<br>1: Major unrecoverable fault detected   |

#### 9.4.4.4 Assembly Object (Class ID: 04 Hex)

Assembly Objects are used to aggregate data for the input data and output data associated with I/O connections.

- **Service Code**

| Service Code | Service Name         | Attribute       |                    | Description              |
|--------------|----------------------|-----------------|--------------------|--------------------------|
|              |                      | Class Attribute | Instance Attribute |                          |
| H'0E         | Get_Attribute_Single | X               | V                  | Read a single attribute. |

- **Class**

- Class ID : H'04

- **Instance**

- H'64 : Output assembly
- H'65 : Input assembly
- H'66 : Dummy ( needed for compatibility )
- When Instance = 64~66, Instance Attribute are listed below:

| Instance Attribute | Name | Access Rule | Data Type     | Values | Description        |
|--------------------|------|-------------|---------------|--------|--------------------|
| H'03               | Data | Get         | ARRAY of BYTE | H'2    | IO Connection Data |

- **Example of reading and writing objects**

- To read Output assembly data, write the data as shown below

Service code : H'0E

Class ID : H'04

Instance ID : H'64

Attribute ID : H'03

- To read Input assembly data, write the data as shown below

Service code : H'0E

Class ID : H'04

Instance ID : H'65

Attribute ID : H'03

### 9.4.4.5 TCP/IP Interface Object (Class ID: F5 Hex)

- **Service Code**

| Service Code | Service Name         | Attribute       |                    | Description                      |
|--------------|----------------------|-----------------|--------------------|----------------------------------|
|              |                      | Class Attribute | Instance Attribute |                                  |
| H'0E         | Get_Attribute_Single | V               | V                  | Read a single attribute          |
| H'10         | Set_Attribute_Single | X               | V                  | Set values of a single attribute |

- **Class**

- Class ID = H'F5

- **Instance**

- H'00 : Class Attribute
- H'01 : Instance Attribute
- When Instance = 0, Class Attribute are listed below:

| Class Attribute | Name     | Access Rule | Data Type | Values | Description     |
|-----------------|----------|-------------|-----------|--------|-----------------|
| H'01            | Revision | Get         | UINT      | H'4    | Object revision |

- When Instance = 1, Instance Attribute are listed below:

| Instance Attribute | Name                     | Access Rule | Data Type | Values | Description   |
|--------------------|--------------------------|-------------|-----------|--------|---|
| H'01               | Status                   | Get         | DWORD     | H'2    | IP Status <sup>1</sup>                                |
| H'02               | Configuration Capability | Get         | DWORD     | H'20   | Configuration capability <sup>2</sup>                 |
| H'03               | Configuration Control    | Get/Set     | DWORD     | H'0    | Configuration control <sup>3</sup>                    |
| H'04               | Physical Link Object :   | Get         | STRUCT of | --     | Path to physical link object                          |
|                    | Path Size                |             | UINT      | H'0    | Size of Path  |
|                    | Path                     |             | EPATH     | --     | Logical segments identifying the physical link object |
| H'05               | Interface                | Get/Set     | STRUCT    | --     | TCP/IP network  |

| Instance Attribute | Name                             | Access Rule | Data Type | Values        | Description   |
|--------------------|----------------------------------|-------------|-----------|---------------|---|
|                    | Configuration :                  |             | of        |               | interface configuration.  |
|                    | IP Address                       |             | UDINT     | 192.168.1.5   | The device's IP address   |
|                    | Network Mask                     |             | UDINT     | 255.255.255.0 | The device's network mask   |
|                    | Gateway Address                  |             | UDINT     | 0             | Default gateway address   |
|                    | Name Server                      |             | UDINT     | 0             | Primary name server   |
|                    | Name Server 2                    |             | UDINT     | 0             | Secondary name server   |
|                    | Domain Name                      |             | STRING    | 00 00         | Default domain name   |
| H'06               | Host Name                        | Get         | STRING    | AX-8xxxxxxxxx | Device name   |
| H'13               | Encapsulation Inactivity Timeout | Get/Set     | UINT      | 120           | EIP equipment connection time; unit: seconds; range of values: 0~3600 |

When the master is communicating, the instance attribute H'03 and H'05 cannot be written.

- **Example of reading and writing objects**

- To read Instance Attribute H'03, write the data as shown below

Service code : H'0E  
Class ID : H'F5  
Instance ID : H'01  
Attribute ID : H'03

- To read Instance Attribute H'05, write the data as shown below

Service code : H'10  
Class ID : H'F5  
Instance ID : H'01  
Attribute ID : H'05  
Data Byte[0~3] : IP Address=192.168.1.5  
Byte[4~7] : Network Mask=255.255.255.0  
Byte[8~11] : Gateway Mask=0.0.0.0  
Byte[12~15] : Name Server =0  
Byte[16~19] : Name Server2 =0

\*1 : Interface status

| Status | Description  |
|--------|--|
| 0      | Interface Configuration attribute has not been configured.   |
| 1      | The Interface Configuration attribute contains valid configuration obtained from BOOTP, DHCP or non-volatile memory. |
| 2      | The Interface Configuration attribute contains valid configuration obtained from hardware.                           |

\*2 : Interface capability flags

| Bit | Description                                   |
|-----|---|
| 0   | BOOTP Client                                  |
| 1   | DNS Client                                    |
| 2   | DHCP Client                                   |
| 3   | DHCP-DNS Update                               |
| 4   | Configuration Settable                        |
| 5   | Hardware Configurable                         |
| 6   | Interface Configuration Change Requires Reset |

\*3 : Interface Configuration Control

| Status | Description   |
|--------|---|
| 0      | The device shall use the interface configuration values previously stored (for example, in non-volatile memory or via hardware switches). |
| 1      | The device shall obtain its interface configuration values via BOOTP.   |
| 2      | The device shall obtain its interface configuration values via DHCP upon start-up.  |

### 9.4.4.6 Ethernet Link Object (Class ID : F6 Hex)

- **Service Code**

| Service Code | Service Name         | Attribute       |                    | Description             |
|--------------|----------------------|-----------------|--------------------|-------------------------|
|              |                      | Class Attribute | Instance Attribute |                         |
| H'0E         | Get_Attribute_Single | V               | V                  | Read a single attribute |

- **Class**

- Class ID : H'F6

- **Instance**

- H'00 : Class Attribute
- H'01 : Instance Attribute
- When Instance = 0, Class Attribute are listed below:

| Class Attribute | Name     | Access Rule | Data Type | Values | Description     |
|-----------------|----------|-------------|-----------|--------|-----------------|
| H'01            | Revision | Get         | UINT      | H'04   | Object revision |

- When Instance =1, Instance Attribute are listed below:

| Instance Attribute | Name                 | Access Rule | Data Type         | Values     | Description   |
|--------------------|----------------------|-------------|-------------------|------------|---|
| H'01               | Interface Speed      | Get         | DWORD             | 0          | Interface speed ( indeterminate )                                 |
| H'02               | Interface Flags      | Get         | DWORD             | H'0D       | Ethernet port status <sup>*1</sup>                                |
| H'03               | Physical Address     | Get         | ARRAY of 6 USINTs | By Product | MAC address   |
| H'0B               | Interface Capability | Get         | STRUCT of :       | --         | Capabilities of Ethernet interface <sup>*2</sup>                  |
|                    | Capability Bits      |             | DWORD             | H'020000   | The definition of Ethernet interface capability                   |
|                    | Speed/Duplex Options |             | STRUCT of :       | --         | The definition of speed and duplex options of Ethernet interface. |
|                    | Speed/Duplex         |             | USINT             | H'00       | The count of speed/ duplex  |

| Instance Attribute | Name                  | Access Rule | Data Type            | Values | Description   |
|--------------------|-----------------------|-------------|----------------------|--------|---|
|                    | Array Count           |             |                      |        | options.  |
|                    | Speed/Duplex Array    |             | ARRAY of STRUCT of : | --     | Speed and duplex settings   |
|                    | Interface Speed       |             | UINT                 | H'00   | Ethernet interface speed. For example, 10 bps and 100 bps would be H'0A and H'64 accordingly.                       |
|                    | Interface Duplex Mode |             | USINT                | H'00   | Duplex mode capability of Ethernet interface. For example, half and full duplex would be H'00 and H'01 accordingly. |

\*1 : Interface Flag Table

| Bit ( s ) | Name                          | Description   |
|-----------|-------------------------------|---|
| 0         | Link Status                   | 0 indicates an inactive link<br>1 indicates an active link  |
| 1         | Half/Full Duplex              | 0 indicates half duplex<br>1 indicates full duplex  |
| 2-4       | Negotiation Status            | 0 : Auto-negotiation in progress<br>1 : Auto-negotiation and speed detection failed<br>2 : Auto negotiation failed but detected speed<br>3 : Successfully negotiated speed and duplex<br>4 : Auto-negotiation not attempted. Forced speed and duplex. |
| 5         | Manual Setting Requires Reset | shall be set zero   |
| 6         | Local Hardware Fault          | 0 indicates the interface detects no local hardware fault<br>1 indicates a local hardware fault is detected   |
| 7-31      | Reserved                      | 0   |

## \*2 : Interface Capability Bits

| Bit ( s ) | Name                          | Description   |
|-----------|-------------------------------|---|
| 0         | Manual Setting Requires Reset | Indicates whether or not the device requires a reset when instance attribute #6 (Interface Control attribute) changes.<br>0 indicates the device does not require a reset<br>1 indicates the device requires a rest |
| 1         | Auto-negotiate                | 0 indicates the interface does not support auto-negotiation<br>1 indicates the interface supports auto-negotiation  |
| 2         | Auto-MDIX                     | 0 indicates the interface does not support auto MDIX operation<br>1 indicates the interface supports auto MDIX operation  |
| 3         | Manual Speed/Duplex           | 0 indicates the interface does not support to set speed/duplex.<br>(Instance attribute #6, Interface Control attribute)<br>1 indicates the interface supports to set speed/duplex                                   |
| 4-31      | Reserved                      | shall be set 0  |

## 9.4.5 Delta EIP Product List

### 9.4.5.1 Delta EIP Product List (Adapters Supported)

| Positioning   | Product   | Version         |
|---------------|---|-----------------|
| Mid-range PLC | AHCPU501-EN、AHCPU511-EN、AHCPU521-EN、AHCPU531-EN     | V2.00           |
|               | AHCPU560-EN2  | V1.00           |
|               | AH10EN-5A   | V2.00           |
|               | AHRTU-ETHN-5A                                       | V1.00           |
|               | AH10EMC-5A  | V1.00           |
|               | AS300 Series  | V1.00           |
|               | AS200 Series  | V1.00           |
|               | AS300 Series ( AS-FEN02 communication card )        | V1.06 ( V1.00 ) |
|               | AS00SCM-A ( AS-FEN02 communication card )           | V2.02 ( V1.00 ) |
|               | AX-3 Series   | V1.01           |
|               | AX-8 Series   | V1.01           |
| Small PLC     | DVPES2-E Series                                     | V3.60           |
|               | DVP26SE   | V1.00           |
|               | DVP-ES3 Series                                      | V1.00           |
| Inverter      | CMM-EIP01/02 communication card ( VFD-M300 Series ) | V1.00           |
|               | CMC-EIP01 communication card ( VFD-C2000 Series )   | V1.06           |
|               | CMM-EIP03 communication card ( VFD-M300 Series )    | V1.00           |
|               | CMC-EIP02 communication card ( VFD-C2000 Series )   | V1.00           |

### 9.4.5.2 Delta EIP Product List (Scanners Supported)

| Positioning   | Product   | Version |
|---------------|---|---------|
| Mid-range PLC | AHCPU501-EN、AHCPU511-EN、AHCPU521-EN、AHCPU531-EN | V2.00   |
|               | AHCPU560-EN2                                    | V1.00   |
|               | AH10EN-5A                                       | V2.00   |
|               | AS300 Series、AS200 Series                       | V1.00   |
|               | AX-3 Series                                     | V1.01   |
|               | AX-8 Series                                     | V1.01   |
| Small PLC     | DVP-ES3 Series                                  | V1.00   |

## 9.5 Network Security

We suggest you to use closed network or use local network with a firewall to secure and prevent the Ethernet network as well as our products from any unwanted attacks.

**MEMO**



---

# Appendix A Troubleshooting

## Table of Contents

|            |  |            |
|------------|--|------------|
| <b>A.1</b> | <b>Troubleshooting</b> .....                               | <b>A-2</b> |
| A.1.1      | Basic Troubleshooting Steps .....                          | A-2        |
| A.1.2      | Clear Error States .....                                   | A-2        |
| A.1.3      | Troubleshooting SOP .....                                  | A-3        |
| A.1.4      | Viewing Log .....  | A-3        |
| <b>A.2</b> | <b>Troubleshooting of CPU Modules</b> .....                | <b>A-5</b> |
| A.2.1      | ERROR LED Indicators Blinking Every 0.5 Seconds .....      | A-5        |
| A.2.2      | ERROR LED Indicators Blinking Rapidly Every 2 Seconds..... | A-6        |
| A.2.3      | ERROR LED Indicators Blinking Rapidly Every 1 Second ..... | A-6        |
| <b>A.3</b> | <b>Troubleshooting of Function Blocks</b> .....            | <b>A-7</b> |
| A.3.1      | DL_CmpAX8xxEDrv.....                                       | A-7        |
| A.3.2      | Motion Control Related Instructions.....                   | A-8        |

## A.1 Troubleshooting

### A.1.1 Basic Troubleshooting Steps

This section introduces the types of errors which might occur during operation and their causes as well as resolutions. Complete the checklist below before looking further into the errors.


1. Check the following items:
  - The controller is operating under the specified conditions (considering the environmental, electronic, vibration safety and so on).
  - Power supply is connected properly to the controller.
  - The modules, terminals and cables are installed correctly.
  - All LED indicators work properly.
  - Set all the switches correctly.
2. Check the operational functions:
  - Check and eliminate errors from external devices.
  - Check system operation and logs through System Log in DIADesigner-AX.
3. Identify possible causes based on examination in point 1 and 2.
  - AX-8 Series
  - CPU
  - Parameter or program settings

### A.1.2 Clear Error States

This section introduces the methods to clear the error states. The system will keep going into error mode if the source errors are not resolved.

1. Turn off the CPU and restart again.
2. Perform **Reset Warm** to clear the error logs through DIADesigner-AX.
3. Perform **Reset Origin** to reset CPU to default and redownload the program through DIADesigner-AX.


### A.1.3 Troubleshooting SOP



### A.1.4 Viewing Log

When an error occurs, the corresponding error codes are generated and stored in the controller. On the **Log** tab of the **Device** pane, you are able to check all the events recorded during system startup and shutdown, application download and loading of boot application, custom entries, log entries from I/O drivers and from data source. Refer to **section 4.2.1.5** for more information on Log.

#### 1. Log Tab (Device > LOG)





## A.2 Troubleshooting of CPU Modules

Check the LED indicators and the error codes from the CPU modules, and refer to the following table for troubleshooting.

### A.2.1 ERROR LED Indicators Blinking Every 0.5 Seconds

- CPU error

| Error Code (16#) | Description  | Solution  |
|------------------|--|---|
| 0x2000           | CPU memory access is denied  | If the problem persists, contact the local authorized distributors.   |
| 0x2001           | CPU external memory access is denied   | If the problem persists, contact the local authorized distributors.   |
| 0x2002           | Either OS file or firmware-related file is corrupted or system backup is activated | If the problem persists, contact the local authorized distributors or update the firmware.                          |
| 0x2005           | GPIO failed to initialize  | If the problem persists, contact the local authorized distributors or update the firmware.                          |
| 0x2006           | Semaphore failed to establish  | If the problem persists, contact the local authorized distributors or update the firmware.                          |
| 0x2007           | Task failed to establish   | If the problem persists, contact the local authorized distributors or update the firmware.                          |
| 0x2008           | Unable to access data file   | If the problem persists, contact the local authorized distributors or update the firmware.                          |
| 0x2009           | PowerIC failed to initialize   | If the problem persists, contact the local authorized distributors or update the firmware.                          |
| 0x200A           | FPGA done condition mismatched   | If the problem persists, contact the local authorized distributors or update the firmware.                          |
| 0x200B           | Ethernet IP failed to initialize   | Redownload the project and select <b>Apply IP settings while download</b> .   |
| 0x200C           | PLC ID access denied   | If the problem persists, contact the local authorized distributors or update the firmware.                          |
| 0x200D           | Error detected in the check sum of %M device                                       | 1. Check whether the 24V power supply is sufficient or not.<br>2. Amplify 24V power supply if the problem persists. |
| 0x200E           | The MRAM position set by the cfg file and FW do NOT match.                         | If the problem persists, contact the local authorized distributors  |

|        |  |  |
|--------|--|--|
| 0x200F | Codesyscontrol file is missing or corrupted.           | If the problem persists, contact the local authorized distributors                                     |
| 0x2100 | The number of MODBUS TCP connections exceed the range. | Please refer to <b>section 2.2 CPU Module Specifications</b> and adjust the connection to the maximum. |
| 0x3000 | Hardware access error                                  | If the problem persists, contact the local authorized distributors.                                    |
| 0x3002 | SSD lifespan reached limit.                            | If the problem persists, contact the local authorized distributors                                     |

### A.2.2 ERROR LED Indicators Blinking Rapidly Every 2 Seconds

| Error Code (16#) | Description                                      | Solution   |
|------------------|--|--|
| 0x2004           | The external 24V power supply is in low voltage. | Check whether the power supply connected to the module is stable or not. |

### A.2.3 ERROR LED Indicators Blinking Rapidly Every 1 Second

| Error Code (16#) | Description             | Solution  |
|------------------|-------------------------|---|
| 0x3001           | Factory test info error | If the problem persists, contact the local authorized distributors. |

## A.3 Troubleshooting of Function Blocks

### A.3.1 DL\_CmpAX8xxEDrv

The following errors are specified as warnings. No error indicators will appear and the CPU can still run.

| Error code (16#) | Item                                 | Description   | Solution  |
|------------------|--------------------------------------|---|---|
| 0                | DFB_NO_ERROR                         | No error  | N/A   |
| 0x5              | DFB_CAP_SOURCE_OUT_RANGE             | Capture trigger source is out of range.   | Source range is between <b>BuiltIn_DIO</b> X0~X3  |
| 0x6              | DFB_CAP_SOURCE_IS_ACTIVE             | Capture trigger source is already active.   | Please check if any other function block has used the same trigger source.  |
| 0x7              | DFB_PWM_INPUT_OUT_RANGE              | DFB_PWM Input is out of range or values are invalid.  | Please check if the parameters of DFB_PWM are correct   |
| 0x8              | DFB_PWM_DO_OTH_FUNCTION_ACT          | DO is already in use for other function.  | Please check if any other function block has used the same DO for other function or PWM is already active in other function block.  |
| 0x9              | DFB_UDC_COUNTER_NUMBER_MISMATCH_MODE | Counter number (0~7) mismatched with counter mode.  | Please check if the counter number has supported this counter mode.   |
| 0xA              | DFB_UDC_MODE_OUT_RANGE               | Counter mode is out of range.   | Please check if the parameters of DFB_Counter are correct.  |
| 0xB              | DFB_UDC_COUNTER_NUMBER_IS_ACT        | Channel of counter number has been active or counter mode is already set by other function block. | Disable other DFB_Counter function blocks or set up the same settings.  |
| 0xC              | DFB_TCMP_FIFO_FULL                   | Compare FIFO position table is full.  | Please reset FIFO table.  |
| 0xD              | DFB_TCMP_OS_TIME_OUT_RANGE           | <b>rOneShotTime</b> or <b>byTimeExten</b> is out of range.  | <b>rOneShotTime</b> range of 5000 ~ 0.0003(ms)<br><b>byTimeExten</b> range of 1~15  |
| 0xE              | DFB_TCMP_DO_OTH_FUNCTION_ACT         | DO is already in use for other function.  | Please check if any other function block has used the same DO for other functions or PWM is already active in other function block. |

| Error code (16#) | Item                          | Description  | Solution   |
|------------------|-------------------------------|--|--|
| 0xF              | DFB_TCMP_FIFO_WRITE_ACT       | FIFO table is writing.                                       | Please check if any other function block has used other functions.         |
| 0x10             | DFB_TCMP_ACT                  | TCMP function is active.                                     | Please check if any other function block has used other functions.         |
| 0x11             | DFB_TCMP_TABLE_SIZE_OUT_RANGE | TCMP table size is out of range.                             | Range: 1~255   |
| 0x12             | DFB_DVR_GET_VER_ERROR         | Get device version error                                     | Not supported in FPGA version  |
| 0x14             | DFB_SRT_TYPE_ERROR            | Retain type error  | Please check if the parameter Retain Type of DFB_SetRetainType is correct. |
| 0x15             | DFB_SRD_PASSWORD_ERROR        | Password value error   | Please check if the parameter sPassword of DFB_SetRestorePwd is correct.   |
| 0x16             | DFB_SIPC_LAN_PORT_INVALID     | Lanport number error   | Please check if the parameter LanPort of DFB_SetIPConfig is correct.       |
| 0x17             | DFB_SIPC_MASK_INVALID         | Mask address value error                                     | Please check if the parameter SubnetMask of DFB_SetIPConfig is correct.    |
| 0x18             | DFB_SIPC_GATEWAY_INVALID      | Gateway address value error                                  | Please check if the parameter Gateway of DFB_SetIPConfig is correct.       |
| 0x19065          | DFB_SSI_INPUT_OUT_RANGE       | DFB_SSI_Encoder Input is out of range or values are invalid. | Please check if the parameter of DFB_SSI_Encoder is correct.               |
| 0x19066          | DFB_SSI_CONF_ERROR            | Serial communication mode config error                       | Change device parameter <b>Serial communication mode</b> settings to SSI.  |
| 0x19067          | DFB_SSI_NOT_SUPPORTED         | Device does not support this function.                       | Check if the FPGA version is v0x25 or later.                               |
| 0x19068          | DFB_SSI_IS_ACTIVE             | SSI Encoder is already active                                | SSI Encoder is already active.   |

### A.3.2 Motion Control Related Instructions

The errors which occur in DL\_MotionControl or DL\_MotionControlLight are specified as warnings; however, no error indicators will appear and the CPU can still run. Refer to **AX Series Motion Controller Manual** for the troubleshooting of DL\_MotionControl.



---

## Appendix B BIOS Settings

### Table of Contents

|            |   |            |
|------------|---|------------|
| <b>B.1</b> | <b>Basic Settings and Operation of BIOS .....</b> | <b>B-2</b> |
| B.1.1      | Main.....   | B-3        |
| B.1.2      | Advanced.....                                     | B-4        |
| B.1.3      | Chipset.....                                      | B-5        |
| B.1.4      | Security.....                                     | B-8        |
| B.1.5      | Boot.....   | B-9        |
| B.1.6      | Save & Exit .....                                 | B-10       |


## B.1 Basic Settings and Operation of BIOS

When the computer boots up, following with the message **Press <Del> or <F2> to enter setup** on the screen, click either the **Del** key or the **F2** key to enter BIOS settings.

### 1. BIOS keyboard shortcuts

| Key     | Function                         | Key | Function                                |
|---------|----------------------------------|-----|---|
| ↑ ↓ ← → | Move among items                 | F1  | Keys operation support                  |
| Enter   | Enter or select the current item | F2  | Restore device to the previous settings |
| + -     | Adjust values                    | F3  | Restore device to factory settings      |
| Esc     | Escape                           | F4  | Save current settings                   |

### 2. Menu bar




| Menu     | Function                       | Menu        | Function              |
|----------|--------------------------------|-------------|-----------------------|
| Main     | Basic settings                 | Security    | Security settings     |
| Advanced | Settings of advanced functions | Boot        | Startup settings      |
| Chipset  | Chipset settings               | Save & Exit | Save changes and exit |

( Use the ← 、 → key to browse each menu. )

### B.1.1 Main

Here you can find information such as Total Memory, System Language, etc. in the Main menu:




| Item            | Default | Description             |
|-----------------|---------|-------------------------|
| System Language | English | N/A                     |
| System Date     | N/A     | Settings of system date |
| System Time     | N/A     | Settings of system time |

**B**

## B.1.2 Advanced


Here you can find information such as CPU Configuration, Power & Performance, etc. in the Advanced menu.



| Item                              | Default | Description                               |
|-----------------------------------|---------|---|
| CPU Configuration                 | N/A     | Settings of CPU parameters                |
| Power & Performance               | N/A     | Settings of CPU and GPU power performance |
| Thermal Configuration             | N/A     | Settings of Thermal parameters            |
| Intel® Time Coordinated Computing | N/A     | Settings of Intel TCC                     |
| ACPI Setting                      | N/A     | Settings of ACPI                          |
| USB Configuration                 | N/A     | Settings of USB parameter                 |

### B.1.3 Chipset

Here you can find information such as System Agent Configuration, PCH-IO Configuration, etc. in the Chipset menu:




| Item                       | Default | Description              |
|----------------------------|---------|--------------------------|
| System Agent Configuration | N/A     | Settings of system agent |
| PCH-IO Configuration       | N/A     | Settings of PCH-IO       |

● **System Agent Configuration**

Here you can find information such as Memory Configuration and Graphic Configuration in the **System Agent Configuration** view:


**B**



| Item                   | Default | Description                   |
|------------------------|---------|-------------------------------|
| Memory Configuration   | N/A     | Settings of memory parameters |
| Graphics Configuration | N/A     | Settings of graphics output   |
| Display setup Menu     | N/A     | Settings of display interface |

● **PCH-IO Configuration**

Here you can find information such as PCIE, SATA and USB Configuration in the PCH-IO Configuration view:




**B**

| Item                       | Default   | Description                                |
|----------------------------|-----------|--|
| PCI Express Configuration  | N/A       | PCIe settings                              |
| SATA And RST Configuration | N/A       | SATA settings                              |
| USB Configuration          | N/A       | USB settings                               |
| Serial IO Configuration    | N/A       | Serial I/O settings                        |
| Status After G3            | S0 Status | Settings of auto startup in power-on state |

## B.1.4 Security


Here you can find information such as Administrator Password and User Password in the Security menu:



| Item                   | Default | Description                             |
|------------------------|---------|---|
| Administrator Password | N/A     | Settings of the administrative password |
| User Password          | N/A     | Settings of the user password           |
| Secure Boot            | N/A     | Secure boot menu                        |

## B.1.5 Boot


Here you can find information such as Setup Prompt Timeout, Bootup NumLock State, etc. in the Boot menu:



| Item                   | Default  | Description                        |
|------------------------|----------|------------------------------------|
| Setup Prompt Timeout   | 1        | N/A                                |
| Bootup NumLock State   | off      | N/A                                |
| Quiet Boot             | Enabled  | N/A                                |
| Boot Option Priorities | N/A      | Setting the boot order for devices |
| Fast Boot              | Disabled | N/A                                |

## B.1.6 Save & Exit

Here you can find information such as Save Changes and Exit, Discard Changes and Exit, etc. in the Save & Exit menu:



| Item                      | Default | Description   |
|---------------------------|---------|---|
| Save Changes and Exit     | N/A     | Save the current changes and exit                         |
| Discard Changes and Exit  | N/A     | Restore device to the previous settings and exit          |
| Save Changes and Reset    | N/A     | Save the current changes then reset the PC                |
| Discard Changes and Reset | N/A     | Restore device to the previous settings then reset the PC |
| Save Changes              | N/A     | Save the current changes                                  |
| Discard Changes           | N/A     | Restore device to the previous settings                   |
| Restore Defaults          | N/A     | Restore device to factory settings                        |
| Save as User Defaults     | N/A     | Save the current user settings as defaults                |
| Restore User Defaults     | N/A     | Restore the user defaults                                 |
| Boot Override             | N/A     | Force reboot the device                                   |



---

# Appendix C Settings and Operation of Windows/Linux

## Table of Contents

|            |   |             |
|------------|---|-------------|
| <b>C.1</b> | <b>Basic Settings of UWF</b> .....                            | <b>C-2</b>  |
| C.1.1      | UWF Execution via PAC_Tool .....                              | C-2         |
| C.1.2      | Read Current Status.....                                      | C-2         |
| C.1.3      | Enable UWF .....  | C-3         |
| C.1.4      | Disable UWF.....  | C-4         |
| C.1.5      | Fix UWF.....  | C-4         |
| <b>C.2</b> | <b>Display Language Settings</b> .....                        | <b>C-5</b>  |
| <b>C.3</b> | <b>UWF Exclusion Settings</b> .....                           | <b>C-6</b>  |
| <b>C.4</b> | <b>Replace Original Project with USB Backup Project</b> ..... | <b>C-7</b>  |
| C.4.1      | Retrieve a Project from PLC.....                              | C-7         |
| C.4.2      | Create a Project from DIADesigner-AX.....                     | C-8         |
| C.4.3      | USB Project Backup Tool .....                                 | C-8         |
| C.4.4      | Project Mode .....  | C-9         |
| C.4.5      | Clear mode .....  | C-10        |
| C.4.6      | Extraction Password Settings.....                             | C-11        |
| C.4.7      | Project Replacement .....                                     | C-12        |
| <b>C.5</b> | <b>IP Address Settings</b> .....                              | <b>C-13</b> |
| C.5.1      | Modify through Project Download.....                          | C-13        |
| C.5.2      | Modify through Windows Settings .....                         | C-13        |
| <b>C.6</b> | <b>Reset IP Address</b> .....                                 | <b>C-14</b> |
| C.6.1      | Connection Denied to PLC .....                                | C-14        |
| <b>C.7</b> | <b>System Operation</b> .....                                 | <b>C-16</b> |

---

## C.1 Basic Settings of UWF

In factory settings, the Unified Write Filter (UWF) is turned on to protect Windows system from file corruptions in abnormal power outages or crashes.

If you need to turn off UWF for software installation or parameter adjustment reasons, be sure to turn it on again right after the installation or settings are completed.

When UWF is switched off, the LED indicator on AX-8 Series PLC, FB1 and FB2, will flash consecutively to alert the user that UWF is currently off.

### C.1.1 UWF Execution via PAC\_Tool

The main function of PAC\_Tool is to protect the C drive in Windows system. When UWF is turned on, the data written to the C drive will be stored in the memory and it will be removed once the device is rebooted. To perform this function, click **PAC\_Tool.exe** on the computer desktop.



### C.1.2 Read Current Status

Open PAC\_Tool and the **Current Status** will be shown as below:

- **Disabled:** UWF is currently turned off and changes will be saved after power outages.



- **Enabled:** UWF is currently turned on and changes will not be saved after power outages.



### C.1.3 Enable UWF

Refer to the following steps to activate UWF.

1. Click **Enable**.
2. Click **Reboot** to restart.



### C.1.4 Disable UWF

Refer to the following steps to deactivate UWF.

1. Click **Enable**.
2. Click **Reboot** to restart.



### C.1.5 Fix UWF

Refer to the following steps to fix UWF.

1. Click **Fix**.
2. Click **Reboot** to restart.



## C.2 Display Language Settings

Refer to the following steps to switch display languages.

- If the Current Status is **Disabled**:

1. Select the preferred language.
2. Click **Reboot** to restart.



- If the Current Status is **Enabled**, you should turn off UWF in advanced.


1. Click **Disable**.
2. Click **Reboot** to restart.
3. Select the preferred language.
4. Click **Reboot** to restart.



### C.3 UWF Exclusion Settings

Refer to the following steps to exclude folders or files from write protection while the UWF is enabled.

- If the Current Status is **Enabled**.
  1. Click **Add Folder** to select the folders or files to be excluded.
  2. Click **Reboot** to restart.



\*1: The Touch Panel tab is not available here since it is exclusively for Panel devices.

\*2: In some models the storage path is set to be in the D drive; hence, files and data could be lost due to unexpected shutdown of the device.

## C.4 Replace Original Project with USB Backup Project


This section introduces how to create an USB backup project and the way to replace the ongoing project in AX-8 Series PLC with the USB backup project.

When the backup project contains the same retentive data as the project currently running on the target PLC, please refer to **section C.4.1** to acquire the project. After the project is successfully replaced, the retentive data will be preserved.


If you are not sure whether the retentive data of both projects are consistent, or if it is not necessary to keep the existing retentive data, please refer to **section C.4.2** to acquire the project. After the project is successfully replaced, the system will automatically reset the retentive data.

### C.4.1 Retrieve a Project from PLC

1. The PlcLogic folder on AX-8 Series PLC can be accessed through DIADesigner-AX.
2. Open a new project and check if the connection with the PLC has been established (path: **Device > Communication Setting > Scan Network**).




3. Check the AX-8 Series PLC folder system through the path: **Device > Files**. Click the button marked below to retrieve the PlcLogic folder.




## C.4.2 Create a Project from DIADesigner-AX

1. Open DIADesigner-AX, then click **Online > Create Boot Application**.



2. Create the folder structure **PlcLogic\Application** and drag the created **Boot Application** into the **Application** folder.



## C.4.3 USB Project Backup Tool

Software: PBT

Operating system: Windows 7 (Service Pack 1 or higher) / 8 / 10 (32 / 64 Bit)

Download path: <https://downloadcenter.deltaww.com/downloadCenterCounter.aspx?DID=41632&DocPath=1&hl=zh-TW>

Use PBT.exe to compress the obtained PlcLogic folder into PlcLogic.zip. Store this compressed file in the root directory of the USB flash drive. You can then use the USB flash drive to replace the project on the target PLC.

| 名稱              | 修改日期               | 類型     | 大小       |
|-----------------|--------------------|--------|----------|
| 7za.dll         | 2019/2/22 上午 12:00 | 應用程式擴充 | 263 KB   |
| 7za             | 2019/2/22 上午 12:00 | 應用程式   | 723 KB   |
| 7za.dll         | 2019/2/22 上午 12:00 | 應用程式擴充 | 155 KB   |
| BMC_GENERIC.dll | 2021/1/14 下午 01:30 | 應用程式擴充 | 612 KB   |
| MRAMtoData      | 2021/8/18 下午 04:34 | 應用程式   | 6,002 KB |
| PBT             | 2023/4/10 下午 05:17 | 應用程式   | 1,764 KB |


### C.4.4 Project Mode

1. Select **Load project from disk to device** to create a backup project file from the Boot Application generated by the PLC or DIADesigner-AX. This file is to replace the project currently running on the target PLC.older: The PlcLogic folder obtained from the PLC or DIADesigner-AX.
2. Zip File: Location where the ZIP file will be created.
3. Password: Password for the ZIP file (optional).
4. Password Check: Confirm the password.
5. Copy Max Count: The maximum number of project restorations; once the limit is exceeded, the ZIP file will be deleted.
6. Retain Type: MRAM mode provides 96KB of storage space, while UPS mode (supported on Linux system only) extends this to 10MB Retain/Persistent + 5M Mdev.
7. Clean Retain: Specify whether to clear the current MRAM data before project restoration (supported in MRAM mode only).
8. Write Password: Write the password to the PLC for extracting the ZIP file (supported on Windows system only). Please refer to **section C.4.6**.



### C.4.5 Clear mode

Select **Remove project from device** to generate a file which will be used to clear the project currently running on the target PLC.




1. Zip File: Location where the ZIP file will be created.
2. Password: Password for the ZIP file (optional).
3. Password Check: Confirm the password.
4. Copy Max Count: The maximum number of project restorations; once the limit is exceeded, the ZIP file will be deleted.
5. Retain Type: MRAM mode provides 96KB of storage space, while UPS mode (supported on Linux system only) extends this to 10MB Retain/Persistent + 5M Mdev.
6. Clean Retain: Specify whether to clear the current MRAM data before project restoration (supported in MRAM mode only).
7. Write Password: Write the password to the PLC for extracting the ZIP file (supported on Windows system only). Please refer to **section C.4.6**.

## C.4.6 Extraction Password Settings

If the backup project file is encrypted with a password, users must write the extraction password to the target PLC before project replacement. The password length is limited to 20 characters.


Method 1 (Windows only): Place the PBT tool on the desktop, and use **Write Password** to set the extraction password.



Method 2: In the PLC project, call the **DFB\_SetRestorePwd** function block. Enter the password in the **sPassword** input pin, then trigger the **xExecute** pin on its rising edge to complete the password setting.

For the AX-8 Series models, the location where of the **DFB\_SetRestorePwd** function block varies as follows:

1. AX-8xxEP0MB and AX-8xxEP0CB: DL\_CmpAX8xxEDrv Library
2. AX-8xxEP0CE and AX-8xxEP0ME: DL\_CmpAX8xxEDrvLinux Library
3. AX-8H1E30CD2T: DL\_CmpAX8xxEDrvLinuxNonFPGA Library
4. AX-864EP1ME1TP: DL\_CmpAX8Gen2BasicDrvLinux
5. AX-8DH1ECP1CE1TP: DL\_CmpAX8xxEDrvLinux



## C.4.7 Project Replacement

1. Before powering on the PLC, insert the USB flash drive which contains the backup project into the target PLC, then turn the power on.
2. If the ZIP file is encrypted, the extraction password should be written to the PLC (please refer to **section C.4.6**).
3. After the AX-8 Series PLC is powered on, replacement will be executed automatically with intermittent buzzing sounds to remind users.
4. Upon successful project replacement, the buzzer will sound intermittently. After the USB flash drive is removed, the PLC will reboot automatically and run with the backup project.
5. If the PLC cannot decrypt the backup project in the USB flash drive, the buzzer will sound continuously and the Error LED will keep flashing. After the USB flash drive is removed, the PLC will reboot automatically and run with the original project.
6. Repeat step 1 to 4 if the project replacement fails.

## C.5 IP Address Settings

### C.5.1 Modify through Project Download


The IP address of AX-8 Series PLC can be modified by downloading the project. To Enter the IP settings page, go to **Device > Parameters**. IP-related settings can be adjusted in the **Value** column of the respective network interface. After the completion, download the project to the AX-8 Series PLC and the settings take effect immediately.

| Parameter                  | Type                | Value              | Default Value      | Unit | Description   |
|----------------------------|---------------------|--------------------|--------------------|------|---|
| Application Run Mode       | BOOL                | false              | false              |      | [True]:Enable Run Mode [False]:Disable Run Mode                         |
| Serial Communication Mode  | Enumeration of BYTE | RS-485             | RS-485             |      | Choose Serial Communication Mode  |
| GLAN1 NetworkInterface     |                     |                    |                    |      |   |
| GLAN1 NetworkInterfaceMode | Enumeration of BOOL | static-IP          | static-IP          |      | Configure NetworkInterface Mode of the Controller on the EtherNet GLAN1 |
| GLAN1 IPAddress            | ARRAY[0..3] OF BYTE | [192, 168, 0, 10]  | [192, 168, 0, 10]  |      | Configure IP Address of the Controller on the EtherNet GLAN1 (IP).      |
| GLAN1 SubnetMask           | ARRAY[0..3] OF BYTE | [255, 255, 255, 0] | [255, 255, 255, 0] |      | Configure IP Address of the Controller on the EtherNet GLAN1 (Mask).    |
| GLAN2 NetworkInterface     |                     |                    |                    |      |   |
| GLAN2 NetworkInterfaceMode | Enumeration of BOOL | static-IP          | static-IP          |      | Configure NetworkInterface Mode of the Controller on the EtherNet GLAN2 |
| GLAN2 IPAddress            | ARRAY[0..3] OF BYTE | [192, 168, 1, 10]  | [192, 168, 1, 10]  |      | Configure IP Address of the Controller on the EtherNet GLAN2 (IP).      |
| GLAN2 SubnetMask           | ARRAY[0..3] OF BYTE | [255, 255, 255, 0] | [255, 255, 255, 0] |      | Configure IP Address of the Controller on the EtherNet GLAN2 (Mask).    |

### C.5.2 Modify through Windows Settings

To enter Windows desktop, you can either go through remote desktop connection<sup>\*1</sup> or through HDMI cable connected to the PLC.

After Windows desktop is accessed, go to **Settings > Network & Internet** to change the IP address<sup>\*2</sup>.



\*1: The default IP address of GLAN1 is 192.168.0.10 while the default IP address of GLAN2 is 192.168.1.10.

\*2: When UWF is on and the AX-8 Series PLC is rebooted, the IP address modified through Windows system will be replaced by the previous settings.


## C.6 Reset IP Address

If the IP address\*<sup>1</sup> is unable to be confirmed due to project lost or other factors, users can restore the system to factory settings and connect to the PLC with the default IP address or replace the project in the PLC with a backup one.


\*1: The default IP addresses are 192.168.0.10 for GLAN 1 and 192.168.1.10 for GLAN 2.

### C.6.1 Connection Denied to PLC

When the PC with DIADesigner-AX software and the AX-8 Series PLC are in the same network domain, users can detect the PLC through **Device > Communication Settings > Scan Network**; download the new project to change the IP address of the PLC.



On the contrary, the AX-8 Series PLC will not be detected by scanning if it is not located in the same domain where the PC exists.




When it is unable to confirm the IP address of the PLC, please refer to **section C.4.4 Project Mode**; the IP address will be the backup project IP address after replacement. Or refer to **section C.4.5 Clear Mode**; the IP address will be reset to the default after restoration.


## C.7 System Operation

Please refer to the following steps for operation of PLC with Windows / Linux operating system.

1. When users are creating or writing the file, the target path should be set in external devices (SD card, USB flash drive). Storing in the PLC does not guarantee file integrity and accuracy.
2. On the Recipe Manger page, users need to enter the complete file path and the exact file extension of external devices (SD card, USB flash drive) in the storage fields. Using a relative path will save the recipe file to the PLC. Storing in the PLC does not guarantee file integrity and accuracy.



3. If the project downloaded from DIADesigner-AX software has been executed before, the PLC will automatically back up the project to avoid unexpected file damage or loss. However, users should avoid power outages to ensure that the download procedure is completed correct.



4. Avoid creating or writing files manually when accessing a Windows system PLC via remote desktop. In addition, users must follow the procedures stated in **section C.1.3** to turn on UWF as the PLC with Windows system is in operation.



---

# Appendix D Firmware Package Updater Operation


## Table of Contents

|            |   |            |
|------------|---|------------|
| <b>D.1</b> | <b>Firmware Package Updater Operation .....</b> | <b>D-2</b> |
| D.1.1      | Firmware Package Updater .....                  | D-3        |
| D.1.2      | Firmware Path .....                             | D-3        |
| D.1.3      | Online Device .....                             | D-4        |
| D.1.4      | Update.....                                     | D-4        |

## D.1 Firmware Package Updater Operation

Open DIADesigner-AX 1.5. Click **Tools** on the toolbar and select **Firmware Update** as shown below.

- **Drop-down menu**



### D.1.1 Firmware Package Updater

The setting window, **Firmware Package Updater**, allows you to set up **Path** (firmware file path) and **Online Device** (device update).

The screenshot shows the 'Firmware Package Updater' window. The 'Path' field is highlighted with a red box. Below it are fields for 'Vendor:', 'Device Type:', 'Device ID:', 'Device Version:', and 'Mini FW Version:'. A collapsed 'Integrity Details' section is visible. The 'Online Device' dropdown menu is also highlighted with a red box. Below it are fields for 'Device Name:', 'Device Address:', 'Device Type:', 'Device ID:', and 'Device Version:'. At the bottom, there is an 'Update Progress' section with a 'Progress' field and an 'Update' button.


### D.1.2 Firmware Path

You can set up the path for storage of firmware files under **Firmware Path**.

The screenshot shows the 'Firmware Package Updater' window with a file browser dialog open. The 'Path' field in the window is set to 'D:\project\PAC\AX8\AX8 LINUX'. The file browser dialog shows a list of files, with 'D:\project\PAC\AX8\AX8 LINUX\FW\AX8\_Linux\_CNC\_1\_0\_4\_0.fwpkg' selected and highlighted with a red box. The 'Update' button is visible at the bottom right of the window.



### D.1.3 Online Device

Select the device for update under **Online Device**.



### D.1.4 Update

Click **Update** to start firmware update.





Smarter. Greener. Together.

## Industrial Automation Headquarters

### Taiwan: Delta Electronics, Inc.

Taoyuan Technology Center  
No.18, Xinglong Rd., Taoyuan District,  
Taoyuan City 330477, Taiwan  
TEL: +886-3-362-6301 / FAX: +886-3-371-6301

## Asia

### China: Delta Electronics (Shanghai) Co., Ltd.

No.182 Minyu Rd., Pudong Shanghai, P.R.C.  
Post code : 201209  
TEL: +86-21-6872-3988 / FAX: +86-21-6872-3996  
Customer Service: 400-820-9595

### Japan: Delta Electronics (Japan), Inc.

Industrial Automation Sales Department  
4-11-25, Shibaura, Minato-ku, Tokyo 108-0023, Japan  
TEL: +81-3-6811-5470 / FAX: +81-3-6811-5802

### Korea: Delta Electronics (Korea), Inc.

1511, 219, Gasan Digital 1-Ro., Geumcheon-gu,  
Seoul, 08501 South Korea  
TEL: +82-2-515-5305 / FAX: +82-2-515-5302

### Singapore: Delta Energy Systems (Singapore) Pte Ltd.

4 Kaki Bukit Avenue 1, #05-04, Singapore 417939  
TEL: +65-6747-5155 / FAX: +65-6744-9228

### India: Delta Electronics (India) Pvt. Ltd.

Plot No.43, Sector 35, HSIIDC Gurgaon,  
PIN 122001, Haryana, India  
TEL: +91-124-4874900 / FAX: +91-124-4874945

### Thailand: Delta Electronics (Thailand) PCL.

909 Soi 9, Moo 4, Bangpoo Industrial Estate (E.P.Z),  
Pattana 1 Rd., T.Phraksa, A.Muang,  
Samutprakarn 10280, Thailand  
TEL: +66-2709-2800 / FAX: +66-2709-2827

### Australia: Delta Electronics (Australia) Pty Ltd.

Unit 2, Building A, 18-24 Ricketts Road,  
Mount Waverley, Victoria 3149 Australia  
Mail: IA.au@deltaww.com  
TEL: +61-1300-335-823 / +61-3-9543-3720

## Americas

### USA: Delta Electronics (Americas) Ltd.

5101 Davis Drive, Research Triangle Park, NC 27709, U.S.A.  
TEL: +1-919-767-3813

### Brazil: Delta Electronics Brazil Ltd.

Estrada Velha Rio-São Paulo, 5300 Eugênio de  
Melo - São José dos Campos CEP: 12247-004 - SP - Brazil  
TEL: +55-12-3932-2300 / FAX: +55-12-3932-237

### Mexico: Delta Electronics International Mexico S.A. de C.V.

Gustavo Baz No. 309 Edificio E PB 103  
Colonia La Loma, CP 54060  
Tlalnepantla, Estado de México  
TEL: +52-55-3603-9200

## EMEA

### EMEA Headquarters: Delta Electronics (Netherlands) B.V.

Sales: Sales.IA.EMEA@deltaww.com  
Marketing: Marketing.IA.EMEA@deltaww.com  
Technical Support: iatechnicalsupport@deltaww.com  
Customer Support: Customer-Support@deltaww.com  
Service: Service.IA.emea@deltaww.com  
TEL: +31(0)40 800 3900

### BENELUX: Delta Electronics (Netherlands) B.V.

Automotive Campus 260, 5708 JZ Helmond, The Netherlands  
Mail: Sales.IA.Benelux@deltaww.com  
TEL: +31(0)40 800 3900

### DACH: Delta Electronics (Netherlands) B.V.

Coesterweg 45, D-59494 Soest, Germany  
Mail: Sales.IA.DACH@deltaww.com  
TEL: +49 2921 987 238

### France: Delta Electronics (France) S.A.

ZI du bois Challand 2, 15 rue des Pyrénées,  
Lisses, 91090 Evry Cedex, France  
Mail: Sales.IA.FR@deltaww.com  
TEL: +33(0)1 69 77 82 60

### Iberia: Delta Electronics Solutions (Spain) S.L.U

Ctra. De Villaverde a Vallecas, 265 1º Dcha Ed.  
Hormigueras – P.I. de Vallecas 28031 Madrid  
TEL: +34(0)91 223 74 20  
Carrer Llacuna 166, 08018 Barcelona, Spain  
Mail: Sales.IA.Iberia@deltaww.com

### Italy: Delta Electronics (Italy) S.r.l.

Via Meda 2-22060 Novedrate(CO)  
Piazza Grazioli 18 00186 Roma Italy  
Mail: Sales.IA.Italy@deltaww.com  
TEL: +39 039 8900365

### Turkey: Delta Greentech Elektronik San. Ltd. Sti. (Turkey)

Şerifali Mah. Hendem Cad. Kule Sok. No:16-A  
34775 Ümraniye – İstanbul  
Mail: Sales.IA.Turkey@deltaww.com  
TEL: + 90 216 499 9910

### MEA: Eltek Dubai (Eltek MEA DMCC)

OFFICE 2504, 25th Floor, Saba Tower 1,  
Jumeirah Lakes Towers, Dubai, UAE  
Mail: Sales.IA.MEA@deltaww.com  
TEL: +971(0)4 2690148