

**SELEC****MFM384-R-C SERIES**

Operating Instructions

**SPECIFICATIONS****DISPLAY**

Liquid crystal display with backlight  
1 line, 4 digits and 2 lines, 7 digits per line  
to show electrical Parameters

**LCD INDICATIONS**

**MD** - Maximum Demand of Power  
 - Communication in progress  
 % - Total Harmonic Distortion Percentage

**LED INDICATIONS**

**INT** - Integration of energy(1000pulses/kWh)

**WIRING INPUT**

3 Ø 4 wire, 1 Ø 2 wire, 3 Ø 3 wire

**RATED INPUT VOLTAGE**

11 to 300V AC (L-N) ; 19 to 519V AC (L-L)

**RATED INPUT CURRENT**

Nominal 5A AC (Min-11mA, Max-6A)

**BURDEN**

0.5 VA @5A per phase

**FREQUENCY RANGE**

45-65 Hz

**CT PRIMARY**

1A / 5A to 10,000A (Programmable for any Value)

**Note** : 1A to 10,000A if CT secondary is 1 else  
CT primary is 5A to 10,000A

**CT SECONDARY**

1A or 5A (Programmable)

**PT PRIMARY**

100V to 500kV (Programmable for any value)

**PT SECONDARY**

100V to 500V (Programmable for any value)

**OVER VOLTAGE CATEGORY**

< 277VAC (L-N) or < 480VAC (L-L) = Category III  
> 277VAC (L-N) or > 480VAC (L-L) = Category II

**DISPLAY UPDATE TIME**

1sec for all parameters

**DISPLAY SCROLLING**

Auto / Manual / Default (programmable)

**DISPLAY SCROLLING TIME**

5 Sec.

**POWER CONSUMPTION**

**MFM384-R-C** : Less than 8VA

**MFM384-R-C-24V** : Less than 4VA

**ENVIRONMENTAL CONDITIONS**

- Indoor use  
- Altitude of up to 2000 meters  
- Pollution degree II

Temperature : Operating : -5°C to 60°C

Storage : -20°C to 75°C

Group : I

Humidity : Up to 85% RH.

**PROTECTION CLASS : II****MOUNTING**

Din Rail mounting

**WEIGHT**

208gms.

**ORDER CODE INFORMATION**

Product	Supply	CE
<b>MFM384-R-C</b>	85 to 270V AC, 50 / 60Hz	■
<b>MFM384-R-C-24V</b>	DC : 18 to 42V AC : 18 to 28V, 50 / 60Hz	■

**SERIAL COMMUNICATION**

<b>Interface standard and protocol</b>	RS485 AND MODBUS RTU
<b>Communication address</b>	1 to 255
<b>Transmission mode</b>	Half duplex
<b>Data types</b>	Float and Integer
<b>Transmission distance</b>	500 Meter maximum
<b>Transmission speed</b>	300, 600,1200, 2400, 4800, 9600,19200 (in bps)
<b>Parity</b>	None, Odd, Even
<b>Stop bits</b>	1 or 2
<b>Response time</b>	500ms (max and independent of baud rate)

**RESOLUTION**

PT Ratio x CT Ratio	kWh	INT
<15	0.01K	0.01K
<150	0.1K	0.1K
<1500	1K	1K
<15000	0.01M	0.01M
<150000	0.1M	0.1M
≥1500000	1M	1M

**NOTE** : 1) For Voltage, Current, Power, resolution is automatically adjusted  
2) For power factor, resolution is 0.01

**NETWORK SELECTION AND WIRING INPUT**

Network selection in configuration mode	Wiring
<b>3P4W</b>	<b>3P4W</b>
<b>3P3W</b>	<b>3P3W</b>
<b>1P2W</b>	<b>1P2W-P1/P2/P3</b>

**NOTE** : P1/P2/P3 will be the phase one, two and three.

**ACCURACY**

Measurement	Accuracy
Voltage $V_{L-N}, V_{L-L}$	0.5   of full range
Current	0.5   of full range
Frequency For MFM384-R-C: >20 $V_{L-N}$ , >35 $V_{L-L}$ For MFM384-R-C-24V: >42 $V_{L-N}$ , >73 $V_{L-L}$	0.1   of full range
Power & MIN/MAX DMD (Active,Reactive,Apparent)	1.0   of full range
Power Factor	±0.01 of full range
Energy(Active,Reactive, Apparent)	1.0   of full range

**SAFETY PRECAUTIONS**

All safety related codifications, symbols and instructions that appear in this operating manual or on the equipment must be strictly followed to ensure the safety of the operating personnel as well as the instrument.

If the equipment is not used in a manner specified by the manufacturer it might impair the protection provided by the equipment.

- Do not use the equipment if there is any mechanical damage.
- Ensure that the equipment is supplied with correct voltage.

**CAUTION :**




- Read complete instructions prior to installation and operation of the unit.
- Risk of electric shock.
- The equipment in its installed state must not come in close proximity to any heating sources, oils, steam, caustic vapors or other unwanted process by products.

**WIRING GUIDELINES****WARNING :**

- To prevent the risk of electric shock, power supply to the equipment must be kept OFF while doing the wiring arrangement.
- Wiring shall be done strictly according to the terminal layout. Confirm that all connections are correct.
- Use lugged terminals.
- To reduce electromagnetic interference use of wires with adequate ratings and twists of the same in equal size shall be made with shortest connections.
- Layout of connecting cables shall be away from any internal EMI source.
- Cable used for connection to power source, must have a cross section of 0.5mm<sup>2</sup> to 2.5mm<sup>2</sup> ( 20 to 14AWG ; 75°C (min) ). These wires shall have current carrying capacity of 6A.
- Copper cable should be used ( Stranded or Single core cable).
- Before attempting work on device, ensure absence of voltages using appropriate voltage detection device.

**INSTALLATION GUIDELINES****CAUTION :**

- This equipment, being built-in-type, normally becomes a part of main control panel and in such case the terminals do not remain accessible to the end user after installation and internal wiring.
- Conductors must not come in contact with the internal circuitry of the equipment or else it may lead to a safety hazard that may in turn endanger life or cause electrical shock to the operator.
- Circuit breaker or mains switch must be installed between power source and supply terminals to facilitate power 'ON' or 'OFF' function. However this switch or breaker must be installed in a convenient position normally accessible to the operator.
- Before disconnecting the secondary of the external current transformer from the equipment, make sure that the current transformer is short circuited to avoid risk of electrical shock and injury.
- The equipment shall not be installed in environmental conditions other than those mentioned in this manual.
- The equipment does not have a built-in-type fuse. Installation of external fuse of rating 275V AC / 0.5Amp for electrical circuitry/ battery is highly recommended.

**DIMENSIONS ( All dimensions in mm )****Front View****Side View****TERMINAL CONNECTIONS****EXAMPLE TO READ DATA FROM INPUT REGISTER****Data format: Big Endian (Default format)**

If Import kWh = 1234.12kWh  
Start Address : 30058, No. Of register : 02  
Hexadecimal Equivalent of 1234.12 is 0x449A43D7

Data stored at 30058 is :  $\frac{A}{43} \frac{B}{9A}$

Data Stored at 30059 is :  $\frac{C}{43} \frac{D}{D7}$

Data Format to be followed is A-B-C-D

**Data format: Mid Little Endian**


If Import kWh = 1234.12kWh  
Start Address : 30058, No. Of register : 02  
Hexadecimal Equivalent of 1234.12 is 0x449A43D7

Data stored at 30058 is :  $\frac{C}{43} \frac{D}{D7}$

Data Stored at 30059 is :  $\frac{A}{44} \frac{B}{9A}$

Data Format to be followed is C-D-A-B

## FRONT PANEL DESCRIPTION



## ONLINE PAGE DESCRIPTION

There are 2 dedicated key labeled as PAGE and PRG with symbols marked as  $\triangleright$  and  $\blacktriangleleft$  to read meter parameters.

For 3P4W and 3P3W		
KEY PRESS	PARAMETER KEY	DESCRIPTION
<b>Press page (<math>\triangleright</math>) key (1st time)</b>	(Page 1)	Displays line to neutral voltage of three phases
	Press $\blacktriangleleft$ key (Page 2)	Displays line to line voltage of three phases (★)
	Press $\blacktriangleleft$ key (Page 3)	Displays L-N total harmonic of voltage of three phases
	Press $\blacktriangleleft$ key (Page 4)	Displays L-L total harmonic of voltage of three phases (★)
<b>Press page (<math>\triangleright</math>) key (2nd time)</b>	(Page 5)	Displays phase current of three phases (★)
	Press $\blacktriangleleft$ key (Page 6)	Displays total harmonic of Current of three phases (★)
<b>Press page (<math>\triangleright</math>) key (3rd time)</b>	(Page 7)	Displays average line to neutral voltage, current and power factor of three phases and frequency.
	Press $\blacktriangleleft$ key (Page 8)	Displays average line to line voltage, current and power factor of three phases and frequency. (★)
<b>Press page (<math>\triangleright</math>) key (4th time)</b>	(Page 9)	Displays power factor of three phases and frequency.
	Press $\blacktriangleleft$ key 1st time (Page 10)	Displays active power of three phases.
	Press $\blacktriangleleft$ key 2nd time (Page 11)	Displays reactive power of three phases.
	Press $\blacktriangleleft$ key 3rd time (Page 12)	Displays apparent power of three phases.
	Press $\blacktriangleleft$ key 4th time (Page 13)	Displays total active power of three phases.(★)

KEY PRESS	PARAMETER KEY	DESCRIPTION
	Press $\blacktriangleleft$ key 5th time (Page 14)	Displays total reactive power of three phases. (★)
	Press $\blacktriangleleft$ key 6th time (Page 15)	Displays total apparent power of three phases.(★)
	Press $\blacktriangleleft$ key 7th time (Page 16)	Display MAX(2nd row) and MIN(3rd row) demand of total active power (★)
	Press $\blacktriangleleft$ key 8th time (Page 17)	Display MAX(2nd row) and MIN (3rd row) demand of total reactive power (★)
	Press $\blacktriangleleft$ key 9th time (Page 18)	Display MAX demand of total apparent power (★)
	<b>Press page (<math>\triangleright</math>) key (5th time)</b>	(Page 19)
Press $\blacktriangleleft$ key 1st time (Page 20)		Displays average voltage line to neutral (1st row) and Import (2nd row) and export (3rd row) reactive energy of three phases.(★)
Press $\blacktriangleleft$ key 2nd time (Page 21)		Displays average voltage line to neutral (1st row) and apparent energy (3rd row) of three phases. (★)
For this key function in 1st row for 3P3W voltage will be average line to line.		

**Note :** For 3 phase 3 wire network only (★) marked page will be display.

For 1P2W - P1 / P2 / P3		
KEY PRESS	PARAMETER KEY	DESCRIPTION
<b>Press page (<math>\triangleright</math>) key (1st time)</b>	(Page 1)	Displays line to neutral voltage of selected phase.
	Press key 1st time (Page 3)	Displays L-N total harmonic of voltage of selected phase
<b>Press page (<math>\triangleright</math>) key (2nd time)</b>	(Page 5)	Displays phase current of selected phase.
	Press key 1st time (Page 6)	Displays L-N total harmonic of current of selected phase
<b>Press page (<math>\triangleright</math>) key (3rd time)</b>	(Page 9)	Displays power factor of selected phase and frequency.
	Press $\blacktriangleleft$ key 1st time (Page 10)	Displays active power of selected phase.
	Press $\blacktriangleleft$ key 2nd time (Page 11)	Displays reactive power of selected phase.

KEY PRESS	PARAMETER KEY	DESCRIPTION	
	Press $\blacktriangleleft$ key 3rd time (Page 12)	Displays apparent power of selected phase.	
	Press $\blacktriangleleft$ key 7th time (Page 16)	Display MAX(2nd row) and MIN(3rd row) demand of total active power.	
	Press $\blacktriangleleft$ key 8th time (Page 17)	Display MAX(2nd row) and MIN (3rd row) demand of total reactive power.	
	Press $\blacktriangleleft$ key 9th time (Page 18)	Display MAX demand of total apparent power.	
	<b>Press page (<math>\triangleright</math>) key (4th time)</b>	(Page 19)	Displays line to neutral voltage(1st row) and Import (2nd row) and export (3rd row) active energy of selected phase.
		Press $\blacktriangleleft$ key 1st time (Page 20)	Displays line to neutral voltage(1st row) and Import (2nd row) and export (3rd row) reactive energy of selected phase.
		Press $\blacktriangleleft$ key 2nd time (Page 21)	Displays line to neutral voltage(1st row) and apparent energy (3rd row) of selected phase.

**Note :** For 1 phase 2 wire network, only selected phase Parameter will display.

## CONFIGURATION

There are 3 dedicated key with symbols marked as  $\triangleright$ ,  $\blacktriangleleft$  and  $\blacktriangleleft$ . Use these 3 key to enter into configuration / change setting.

**Note :** The settings should be done by a professional, after going through this users manual and after having understood the application situation.

For the configuration setting mode :

- Use  $\blacktriangleleft$  and  $\blacktriangleleft$  for 3 sec. to enter or exit from config. mode.
- Use  $\triangleright$  shift key to move cursor left or right by one digit each time. After last digit of display cursor shift at 1st digit of display.
- Use  $\blacktriangleleft$  increment key for increasing the parameter value.
- Use  $\blacktriangleleft$  key to save the setting and move on to next page.
- Use  $\blacktriangleleft$  and  $\triangleright$  keys to go back to previous page.

Config. page.	Function	Range or Selection	Factory Setting
	Password	0000 to 9998	1000
1	Change Password	No / Yes	No
1.1	New Password	0000 to 9998	1000
2	Network Selection	3P4W, 3P3W, 1P2W-P1, 1P2W-P2, 1P2W-P3.	3P4W
3	CT Secondary	1 or 5	5
4	CT Primary	5A to 10,000A	5
5	PT Secondary	100V to 500V	350
6	PT primary	100V to 500kV	350

Config. page.	Function	Range or Selection	Factory Setting
7	Slave Id	1 to 255	1
8	Baud Rate	300, 600, 1200, 2400, 4800, 9600 and 19200	9600
9	Parity	None, Even, Odd	None
10	Stop Bit	1 or 2	1
11	Endianess	LSRF / MSRF	MSRF
12	Back Light	0 to 7200 sec.	0000
13	Demand interval method	Sliding / Fixed	Sliding
14	Demand interval duration	1 to 30	15
15	Demand interval length	1 to 30min	1
16	Max auto Pages	1 to 21	21
17	Change Page Sequence	No / Yes	No
17.1	Page Sequence 1	01 to 21	1
17.2	Page Sequence 2	01 to 21	2
17.3	Page Sequence 3	01 to 21	3
17.4	Page Sequence 4	01 to 21	4
17.5	Page Sequence 5	01 to 21	5
17.6	Page Sequence 6	01 to 21	6
17.7	Page Sequence 7	01 to 21	7
17.8	Page Sequence 8	01 to 21	8
17.9	Page Sequence 9	01 to 21	9
17.10	Page Sequence 10	01 to 21	10
17.11	Page Sequence 11	01 to 21	11
17.12	Page Sequence 12	01 to 21	12
17.13	Page Sequence 13	01 to 21	13
17.14	Page Sequence 14	01 to 21	14
17.15	Page Sequence 15	01 to 21	15
17.16	Page Sequence 16	01 to 21	16
17.17	Page Sequence 17	01 to 21	17
17.18	Page Sequence 18	01 to 21	18
17.19	Page Sequence 19	01 to 21	19
17.20	Page Sequence 20	01 to 21	20
17.21	Page Sequence 21	01 to 21	21
18	Factory Default	No / Yes	No
19	Reset Energy and MAX Demand	No / Yes	No
19.1	Password	0001 to 9999	1001
19.1	Reset Active Energy	No / Yes	No
19.2	Reset Reactive Energy	No / Yes	No
19.3	Reset Apparent Energy	No / Yes	No
19.4	Reset MAX Power	No / Yes	No

- For resetting energy parameters user will be prompted the password. If correct password is entered, the user will be able to reset all energy parameters. This password will be value which will be greater than the configuration password by 1.

### MODBUS REGISTER ADDRESSES LIST

Readable parameters : [ Length (Register) : 2 ; Data Structure : Float ]

Note : In four byte data type , LSB will be displayed on lower address and MSB will be displayed on higher address.

Address	Hex Address	Parameter	Address	Hex Address	Parameter	Address	Hex Address	Parameter
30000	0x00	Voltage 1st Phase	30062	0x3E	Import kVArh	30138	0x8A	Existing MAX reactive power
30002	0x02	Voltage 2nd Phase	30064	0x40	kW MAX Active Power	30140	0x8C	Existing MIN reactive power
30004	0x04	Voltage 3rd Phase	30066	0x42	kW MIN Active Power	30142	0x8E	Existing MAX apparent power
30006	0x06	Average Voltage LN	30068	0x44	kVar MAX Reactive Power	30144	0x90	THD of 1st Phase Voltage
30008	0x08	Voltage V12	30070	0x46	kVar MIN Reactive Power	30146	0x92	THD of 2nd Phase Voltage
30010	0x0A	Voltage V23	30072	0x48	kVa MAX Apparent Power	30148	0x94	THD of 3rd Phase Voltage
30012	0x0C	Voltage V31	30074	0x4A	Export kWh	30150	0x96	THD of Voltage V12
30014	0x0E	Average Voltage LL	30076	0x4C	Export kVArh	30152	0x98	THD of Voltage V23
30016	0x10	Current I1	30078	0x4E	MAX Voltage 1st Phase	30154	0x9A	THD of Voltage V31
30018	0x12	Current I2	30080	0x50	MAX Voltage 2nd Phase	30156	0x9C	THD of Current I1
30020	0x14	Current I3	30082	0x52	MAX Voltage 3rd Phase	30158	0x9E	THD of Current I2
30022	0x16	Average Current	30084	0x54	MIN Voltage 1st Phase	30160	0xA0	THD of Current I3
30024	0x18	kW1	30086	0x56	MIN Voltage 2nd Phase	<b>Formula to find address of individual Harmonic</b> {163 + [(Harmonic no-2) x 2] + 60 x Constant Parameter}. For Example, To find the 14 <sup>th</sup> Harmonic address of Voltage V31 following formula can be used : Formula with the parameter : {163 + [(14-2) x 2] + 60 x 5} = 487 So, Check the 14 <sup>th</sup> Harmonic of Voltage V31 at 487address.		
30026	0x1A	kW2	30088	0x58	MIN Voltage 3rd Phase			
30028	0x1C	kW3	30090	0x5A	MAX Voltage V12			
30030	0x1E	kVA1	30092	0x5C	MAX Voltage V23			
30032	0x20	kVA2	30094	0x5E	MAX Voltage V31			
30034	0x22	kVA3	30096	0x60	MIN Voltage V12			
30036	0x24	kVAr1	30098	0x62	MIN Voltage V23			
30038	0x26	kVAr2	30100	0x64	MIN Voltage V31			
30040	0x28	kVAr3	30102	0x66	MAX Current I1			
30042	0x2A	Total kW	30104	0x68	MAX Current I2			
30044	0x2C	Total kVA	30106	0x6A	MAX Current I3			
30046	0x2E	Total kVAr	30108	0x6C	MIN Current I1			
30048	0x30	PF1	30110	0x6E	MIN Current I2	<b>SERIAL NUMBER DESCRIPTION</b> Press <b>A</b> key for 10sec. to display 8 digit serial number only for 10sec. at 2nd and 3rd line of display		
30050	0x32	PF2	30112	0x70	MIN Current I3			
30052	0x34	PF3	30114	0x72	MAX Frequency			
30054	0x36	Average PF	30116	0x74	MIN Frequency			
30056	0x38	Frequency	30132	0x84	Serial no (Data Structure : Hex)	<b>AUTO / MANUAL / DEFAULT PAGE MODE DESCRIPTION :</b> Press MODE key for 3sec. to change the on-line page mode. The sequence will be Auto / Manual / Default		
30058	0x3A	Import kWh	30134	0x86	Existing MAX active power			
30060	0x3C	Import kVAh	30136	0x88	Existing MIN active power			

### MODBUS REGISTER ADDRESSES LIST

Readable / writable parameters from MFM384-R-C :

Address	Hex Address	Parameter	Range		Length (Register)	Data Structure
40000	0x00	Password	Min value : 0	Max value : 9998	1	Integer
40001	0x01	N/W selection	Value : 0x0000	Meaning : 3P-4W	1	Integer
			Value : 0x0001	Meaning : 3P-3W	1	Integer
			Value : 0x0002	Meaning : 1P2W-P1	1	Integer
			Value : 0x0003	Meaning : 1P2W-P2	1	Integer
			Value : 0x0004	Meaning : 1P2W-P3	1	Integer
40002	0x02	CT Secondary (A)	Min value : 1	Max value : 5	1	Integer

### MODBUS REGISTER ADDRESSES LIST

Readable / writable parameters from MFM384-R-C :


Address	Hex Address	Parameter	Range	Length (Register)	Data Structure
40003	0x03	CT primary (CT Secondary = 1)(A)	Min value : 1 Max value : 10000	1	Integer
		CT primary (CT Secondary = 5)(A)	Min value : 5 Max value : 10000	1	Integer
40004	0x04	PT Secondary (V)	Min value :100 Max value : 500	1	Integer
40005	0x05	PT primary (V)	Min value :100 Max value : 500kV	2	Integer
40007	0x07	Slave id	Min value : 1 Max value : 255	1	Integer
40008	0x08	Baud rate (bps)	Value : 0x0000 Meaning : 300	1	Integer
			Value : 0x0001 Meaning : 600		
			Value : 0x0002 Meaning : 1200		
			Value : 0x0003 Meaning : 2400		
			Value : 0x0004 Meaning : 4800		
			Value : 0x0005 Meaning : 9600		
			Value : 0x0006 Meaning : 19200		
40009	0x09	Parity	Value : 0x0000 Meaning : None	1	Integer
			Value : 0x0001 Meaning : Odd		
			Value : 0x0002 Meaning : Even		
40010	0x0A	Stop bit	0x0000 1	1	Integer
			0x0001 2		
40011	0x0B	Backlight OFF (sec.)	Min Value : 0 Max Value : 7200	1	Integer
40012	0x0C	Factory Default	1 Set to factory setting range	1	Integer
40013	0x0D	Reset kWh	1 Reset total active energy	1	Integer
40014	0x0E	Reset kVAh	1 Reset total apparent energy	1	Integer
40015	0x0F	Reset kVArh	1 Reset total reactive energy	1	Integer
40016	0x10	Auto mode sequence	Min value : 1 Max value :21	1	Integer
40017	0x11	Page address sequence 1	Page No.:1-21 Meaning:1-First page;21-Last page	1	Integer
40018	0x12	Page address sequence 2	Page No.:1-21 Meaning:1-First page;21-Last page	1	Integer
40019	0x13	Page address sequence 3	Page No.:1-21 Meaning:1-First page;21-Last page	1	Integer
40020	0x14	Page address sequence 4	Page No.:1-21 Meaning:1-First page;21-Last page	1	Integer
40021	0x15	Page address sequence 5	Page No.:1-21 Meaning:1-First page;21-Last page	1	Integer
40022	0x16	Page address sequence 6	Page No.:1-21 Meaning:1-First page;21-Last page	1	Integer
40023	0x17	Page address sequence 7	Page No.:1-21 Meaning:1-First page;21-Last page	1	Integer
40024	0x18	Page address sequence 8	Page No.:1-21 Meaning:1-First page;21-Last page	1	Integer
40025	0x19	Page address sequence 9	Page No.:1-21 Meaning:1-First page;21-Last page	1	Integer
40026	0x1A	Page address sequence 10	Page No.:1-21 Meaning:1-First page;21-Last page	1	Integer
40027	0x1B	Page address sequence 11	Page No.:1-21 Meaning:1-First page;21-Last page	1	Integer
40028	0x1C	Page address sequence 12	Page No.:1-21 Meaning:1-First page;21-Last page	1	Integer
40029	0x1D	Page address sequence 13	Page No.:1-21 Meaning:1-First page;21-Last page	1	Integer
40030	0x1E	Page address sequence 14	Page No.:1-21 Meaning:1-First page;21-Last page	1	Integer
40031	0x1F	Page address sequence 15	Page No.:1-21 Meaning:1-First page;21-Last page	1	Integer
40032	0x20	Page address sequence 16	Page No.:1-21 Meaning:1-First page;21-Last page	1	Integer
40033	0x21	Page address sequence 17	Page No.:1-21 Meaning:1-First page;21-Last page	1	Integer
40054	0x36	Page address sequence 18	Page No.:1-21 Meaning:1-First page;21-Last page	1	Integer
40055	0x37	Page address sequence 19	Page No.:1-21 Meaning:1-First page;21-Last page	1	Integer
40056	0x38	Page address sequence 20	Page No.:1-21 Meaning:1-First page;21-Last page	1	Integer

40057	0x39	Page address sequence 21	Page No.:1-21	Meaning:1-First page;21-Last page	1	Integer
40034	0x22	Demand Interval Method	Value :0X0000	Meaning : Sliding	1	Integer
			Value :0X0001	Meaning : Fixed		
40035	0x23	Demand Interval Duration	Min Value : 1	Max Value : 30	1	Integer
40036	0x24	Demand Interval Length(min)	Min Value : 1	Max Value : 30	1	Integer
40037	0x25	Reset MAX kW	1	Reset MAX Active Power	1	Integer


### TYPICAL WIRING DIAGRAM

\* NOTE : For auxiliary wiring of MFM384-R-C-24V, L is + and N is -


3 Phase - 4 Wire (Commonly Used) 3 Ø - 4 Wire, 3 CT'S




3 Phase - 3 Wire 3 Ø - 3 Wire, 2 CT'S




3 Phase - 3 Wire 3 Ø - 3 Wire, 2 CT'S and 2 PT'S




3 Phase - 4 Wire 3 Ø - 4 Wire, 3 CT'S and 3 PT'S



1 Phase - 2 Wire 1 Ø - 2 Wire, 1 CT



### CONNECTION DIAGRAM FOR COMMUNICATION



Contact sales for PC based monitoring software to communicate with the meters.

# All fuse types : 0.5A class CC UL type  
0.5A fast acting 600V

(Specifications are subject to change, since development is a continuous process.)

### Selec Controls Pvt. Ltd.

Factory Address : EL-27/1, Electronic Zone, TTC Industrial Area, MIDC, Mahape, Navi Mumbai - 400 710, India.

Website : www.selec.com

For Sales & Support,

Tel. No. : +91-22-41418468 / 452

Mob. No. : +91-9136977315, Email : sales@selec.com

For Service,

Tel. No. : +91-7498077172 / +91-7400069545

Email : service@selec.com