



Programmable Controller
MELSEC iQ-F

Side A JAPANESE
Side B ENGLISH

MELSEC iQ-F FX5-4LC

Hardware Manual



Manual Number	JY997D73701
Revision	F
Date	October 2023

This manual describes the part names, dimensions, installation, and specifications of the product. Before use, read this manual and manuals of relevant products fully to acquire proficiency in handling and operating the product. Make sure to learn all the product information, safety information, and precautions.

And, store this manual in a safe place so that you can take it out and read it whenever necessary. Always forward it to the end user.
Registration:
The company names, system names and product names mentioned in this manual are either registered trademarks or trademarks of their respective companies. In some cases, trademark symbols such as "™" or "®" are not specified in this manual.

Effective October 2023

Specifications are subject to change without notice.

© 2017 MITSUBISHI ELECTRIC CORPORATION

Safety Precautions (Read these precautions before use.)

This manual classifies the safety precautions into two categories:

	Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.
	Indicates that incorrect handling may cause hazardous conditions, resulting in minor or moderate injury or property damage.

Depending on the circumstances, procedures indicated by may also cause severe injury. It is important to follow all precautions for personal safety.

Associated Manual

Manual name	Manual No.	Description
MELSEC iQ-F FX5 Temperature Control Module User's Manual	SH-081799ENG	Explains temperature control module.
MELSEC iQ-F FX5S/FX5UJ/FX5UC User's Manual (Hardware)	SH-082452ENG	Describes the details of hardware of the CPU module, including performance specifications, wiring, installation, and maintenance.

How to obtain manuals

For the necessary product manuals or documents, consult with your local Mitsubishi Electric representative.

Applicable standards

FX5-4LC complies with the EU Directive (EMC Directive), UL standards (UL, cUL) and UKCA marking. Further information can be found in the following manual.
→ MELSEC iQ-F FX5 Temperature Control Module User's Manual

Regarding the standards that relate to the CPU module, please refer to either the product catalog or consult with your local Mitsubishi Electric representative.

Attention

This product is designed for use in industrial applications.

1. Outline


FX5-4LC temperature control module (hereinafter called FX5-4LC) equipped with 4 channel input (thermocouples, resistance thermometer and micro voltage input), 4 points output (open collector transistor) and 4 points current sensor input can perform temperature control.

1.1 Incorporated Items


Check that the following product and items are included in the package:

Product	FX5-4LC temperature control module
Included Items	FX2NC-100MPCB power cable: (1 m, three wire) Dust proof protection sheet (1 sheet) Hardware manual [Japanese/English] (This manual) Hardware manual [Chinese]

1.2 External Dimensions, Part Names



Unit: mm
MASS (Weight): Approx. 0.3 kg
Outer painting color: Munsell 0.6B7.6/0.2




- | | |
|--|--|
| [1] Terminal block (Spring clamp terminal block) | [6] Name plate |
| [2] Extension cable | [7] DIN rail mounting groove (DIN rail: DIN 46277, 35 mm wide) |
| [3] Direct mounting hole: 2 holes of $\phi 4.5$ (mounting screw: M4 screw) | [8] DIN rail mounting hook |
| [4] Operation status display LEDs | [9] Pullout tab |
| [5] Extension connector (for next module) | [10] Power connector |

1.3 Indications of LEDs

LED display	LED color	Status	Indication
POWER	Green	On	Power on
		Off	Power off or module failure
RUN	Green	On	Normal operation
		Off	Error
ERROR	Red	On	Minor error or major error
		Flashing	Moderate error or major error
OUT1 to OUT4	Green	On	Normal operation
		Off	OUT1 to OUT4 output on
		On	OUT1 to OUT4 output on
		Off	OUT1 to OUT4 output off

1.4 Terminal Layout



For further information on terminal, refer to the following manual.
→ MELSEC iQ-F FX5 Temperature Control Module User's Manual

2. Installation

INSTALLATION PRECAUTIONS		WARNING
<ul style="list-style-type: none"> Make sure to cut off all phases of the power supply externally before attempting installation or wiring work. Failure to do so may cause electric shock or damage to the product. This product is an open type device that must be installed and used within a control cabinet which satisfies all of the following three requirements. <ul style="list-style-type: none"> a cabinet which has conductivity. a cabinet which has a structure to prevent the fire to spread outside the cabinet. a cabinet which has sufficient mechanical strength. Use the product within the generic environment specifications described in the User's Manual (Hardware) for the CPU module to be used. Never use the product in areas with excessive dust, oily smoke, conductive dusts, corrosive gas (salt air, Cl₂, H₂S, SO₂ or NO₂), flammable gas, vibration or impacts, or expose it to high temperature, condensation, or rain and wind. If the product is used in such conditions, electric shock, fire, malfunctions, deterioration or damage may occur. 		

INSTALLATION PRECAUTIONS		CAUTION
<ul style="list-style-type: none"> Do not touch the conductive parts of the product directly. Doing so may cause device failures or malfunctions. When drilling screw holes or wiring, make sure that cutting and wiring debris do not enter the ventilation slits of the PLC. Failure to do so may cause fire, equipment failures or malfunctions. The dust proof sheet should be affixed to the ventilation slits before installation and wiring work to block foreign objects such as cutting and wiring debris. However, when the installation work is completed, make sure to remove the sheet to provide adequate ventilation. Failure to do so may cause fire, equipment failures or malfunctions. Install the product on a flat surface. If the mounting surface is rough, undue force will be applied to the PC board, thereby causing nonconformities. Install the product securely using a DIN rail or mounting screws. Connect the extension cables securely to their designated connectors. Loose connections may cause malfunctions. 		

For further information on mounting, refer to the following manual.
→ MELSEC iQ-F FX5S/FX5UJ/FX5UC User's Manual (Hardware)

3. Wiring

WIRING PRECAUTIONS		WARNING
<ul style="list-style-type: none"> Make sure to cut off all phases of the power supply externally before attempting installation or wiring work. Failure to do so may cause electric shock or damage to the product. Don't use the input terminals for measurement on a main circuit, since those terminals have no measurement category. Make sure to properly wire to the spring clamp terminal block in accordance with the following precautions. Failure to do so may cause electric shock, equipment failures, a short-circuit, wire breakage, malfunctions, or damage to the product. <ul style="list-style-type: none"> The disposal size of the cable end should follow the dimensions described in the manual. Twist the ends of stranded wires and make sure that there are no loose wires. Do not solder-plate the electric wire ends. Do not connect more than the specified number of wires or electric wires of unspecified size. Affix the electric wires so that neither the terminal block nor the connected parts are directly stressed. 		

WIRING PRECAUTIONS		CAUTION
<ul style="list-style-type: none"> Make sure to observe the following precautions in order to prevent any damage to the machinery or accidents due to malfunction of the PLC caused by abnormal data written to the PLC due to the effects of noise. <ul style="list-style-type: none"> Do not bundle the power line and control line together with or lay them close to the main circuit, high-voltage line, load line or power line. As a guideline, lay the power line, control line and communication cables at least 100 mm away from the main circuit, high-voltage line, load line or power line. Ground the shield of the analog input/output cable in accordance with the manuals of each model. However, do not use common grounding with heavy electrical systems. Check the interface type and correctly connect the cable. Incorrect wiring (connecting the cable to an incorrect interface) may cause failure of the module and external device. To terminal blocks or power connectors, connect circuits isolated from hazardous voltage by double/reinforced insulation. 		


3.1 Applicable Cable

3.1.1 Spring clamp terminal block

1) Suitable wiring

No. of wire per terminal	Wire size		Temperature rating
	Single wire, Strand wire (Material: Copper wire)	Ferrule with insulation sleeve	
One wire	AWG24 to 16 (0.2 to 1.5 mm ²)	AWG23 to 19 (0.25 to 0.75 mm ²)	80°C or more

- 2) Wire end treatment
Strip the cable about 10 mm from the tip to connect a wire ferrule at the striped area. Failure to do so may result in electric shock or short circuit between adjacent terminals because the conductive part. If the wire strip length is too short, it may result in the poor contact to the spring clamp terminal part. When using a wire ferrule with an insulation sleeve, choose a wire with proper cable sheath referring to the above outside dimensions, otherwise the wire cannot be inserted easily.



The following table shows wire ferrules and tools for wire ferrules compatible with the terminal block. Use of items other than these may result in not being able to remove the wire ferrule, so carefully check that the wire ferrule can be unplugged.
<Reference product>


Manufacturer	Model	Wire size	Crimp tool
PHOENIX CONTACT GmbH & Co. KG	AI 0.5-10 WH	0.5 mm ²	CRIMPFOX 6
	AI 0.75-10 GY	0.75 mm ²	
	A 1.0-10	1.0 mm ²	
	A 1.5-10	1.5 mm ²	

- 3) Connecting a cable
When ferrules with insulation sleeve are used
Insert a wire with the ferrule with insulation sleeve into the wire insertion opening and push the wire.
When stranded wires and solid wires are used
Push the open/close button of the terminal block with a flathead screwdriver. While pushing the open/close button, insert the wire into the insertion opening until the wire reaches the back, and then release the open/close button.
Then, pull the wire lightly and check that it is clamped securely.
<Reference>

Manufacturer	Model
PHOENIX CONTACT GmbH & Co. KG	SZS 0.4×2.5 VDE

- 4) Disconnecting a cable
Push the open/close button of the wire to be disconnected with a flathead screwdriver. Pull out the wire with the open/close button pushed.


3.2 Example of Input/output Wiring



- ch□ : represents the channel number.
*1 When using a thermocouple, use specified compensating lead wires.
*2 When you use a resistance thermometer, the resistance of the lead wire is low, use a wire without a resistance difference between the lead wire.
*3 Make sure to short-circuit the [B] and [b] terminals when a 2-wire resistance thermometer is input.

3.3 Power Connector

For further information on the power supply wiring and power cable, refer to the following manual.
→ MELSEC iQ-F FX5 Temperature Control Module User's Manual



3.4 Grounding

- Ground the PLC as stated below.
• Perform class D grounding. (Grounding resistance: 100 Ω or less)
• Ground the PLC independently if possible.
If the PLC cannot be grounded independently, perform the "Shared grounding" shown below.
For details, refer to the following manual.
→ MELSEC iQ-F FX5S/FX5UJ/FX5UC User's Manual (Hardware)
-
- Bring the grounding point close to the PLC as much as possible so that the ground cable can be shortened.

4. Specification

DESIGN PRECAUTIONS		WARNING
<ul style="list-style-type: none"> Make sure to set up the following safety circuits outside the PLC to ensure safe system operation even during external power supply problems or PLC failure. Otherwise, malfunctions may cause serious accidents. <ul style="list-style-type: none"> Most importantly, set up the following: an emergency stop circuit, a protection circuit, an interlock circuit for opposite movements (such as normal vs. reverse rotation), and an interlock circuit (to prevent damage to the equipment at the upper and lower positioning limits). Note that when the CPU module detects an error, such as a watchdog timer error, during self-diagnosis, all outputs are turned off. Also, when an error that cannot be detected by the CPU module occurs in an input/output control block, output control may be disabled. External circuits and mechanisms should be designed to ensure safe machinery operation in such a case. Note that when an error occurs in a relay, transistor or triac of an output circuit, the output might stay on or off. For output signals that may lead to serious accidents, external circuits and mechanisms should be designed to ensure safe machinery operation in such a case. 		

DESIGN PRECAUTIONS		CAUTION
<ul style="list-style-type: none"> Simultaneously turn on and off the power supplies of the CPU module and extension modules. 		

STARTUP AND MAINTENANCE PRECAUTIONS		CAUTION
<ul style="list-style-type: none"> Do not disassemble or modify the PLC. Doing so may cause fire, equipment failures, or malfunctions. For repair, contact your local Mitsubishi Electric representative. Do not drop the product or exert strong impact to it. Doing so may cause damage. 		

DISPOSAL PRECAUTIONS		CAUTION
<ul style="list-style-type: none"> Please contact a certified electronic waste disposal company for the environmentally safe recycling and disposal of your device. 		

TRANSPORTATION PRECAUTIONS		CAUTION
<ul style="list-style-type: none"> The product is a precision instrument. During transportation, avoid impacts larger than those specified in the general specifications by using dedicated packaging boxes and shock-absorbing pallets. Failure to do so may cause failures in the product. After transportation, verify operation of the product and check for damage of the mounting part, etc. 		

Model name	Applicability
FX5UC CPU module	From first production
FX5UC CPU module	Ver. 1.050 or later
FX5UC CPU module ¹	Ver. 1.050 or later

*1 FX5-CNV-IFC or FX5-C1P5-5V is necessary to connect FX5-4LC to the FX5UC CPU module.

Items	Specifications
Dielectric withstand voltage	500 V AC for 1 minute
Insulation resistance	10 MΩ or higher by 500 V DC insulation resistance tester

Items	Specifications
Power supply voltage	24 V DC +20%, -15%
Allowable instantaneous power failure time	Operation continues when the instantaneous power failure is shorter than 5 ms.
Current consumption	25 mA
Power supply voltage	5 V DC
Current consumption	140 mA

Items	Specifications
Number of input points	4 points
Input type ¹	Thermocouple: K, J, R, S, E, T, B, N JIS C 1602-1995, PLII, W5Re/W26Re, U, L Resistance thermometer: 3-wire type Pt100 JIS C 1604-1997, 3-wire type JPt100 JIS C 1604-1981, 2-wire type/3-wire type Pt1000 JIS C 1604-2013 Micro voltage input
Measurement precision ²	Refer to MELSEC iQ-F FX5 Temperature Control Module User's Manual
Cold contact temperature compensation error	When ambient temperature is 0 to 55°C: Within ±1.0°C. However, within ±2.0°C while input value is -150 to -100°C / within ±3.0°C while input value is -200 to -150°C. When ambient temperature is -20 to 0°C: Within ±1.8°C. However, within ±3.6°C while input value is -150 to -100°C / within ±5.4°C while input value is -200 to -150°C.
Resolution	0.1°C (0.1°F), 1.0°C (1.0°F), 0.5 μV or 5.0 μV. Varies depending on input range of used sensors.
Sampling period	250 ms/4ch
Effect of external resistance (When thermocouple is used)	Approx. 0.125 μV/Ω
Effect of input lead wire resistance (When resistance thermometer is used)	3-wire type: Approx. 0.03%/Ω of full scale. 10 Ω or less per 1-wire 2-wire type: Approx. 0.04%/Ω of full scale. 7.5 Ω or less per 1-wire
Input impedance	1 MΩ or more
Sensor current	Approx. 0.20 mA (When resistance thermometer is used)
Operation when input is disconnected/ Operation when input is short-circuited	Upscale/Downscale (When resistance thermometer is used)

*1 A different input can be selected for each channel.
*2 To stabilize the measurement precision, warm-up (supply power) the system for 30 minutes or more after power-on.

4.2 General Specifications

Items	Specifications
Power supply voltage	24 V DC +20%, -15%
Allowable instantaneous power failure time	Operation continues when the instantaneous power failure is shorter than 5 ms.
Current consumption	25 mA
Power supply voltage	5 V DC
Current consumption	140 mA

Items	Specifications
Number of input points	4 points
Input type ¹	When using this product in the United States or Canada, use current sensors with UL/cUL Listed and/or CSA certified such as XOBA and XOBA7. When using current sensors in countries other than the above, we recommend the following. CTL-12-S36-8, CTL-12-S36-10, CTL-12-S56-10, CTL-12L-8, CTL-6-P, CTL-6-P-H, CTL-6-S-H (manufactured by U.R.D. Co., Ltd.)
Current sensor	
Allowable input current	0 to 182.2 mA/rms

1) Damages caused by any cause found not to be the responsibility of Mitsubishi products.
2) Special damages and profits damages whether foreseeable or not, compensation for accidents, and compensation for damages to products other than Mitsubishi products.
3) Replacement by the user, maintenance of on-site equipment, start-up test run and other tasks.

4.4 Performance Specifications

Items	Specifications
Control method	Two-position control, PID control, Heating/cooling PID control, Cascade control
Control operation period	250 ms/4ch
Measured temperature range	Refer to section 4.7
Heater disconnection detection	Alarm is detected (Variable within range from 0.0 to 100.0 A by GX Works3.)
Operation mode	0: Not used, 1: Monitor, 2: Monitor+Alarm, 3: Monitor+Alarm+Control (Selected by GX Works3)
Insulation method	<ul style="list-style-type: none"> The photocoupler is used to insulate the analog input area and transistor output area from the PLC. The DC/DC converter is used to insulate the power supply from the analog input area and transistor output area. Channels are insulated from each other.
Number of occupied I/O points	8 points

4.5 Input Specifications

Items	Specifications
Number of input points	4 points
Input type ¹	Thermocouple: K, J, R, S, E, T, B, N JIS C 1602-1995, PLII, W5Re/W26Re, U, L Resistance thermometer: 3-wire type Pt100 JIS C 1604-1997, 3-wire type JPt100 JIS C 1604-1981, 2-wire type/3-wire type Pt1000 JIS C 1604-2013 Micro voltage input
Measurement precision ²	Refer to MELSEC iQ-F FX5 Temperature Control Module User's Manual
Cold contact temperature compensation error	When ambient temperature is 0 to 55°C: Within ±1.0°C. However, within ±2.0°C while input value is -150 to -100°C / within ±3.0°C while input value is -200 to -150°C. When ambient temperature is -20 to 0°C: Within ±1.8°C. However, within ±3.6°C while input value is -150 to -100°C / within ±5.4°C while input value is -200 to -150°C.
Resolution	0.1°C (0.1°F), 1.0°C (1.0°F), 0.5 μV or 5.0 μV. Varies depending on input range of used sensors.
Sampling period	250 ms/4ch
Effect of external resistance (When thermocouple is used)	Approx. 0.125 μV/Ω
Effect of input lead wire resistance (When resistance thermometer is used)	3-wire type: Approx. 0.03%/Ω of full scale. 10 Ω or less per 1-wire 2-wire type: Approx. 0.04%/Ω of full scale. 7.5 Ω or less per 1-wire
Input impedance	1 MΩ or more
Sensor current	Approx. 0.20 mA (When resistance thermometer is used)
Operation when input is disconnected/ Operation when input is short-circuited	Upscale/Downscale (When resistance thermometer is used)

*1 A different input can be selected for each channel.
*2 To stabilize the measurement precision, warm-up (supply power) the system for 30 minutes or more after power-on.

4.6 Current Sensor (CT) Input Specifications

Items	Specifications
Number of input points	4 points
Input type ¹	When using this product in the United States or Canada, use current sensors with UL/cUL Listed and/or CSA certified such as XOBA and XOBA7. When using current sensors in countries other than the above, we recommend the following. CTL-12-S36-8, CTL-12-S36-10, CTL-12-S56-10, CTL-12L-8, CTL-6-P, CTL-6-P-H, CTL-6-S-H (manufactured by U.R.D. Co., Ltd.)
Current sensor	
Allowable input current	0 to 182.2 mA/rms

Items	Specifications
Heater current measured value	When CTL-12-S36-8 is used: 0.0 to 100.0 A When CTL-12-S36-10 is used: 0.0 to 100.0 A When CTL-12L-8 is used: 0.0 to 100.0 A When CTL-6-P is used: 0.0 to 30.0 A When CTL-6-S-H is used: 0.0 to 30.0 A
Measurement precision	Larger one between ±5% of input value and ±2 A (Excluding precision of current sensor)
Sampling period	0.5 sec.

4.7 Measured Temperature Range

Input type	Measurement precision
K	-200 to +1300°C (-100 to +2400°F)
J	-200 to +1200°C (-100 to +2100°F)
T	-200 to +400°C (-300 to +700°F)
S	0 to 1700°C (0 to 3200°F)
R	0 to 1700°C (0 to 3200°F)
E	-200 to +1000°C (0 to 1800°F)
B	0 to 1800°C (0 to 3000°F)
N	0 to 1300°C (0 to 2300°F)
PLII	0 to 1200°C (0 to 2300°F)
W5Re/W26Re	0 to 2300°C (0 to 3000°F)
U	-200 to +600°C (-300 to +700°F)
L	0 to 900°C (0 to 1600°F)
Micro voltage input	DC0 to 10 mV, DC0 to 100 mV
Pt100 (3-wire type)	-200 to +600°C (-300 to +1100°F)