MENICS

95mm 각형

15W 혼 스피커 전자음 경보기 (P) (ROHS) VH 시리즈

제품특징

- 가로, 세로 설치방향의 자유로움
- 9가지의 다중 사운드가 내장되어 다양한 환경에 적합한 신호음 선택가능
- 높은 보호등급 IP66 구조로 옥외 및 먼지가 상존하는 장소에서 밀폐성이 우수합니다.
- LED타입 (MQVL, MQVM 시리즈) 및 스트로브 램프타입(MQVX 시리즈)과 연결, 조합하여 다양한 연출이 가능합니다.

취급설명서

메닉스 제품을 구입하여 주셔서감사합니다. 본 제품를 바르고 안전하게 사용하기 위해서 사용 전에 본 사용설명서를 반드시 읽고 숙지하시기 바랍니다.

안전을 위한 주의사항

- ※ '안전을 위한 주의사항'은 제품을 안전하고 올바르게 사용하여 사고나 위험을 미리 막기 위한것이므로 반드시 지켜 주십시오.
- ※ 주의 사항은 '경고'와 '주의'의 두 가지로 구분되어 있으며 경고'와 '주의'의 내용은 다음과 같습니다.



지시 사항을 위반하였을 때, 심각한 상해나 사망이 발생할 가능성이 있는 경우



지시 사항을 위반하였을 때, 경미한 상해나 제품에 손상이 발생할 가능성이 있는 경우

※ 제품과 사용설명서에 표시된 그림기호의 의미는 다음과 같습니다. ▲ 는 특정조건 하에서 위험이 발생할 우려가 있으므로 주의하라는 기호입니다.

▲ 경고

- 1. 인명이나 재산상에 영향이 큰 기기(예: 원자력 제어, 의료기기, 차량, 철도, 항공, 연소장치, 오락기기 등 또는 안전장치)에 사용할 경우 반드시 2중으로 안전장치를 부착한 후 사용하여 주십시오.
 - 화재, 인명사고, 재산상의 막대한 손실이 발생할 수 있습니다.
- 2. 제품을 분해 및 개조하지 마십시오. 내부 점검이나 수리는 본사 또는 사무소에 문의 바랍니다.
- 화재, 감전, 및 제품 파손의 우려가 있습니다.
- 3. 전원이 인가된 상태에서 결선 및 점검, 보수를 하지 마십시오. 감전의 우려가 있습니다.
- 4. 전원 입력 전압은 반드시 정격 범위를 지켜 사용하십시오. 화재나 감전의 우려가 있습니다.
- 5. 전원을 인가하기 전에 반드시 접속이 정확한지 확인하십시오. 화재나 감전 및 제품 파손의 우려가 있습니다.
- 6. 실외 및 폭발의 위험, 인화성 가스, 물이 있는 장소, 가연물 근처, 진동이 많은 곳에서는 사용하지 마십시오. 화재나 감전, 부상의 우려가 있습니다.
- 7. 커버를 분리 한 상태, 느슨해 진 상태 또는 깨진 상태로 방치, 사용하지 마십시오.

▲ 주 의

- 1. 제품에 이상이 발생할 경우 즉시 입력 전원을 차단해 주십시오. 화재나 제품 파손의 우려가 있습니다
- 2. 진동이 심한 곳에서는 사용하지 마십시오. 제품의 파손 우려가 있습니다
- 3. 단자대의 볼트 조임 토오크는 0.4~0.6N.m의 범위를 지켜 주십시오. 제품 파손의 우려가 있습니다.
- 4. 청소 시 반드시 전원을 차단 후, 물기가 없는 마른 수건으로 청소하십시오. 감전 및 화재의 우려가 있습니다.

본 제품은 출하 시 완전 조립된 형태로 납품되어 지지만 사용자(전문가)가 별도로 일부분를 분리하여 고정, 결선, 조립작업을 필요로 합니다.



■제품모델구분

MQVH - 9 F F

① 내장음 수량

9 9가지 사운드

② 전원전압

00 12~24VDC FF 110~220VAC


검정색

③ 혼 커버색상 R 적색 В

■정격/성능

모델	MQVH-9
전원전압	12V~24VDC , 110~220VAC (50/60Hz)
허용전압범위	10.8V~26.4VDC , 100~240VAC
소비전류	12V~24VDC: 0.45A(±10%) 110~220VAC: 0.20A(±10%)
최대음량 (1M)	105±5dB
음량조절	조절볼륨내장
사운드 종류	멜로디: 3음 신호음: 3음 싸이렌: 3음
제품고정	몸체 하단면 고정-나사 고정식 (M6, 2개)
전원선 삽입	본체의 내부 하단 - 케이블 최대 직경: Ø7mm 본체 외부 2개소- 케이블 그랜드 적용 (PG7∼PG13.5)
전원선 추천	AC제품: 18AWG, DC제품: 22AWG
제품색상	몸체 — 검정색 , 스피커 혼 커버— 검정색 or 적색
재질	몸체 — PA6 , 스피커커버 — ABS
절연저항	100Mp 이상 (전단자와 케이스간 500VDC 메가기준)
내전압	500VAC 50/60Hz 1분간 (전단자와 케이스간)
내진동	10~55Hz(주기 1분간) 복진폭 0.75mm X,Y,Z 각 방향 1시간
온도	사용주위온도 : -20 ~ 50°C 보관주위온도 : -20 ~ 70°C
사용주위습도	45~85% RH
보호구조	IP65
취득인증	RoHS
중량	약. 535g (AC형 기준)

■외형치수 (단위:mm)




※ 이 설명서의 주의사항에 기재 한 주의사항 주의사항에 반하는 취급 개조 또는 천재 지변 등으로 인한 고장 및 손해 등에 대해서는 책임을 지지 않으므로 양해 바랍니다.


■제품고정

- 제품 고정시 내부의 회로에 손상이 가지 않도록 주의 하십시오.
- 판넬의 내부 결선 단자대부에 물이 들어가지 않도록 조치를 취하고 설치하십시오. 충분한 강도와 진동이 적은 장소에 설치하십시오.
- 제품의 신뢰성 확보를 위해서 가능한 판넬 등의 금속면에 취부하십시오.
- - 분진이 많은 곳은 되도록이면 피하여 주십시오.
 - 방열 효과를 높이기 위해서 바람이 잘 통하는 곳에 취부하십시오.

제품을 고정 전에 스피커 고정나사를 풀어서 혼 스피커와 제품본체 를 분리하십시오.




포장되어있는 고정나사 2개로 제품 본체를 판넬에 고정하십시오.




제품 본체 옆면에 케이블그랜드 부속품을 이용하여 전원선 삽입시 제품 본체 고정 전에 드릴 및 홀 커터를 사용하여 홀 커팅 작업을 하여야 합니다.


· 작업시 회로부가 손상되지 않도록 주의하십시오.




제품 본체를 고정 후, 전원선 결선 및 사운드 선택/볼륨설정을 하고, 혼 스피커 커버를 다시 조립하십시오. - 혼 스피커커버 조립 전, 사운드 선택 및 볼륨 조절 시, 스피커 전원 커넥터를 본체



■2개이상 연결하여 사용시 고정치수(단위:mm)




■ 연결커플링 조립방법




■결선및 설정



- 전원선 연결전에 반드시 전원 공급 장치를 차단하십시오. 교트에 의한 내부 회로의 소손이나 전기 감전의 위험이 있습니다. 직류, 교류 및 사용 전압이 틀리지 않도록 확인한 후 사용하십시오.
- 전원 측에는 반드시 외부 접점용 퓨즈를 넣어주세요 (권장: 250V, IA) 정격 규즈 사용시 과전압, 오결선에 따른 제품 손실을 예방할 수 있습니다
- 전원을 별도로 차단하는 스위치는 본체에는 없습니다.
- 전원입력단자의 전원선은 AWG.22~18의 케이블을 사용하십시오.
- 노이즈 대책으로 가능한 한 짧게 배선하고, 실드 선을 사용하는 것을 권장합니다. - 전원입력단자의 경우, 반드시 압착단자를 이용하십시오.



- 본 상품 출하시 사운드 볼륨은 최대값으로 설정되어 있음



■자매품

연결 제품 및 부품은 별도로 구매하여야 합니다. 본사 및 구매처에 문의 바랍니다.

MQVX 시리즈

Xenon 램프 경고등

- 야간 시인성은 물론 낮에도 우수한 시인성을 가짐
- 분당 60~70회의 점멸기능





MQVM 시리즈 멀티색상 표시등

- 점등, 점멸기능



경남 양산시 웅비공단길 118-1번지 우.50524 전화: 055-371-5200 SIGNALTECHNOLOGY http://www.menics.co.kr E-mail: menics@chol.com

팩스: 055-371-5202

치수, 사양 및 구조 등은 개선을 위해 예고없이 변경 될 수 있습니다.



15W Horn speaker type 95mm Cube Electronic Multi-Tone Sounder

MOVH Series

Product Feature

- Built-in 15W high power speaker
- Volume adjustable up to 105dB
- 9 tones for a diverse range of applications
- High protection rating IP 65
- Connection with signal light products (MQVL, MQVX series)

Instruction Manual

Thank you for purchasing Menics product, For the proper and safe use of this product, please read and fully understand this manual before use.

Instructions for safety

- * Instruction for safety is made to prevent accidents or risks in dvance by using the product safely and correctly and be sure to observe it.
- * Instructions are divided into two categories as "Warning" and "Attention" and they are as follows.

A	Warning
Λ	Attention

If instruction is violated, there is the possibility of serious injury or death.

If instruction is violated, there is possibility of minor injury or damage on the product.

* The meaning of the picture symbols used in the product and User manual ▲ is the sign meaning attention needs to be paid because there is the concern of

risk occurrence under certain condition. **A** Warning

- 1. In case it is used for the machines which make greater impact on life or property (e.g. nuclear power control, medical equipment, railroad car, aerospace, combustion equipment, recreation equipment, etc. or safety devices), make sure to attach safety device bifariously before use.
- There is the possibility of causing huge losses resulted from fire, personal injury and property damage. 2. Do not disassemble and renovate the product. Please contact the head office
- or regional office for internal inspection or repair. There is the risk of causing fire, electrical shock and product damage.
- 3. While power is on, do not make wiring, maintenance or repair.
- There is the danger of electrical shock. 4. Rated voltage range must be kept for the power input voltage.
- There is the danger of fire or electric shock. 5. Before power on, make sure to check whether connection is made correctly.
- There is the danger of fire, electrical shock or product damage.
- 6. When replacing lens, there might be remaining current. Make sure to replace lens one minute after putting off power. There is the danger of electric shock.
- 7. Do not operate this product with the lens cover removed, use at the cracked lens cover or being loosed dome.

A Attention

- 1. Make sure that there is nothing blocking the flow of air circulating. There is the danger of deformation and product damage caused by heat.
- 2. When the product is in operation, do not touch the product for a while.
- 3. In case abnormality happens to the product, unplug the input power connection immediately. There is the danger of fire or product damage.
- 4. Do not use in places with severe vibration.
- There is the danger of product damage.
- 5. When cleaning, do not use water, organic solvent and clean with towel without moisture. There is the danger of electric shock or fire.

MENICS 118-1, Ungbigongdan-gil, Yangsan-si, Gyeongsangnam-do, Korea, 50524

SIGNALTECHNOLOGY TEL: 82-55-371-5200 FAX: 82-55-371-5202 E-mail: menics@chol.com

This product is delivered in the fully assembled form at the time of shipment, but the user (professional) needs to separate the part separately and fix, wire and



■ Ordering Information

MQVH - 9 F F - R

(1) Built-in Sound **9** 9 tones

(2) Power Supply


00 12~24VDC FF 110~220VAC

(3) Horn Cover Color

■ Specifications

	Model	MQVH-9
	Power supply	12V~24VDC , 110~220VAC (50/60Hz)
	Allowable voltage range	10.8V~26.4VDC , 100~240VAC
	Current consumption (±10%)	12V~24VDC: 0.45A(±10%) 110~220VAC: 0.20A(±10%)
	Sound volume (max)	105±5dB
ĺ	Volume control	Built-in volume control
	Sound type	Melody : 3ch Signal : 3ch Siren : 3ch
i	Mounting Method	Body bottom face fixing - Screw type (M6, 2EA)
	Power cable insertion	Bottom of main body - Maximum cable diameter: Ø7mm Two external locations - Cable gland (PG7~PG13.5)
ĺ	Connection (recommendation)	AC type: 18AWG, DC type: 22AWG
	Color	Body - Black, Speaker cover- Black, Red color
	Material	Body - PA6 resin, Speaker Cover - ABS resin
	Insulation resistance	Over 100MΩ (500VDC mega between terminals and case)
	Withstand voltage	500V AC 50/60Hz 1min (between terminals and case before)
	Vibration	0.75mm at 10~55Hz (cycle: 1minute)
	Temperature	Working temperature : $-20 \sim 50^{\circ}\text{C}$ Storage temperature : $-20 \sim 70^{\circ}\text{C}$
	Ambient humidity	45~85% RH
	Protection structure	IP65
	Approva l	RoHS
	Weight	App. 535g (AC type standard)


■ **Dimensions** (Unit:mm)



Release note that you can not be held liable for any malfunctions or damages caused by handling, modification or natural disaste contrary to the precautions described in this manual. Dimensions, specifications and structure are subject to change without notice for improvemen please understand

■ Fixing Product


Be careful not to damage the internal circuit when fixing the product.




Mount on the metal surface such as the panel to ensure the reliability of the product. Avoid dusty places.


- To increase the heat dissipation effect, please install it in a place where the air is


Before fixing the product, loosen the fixing screw of the speaker cover and



Fix the product to the panel with two mounting screws. (Screw tightening torque: 2.6~3N.m)








- After fixing the product to the panel, wire the power cord and select the sound and volume, and reassemble the horn speaker cover.
 - Before assembling the horn speaker cover, connect the speaker power connector to the main unit.


Connect to the speaker connector on the internal PCB



■ Fixed dimensions when connecting two or more

"L" Product Length 2 section-192mm 3 section-288mm 4 section-384mm

■ How to assemble the coupling



■ Wiring diagram



Always disconnect the power supply before wiring.
 There is a risk of electric circuit damage or electric shock due to short circuit.

Make sure that DC, AC and voltage are correct.

Be sure to insert a fuse for external contact on the power supply side.


When using rated fuse, it is possible to prevent the product loss due to overvoltage and wrong wiring.


There is no switch that cuts off the power separately.

- Use the AWG.22 ~ 18 cable for the power line of the power input terminal.

To prevent noise, it is recommended to use shielded wires and make wiring as short as possible.

- For the power input terminal, be sure to use crimp terminal.





■Used together with-

Connected products and parts must be purchased separately. Please contact the headquarters or your place of purchase.

MQVX series

Xenon lamp strobe light

- Diffusing very clear light for night-time visibility as well as daytime.
- 60 ~ 70 flashing per minute





MQVL series LED Signal Light

MQVM series Multi-color LED Signal Light

- LED Function :

Steady, Flashing

