

## F03-12 Spring Clamp

Used to clamp an Electrode Holder with ease, as shown in the illustrations, when the Electrode Holder is applied to a tank without a coupling.

Squeeze the mounting frame into the Holder as shown below.

Applicable Electrode Holders:  
PS-3S(R), PS-4S(R), PS-5S

