


For IZS41, 42

IZS41-C



• **AC adapter**

G1	AC adapter + AC cord* ¹
G2	AC adapter (Without AC cord)



For IZS41, 42

*¹ When “G1” is selected, an AC cord with a rated voltage of 125 V is included. If using an input voltage exceeding 125 VAC, select “G2” (Without AC cord) and prepare a suitable AC cord separately. The external input/output function of the IZS41 and 42 cannot be used when an AC adapter is being used.

