## **MU Series INSTRUCTION MANUAL**

TCD210224AD

**Autonics** 

Thank you for choosing our Autonics product.

Read and understand the instruction manual and manual thoroughly before using the product.

For your safety, read and follow the below safety considerations before using. For your safety, read and follow the considerations written in the instruction manual, other manuals and Autonics website.

Keep this instruction manual in a place where you can find easily.



Visit Autonics website (www.autonics.com or QR code) for the latest information, Manuals, CAD files, certifications, software, etc. are available. The dimensions, specifications, certifications, etc. are subject to change without notice for product improvement. Certain models may be discontinued without notice.

### **Safety Considerations**

- Observe all 'Safety Considerations' for safe and proper operation to avoid hazards.
- ▲ symbol indicates caution due to special circumstances in which hazards may occur.

▲ Warning Failure to follow instructions may result in serious injury or death.

- 01. Fail-safe device must be installed when using the unit with machinery that may cause serious injury or substantial economic loss. (e.g. nuclear power control, medical equipment, ships, vehicles, railways, aircraft, combustion apparatus, safety equipment, crime/disaster prevention devices, etc.) ailure to follow this instruction may result in personal injury, economic loss or fire.
- 02. Do not use or store the unit in the place where flammable/explosive/ corrosive gas, high humidity, direct sunlight, radiant heat, vibration, impact, or salinity may be present.
- Failure to follow this instruction may result in explosion or fire.
- 03. Do not disassemble or modify the unit.
- Failure to follow this instruction may result in fire.
- 04. Do not connect, repair, or inspect the unit while the load is connected to a power source.
- Failure to follow this instruction may result in fire.
- 05. Check 'Connections' before wiring. Failure to follow this instruction may result in fire.

▲ Caution Failure to follow instructions may result in injury or product damage.

- 01. Use the unit within the rated specifications.
  - Failure to follow this instruction may result in fire or product damage.
- 02. Use a dry cloth to clean the unit, and do not use water or organic solvent. Failure to follow this instruction may result in fire
- 03. Make cable length as short as possible.
  - Failure to follow this instruction may result in malfunction.
- 04. Do not install the switch on the magnetic object or in the environment of ferromagnetic fields. Use bolt and nut of stainless steel or nonmagnetic material. when installing the switch.
- Failure to follow this instruction may result in malfunction or affect sensing
- 05. Do not use a load over the range of rated relay specification.

Failure to follow this instruction may result in fire, relay broken, contact melt. insulation failure or contact failure.

### **Cautions during Use**

- Follow instructions in 'Cautions during Use'. Otherwise, it may cause unexpected
- If excessive shock or vibration is applied to the product, it may cause bounce or
- Use the slow mode filter to avoid bounce and chattering. Bounce and chattering may occur when high-speed mode ( $\leq 1$  ms) filter is applied.
- This unit may be used in the following environments.
- Indoors (in the environment condition rated in 'Specifications')
- Pollution degree 3
- Installation Category II

**Product Components** 

### **Ordering Information**

This is only for reference, the actual product does not support all combinations. For selecting the specified model, follow the Autonics website.

- 0 - 2 - 8

### Contact type 1A: Normally open

MU

## 1B: Normally closed

### ❸ Cable type

No mark: cable type (2 m) E: Cable connector type (0.5 m)

### Sensing distance

Number: Standard sensing distance (unit: mm)

### **Specifications**

Model		MU-1A-30-□	MU-1B-30-□
Contact		N.O.	N.C.
Operating 0	OFF → ON	$\pm$ 10 mm	
distance 01)	ON → OFF	$\pm$ 20 mm	
Standard sen	sing target	Steel plate - a galvanized steel sheet 1.6t	
Operating tin	me	$\leq$ 2 ms	
Release time	•	$\leq 1\mathrm{ms}$	
Operating fro	equency	≤ 500 Hz	
Approval		C€ K EHI	
Unit weight (	(package)	Cable type: $\approx$ 132.5 g ( $\approx$ 172.3 g) Cable connector type: $\approx$ 107 g ( $\approx$	

01) Rated at the ambient tempe	erature of 23 °C. It can be differed up to $\pm 20$ % according to the ambient temperature.
Switching voltage	≤ 24 VDC==
Life expectancy	≥ 100 million times (at a resistive load of 5 VDC=m 10 mA)
Insulated resistance	$\geq$ 1,000 M $\Omega$ (500 VDC== megger)
Dielectric strength	Between the charging part and the case: 500 VAC $\sim 50/60~{\rm Hz}$ for 1 min
Vibration	$1.5\mathrm{mm}$ double amplitude at frequency of 10 to 55 Hz in each X, Y, Z direction for 2 hours
Shock	$100  \text{m/s}^2$ ( $\approx 10  \text{G}$ ) in each X, Y, Z direction for 3 times
Ambient temperature	-10 to 65 °C, storage: -10 to 70 °C (no freezing or condensation)
Ambient humidity	35 to 85 %RH, storage: 35 to 85 %RH (no freezing or condensation)
Protection structure	IP67 (IEC standard)
Connection	Cable type / Cable connector type
Cable	Cable type: Ø 4, 2-wire, 2 m (UL Style 20276, AWG22) Cable connector type: Ø 4, 2-wire, 0.5 m (UL Style 20276, AWG22)
Material	Cover/Case: PC (915R)

### ■ Applied REED SWITCH


p	
Model	ORD324-10-15 (STANDEX MEDER)
Contact	A (SPST-NO: single pole, single throw, normally open)
Contact rating <sup>01)</sup>	≤ 10 W/VA
Voltage	Switching: ≤ 200 VDC==, Breakdown: ≥ 250 VDC==
Current	Switching: ≤ 0.5 A, Carry: ≤ 1.0 A
Ambient temperature	-40 to 125 °C, storage : -65 to 125 °C (22)
Material	Body: glass, leads: tin-plated Ni-Fe wire

- 01) Switching voltage and current should never exceed the wattage rating.
- 02) Long time exposure at elevated temperature may degrade solderability of the leads.

### **Operating Distance**

- Operating distance is the distance between the center line of switch and the target.
- Install the product to be operated within the  $\pm$  20 % of the operating distance.
- The operating distance may be affected by metal or magnetic substances which is placed closely to the switch.


# Moving direction | Operating distance



### Dimensions

• Unit: mm, For the detailed dimensions of the product, follow the Autonics web site.

### ■ MU-□-30 ■ MU-□-30-E



### Connections

### ■ MU-1A-30-

Pin	Color	Function	Internal circuit
4	Blue	Normally Open	4
5	Brown	Normally Open	5

### ■ MII-1R-30-


Pin	Color	Function	Internal circuit
4	Blue	Normally Closed	4
5	Brown	Normally Closed	5

Daedong Inc.


Pin arrangen

•	MO 1D 30 🗆			
n	Color	Function	Internal circuit	
	Blue	Normally Closed	4	
	Brown		5	

### **Timing Diagram**




### ■ MU-1B-30-




### **Cautions during Installation**

- Install the product according to the rated specifications, environment, and place.
- The waterproof function may be damaged if the product is subjected to impact from a hard object or bent excessively or repeatedly.
- Tighten the M5 screw with the tightening torque of 0.8 N·m.
- Installing more than 2 switches closely may result in malfunction due to mutual interference.

Keep the distance between units.






• Install the switch to the position where the center of the switch and the target be exactly horizontal and vertica




• If it is hard to align along the center line, install the switch to the position where the target is closer to the switch part, rather than magnet part.

Otherwise, the target can be attached to the magnet part, so that it can result in malfunction



• Install the switch to the position where the target passes the sensing point area. Sensing point area: area between 30 mm point and 40 mm point from the end of the switch



18, Bansong-ro 513Beon-gil, Haeundae-gu, Busan, Republic of Korea, 48002 www.autonics.com | +82-2-2048-1577 | sales@autonics.com

Autonics